SERVICE BULLETIN

MITSUBISHI MOTORS

GLOBAL AFTER SALES OFFICE, MITSUBISHI MOTORS CORPORATION

PURPOSE : INFORMATION	ISSUE NO. : MSB-11E00-601	DATE : 2011-09-18
SUBJECT : FLAT RATE TIME FOR PAJERO SPORT		<MODEL> (EUR) (KG0W / KH0W) <M/Y> 12
GROUP : GENERAL		

1. Description:

According to the establishment of the 2012 PAJERO SPORT, the flat rate times for the model are added to the following Flat Rate Manual. This Service Bulletin contains the added flat rate times..

2. Applicable Manual:

Manual	Pub. No.	Attached Sheet
2012 Flat Rate Manual (Revised version)	PFAM1101R	Attached sheet

CODE	DESCRIPTION	KG0W KH0W
110010 00	ENGINE ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	6.3
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.3
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	4G6	5.1
	4M4	8.4
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	6B3	7.3
	[Additional time allowance]	
	B1 ··· With transfer	1.8
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	6G7	7.9
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	COMMON 4M4	8.4
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
110010 10	ENGINE ASSEMBLY ··· REPLACEMENT	
	4D5	6.3
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.3
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	4G6	5.1
	4M4	8.4
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	6B3	7.3
	[Additional time allowance]	
	B1 ··· With transfer	1.8
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	6G7	7.9
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	COMMON 4M4	8.4
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A7 ··· Rear heater air duct – R&I	0.6
110010 20	ENGINE ASSEMBLY ··· OVERHAUL	
	4D5	21.9
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	4G6	18.2
	4M4	21.8
	[Additional time allowance]	
	B8 ··· Automatic transmission	0.4
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	6B3	25.4
	[Additional time allowance]	
	B1 ··· With transfer	1.8
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	6G7	22.3
	[Additional time allowance]	
	B8 ··· Automatic transmission	0.3
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
	COMMON 6B3	25.4
	[Additional time allowance]	
	B1 ··· With transfer	1.8
	[Additional operation]	
	A7 ··· Rear heater air duct – R&I	0.6
110010 40	ENGINE ASSEMBLY ··· ADJUSTMENT	
	4D5	2.8
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts – R&I	0.3
	4G6	1.0
	4M4	2.6
	6B3	2.3
	6G7	1.0
	COMMON 4D5	2.8
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts – R&I	0.3
110011 00	SHORT ENGINE ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	13.3
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4M4	16.1
	[Additional time allowance]	
	C8 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	12.5

CODE	DESCRIPTION	KG0W KH0W
	[Additional time allowance]	
	D3 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	11.9
	[Additional time allowance]	
	C8 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 4M4	16.1
	[Additional time allowance]	
	C8 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
110011 10	SHORT ENGINE ASSEMBLY ··· REPLACEMENT	
	4D5	13.3
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	8.3
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	16.1
	[Additional time allowance]	
	C8 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	12.5
	[Additional time allowance]	
	D3 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	11.9
	[Additional time allowance]	
	C8 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 4M4	16.1
	[Additional time allowance]	
	C8 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
111110 00	CYLINDER BLOCK ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	16.0
	[Additional time allowance]	

CODE	DESCRIPTION	KG0W KH0W
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	13.7
	4M4	19.0
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	16.6
	[Additional time allowance]	
	C4 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	17.5
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 4M4	19.0
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
111110 10	CYLINDER BLOCK ASSEMBLY ··· REPLACEMENT	
	4D5	16.0
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	13.7
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	19.0
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	16.6
	[Additional time allowance]	
	C4 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	17.5
	[Additional time allowance]	

CODE	DESCRIPTION	KG0W KH0W
	D9 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 4M4	19.0
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
111210 00	CYLINDER HEAD ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	11.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts – R&I	0.3
	A7 ··· Front under floor heat protector – R&I	0.2
	4G6	7.9
	4M4	11.4
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.3
	6B3	11.0
	6G7	10.4
	COMMON 4D5	11.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts – R&I	0.3
	A7 ··· Front under floor heat protector – R&I	0.2
111210 10	CYLINDER HEAD ASSEMBLY ··· REPLACEMENT	
	4D5	11.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts – R&I	0.3
	A7 ··· Front under floor heat protector – R&I	0.2
	4G6	7.9
	4M4	11.4
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.3
	COMMON 4D5	11.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts – R&I	0.3
	A7 ··· Front under floor heat protector – R&I	0.2
111210 20	CYLINDER HEAD ASSEMBLY ··· OVERHAUL	
	4D5	12.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts – R&I	0.3
	A7 ··· Front under floor heat protector – R&I	0.2
	4G6	8.9
	4M4	12.4
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.3
	COMMON 4D5	12.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts – R&I	0.3
	A7 ··· Front under floor heat protector – R&I	0.2
111210 84	CYLINDER HEAD ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT	
	6B3	10.7
	[Additional operation]	
	A1 ··· Both side replace	4.3

CODE	DESCRIPTION	KG0W KH0W
	6G7	10.3
	[Additional operation]	
	A1 ··· Both side replace	4.4
	COMMON 6B3	10.7
	[Additional operation]	
	A1 ··· Both side replace	4.3
111210 85	CYLINDER HEAD ASSEMBLY (RIGHT SIDE) ··· OVERHAUL	
	6B3	11.4
	[Additional operation]	
	A1 ··· Both side overhaul	5.0
	6G7	11.0
	[Additional operation]	
	A1 ··· Both side overhaul	5.1
	COMMON 6B3	11.4
	[Additional operation]	
	A1 ··· Both side overhaul	5.0
111210 86	CYLINDER HEAD ASSEMBLY (LEFT SIDE) ··· REPLACEMENT	
	6B3	11.0
	6G7	10.4
	COMMON 6B3	11.0
111210 87	CYLINDER HEAD ASSEMBLY (LEFT SIDE) ··· OVERHAUL	
	6B3	11.7
	6G7	11.1
	COMMON 6B3	11.7
111221 00	CYLINDER HEAD GASKET ··· REMOVAL AND INSTALLATION	
	4D5	8.0
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	A7 ··· Front under floor heat protector − R&I	0.2
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	4G6	3.7
	4M4	7.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	6B3	7.7
	[Additional operation]	
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	6G7	7.0
	[Additional operation]	
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	COMMON 4D5	8.0
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	A7 ··· Front under floor heat protector − R&I	0.2
	A8 ··· Cylinder head assembly ··· cleaning	0.2
111221 10	CYLINDER HEAD GASKET ··· REPLACEMENT	
	4D5	8.0
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	A7 ··· Front under floor heat protector − R&I	0.2
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	4G6	3.7
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	4M4	7.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	COMMON 4D5	8.0
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	A7 ··· Front under floor heat protector − R&I	0.2
	A8 ··· Cylinder head assembly ··· cleaning	0.2
111221 84	CYLINDER HEAD GASKET (RIGHT SIDE) ··· REPLACEMENT	
	6B3	7.3
	[Additional operation]	
	A1 ··· Both side replace	1.0
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	6G7	7.0
	[Additional operation]	
	A1 ··· Both side replace	1.0
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	COMMON 6B3	7.3
	[Additional operation]	
	A1 ··· Both side replace	1.0
	A8 ··· Cylinder head assembly ··· cleaning	0.2
111221 86	CYLINDER HEAD GASKET (LEFT SIDE) ··· REPLACEMENT	
	6B3	7.7
	[Additional operation]	
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	6G7	7.0
	[Additional operation]	
	A8 ··· Cylinder head assembly ··· cleaning	0.2
	COMMON 6B3	7.7
	[Additional operation]	
	A8 ··· Cylinder head assembly ··· cleaning	0.2
111310 00	ROCKER COVER ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	2.5
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	0.8
	4M4	1.7
	6B3	1.4
	6G7	2.2
	COMMON 4D5	2.5
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
111310 10	ROCKER COVER ASSEMBLY ··· REPLACEMENT	
	4D5	2.5
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	0.8
	4M4	1.7
	COMMON 4D5	2.5
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
111310 84	ROCKER COVER ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT	

CODE	DESCRIPTION	KG0W KH0W
	6B3	0.6
	6G7	1.5
	COMMON 6G7	1.5
111310 86	ROCKER COVER ASSEMBLY (LEFT SIDE) ··· REPLACEMENT	
	6B3	1.4
	6G7	2.2
	COMMON 6G7	2.2
111311 00	ROCKER COVER GASKET ··· REMOVAL AND INSTALLATION	
	4D5	2.5
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4M4	1.7
	6B3	1.4
	6G7	2.2
	COMMON 4D5	2.5
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
111311 10	ROCKER COVER GASKET ··· REPLACEMENT	
	4D5	2.5
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	0.8
	4M4	1.7
	COMMON 4D5	2.5
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
111311 84	ROCKER COVER GASKET (RIGHT SIDE) ··· REPLACEMENT	
	6B3	0.6
	6G7	1.5
	COMMON 6G7	1.5
111311 86	ROCKER COVER GASKET (LEFT SIDE) ··· REPLACEMENT	
	6B3	1.4
	6G7	2.2
	COMMON 6G7	2.2
111320 00	OIL PAN ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	1.8
	[Additional time allowance]	
	B2 ··· With transfer	2.0
	4G6	2.2
	4M4	4.3
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
	6B3	3.6
	[Additional time allowance]	
	B2 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
	6G7	5.2
	COMMON 6G7	5.2
111320 10	OIL PAN ASSEMBLY ··· REPLACEMENT	
	4D5	1.8
	[Additional time allowance]	
	B2 ··· With transfer	2.0
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2

CODE	DESCRIPTION	KG0W KH0W
	4G6	2.2
	4M4	4.3
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
	6B3	3.6
	[Additional time allowance]	
	B2 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	6G7	5.2
	COMMON 6G7	5.2
111321 00	OIL PAN GASKET (LIQUID GASKET) ··· REMOVAL AND INSTALLATION	
	4D5	1.8
	[Additional time allowance]	
	B2 ··· With transfer	2.0
	4M4	4.3
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
	6B3	3.6
	[Additional time allowance]	
	B2 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	6G7	5.2
	COMMON 6G7	5.2
111321 10	OIL PAN GASKET (LIQUID GASKET) ··· REPLACEMENT	
	4D5	1.8
	[Additional time allowance]	
	B2 ··· With transfer	2.0
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	4G6	2.2
	4M4	4.3
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
	6B3	3.6
	[Additional time allowance]	
	B2 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	6G7	5.2
	COMMON 6G7	5.2
111330 00	FRONT CASE ASSEMBLY ··· REMOVAL AND INSTALLATION	4.8
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts - R&I	0.2
111330 10	FRONT CASE ASSEMBLY ··· REPLACEMENT	4.8
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts - R&I	0.2
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
111331 00	FRONT CASE GASKET ··· REMOVAL AND INSTALLATION	4.8
	[Additional time allowance]	

CODE	DESCRIPTION	KG0W KH0W
	B3 ··· With transfer	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
111331 10	FRONT CASE GASKET ··· REPLACEMENT	4.8
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
111336 00	TIMING CHAIN (GEAR) CASE ··· REMOVAL AND INSTALLATION	13.9
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
111336 10	TIMING CHAIN (GEAR) CASE ··· REPLACEMENT	13.9
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
111337 00	TIMING CHAIN (GEAR) CASE GASKET ··· REMOVAL AND INSTALLATION	13.9
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
111337 10	TIMING CHAIN (GEAR) CASE GASKET ··· REPLACEMENT	13.9
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
111351 00	TIMING BELT FRONT UPPER COVER ··· REMOVAL AND INSTALLATION	
	4D5	0.3
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts − R&I	0.3
	6B3	1.2
	6G7	2.2
	COMMON 6G7	2.2
111351 10	TIMING BELT FRONT UPPER COVER ··· REPLACEMENT	0.3
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts − R&I	0.3
111351 84	TIMING BELT FRONT UPPER COVER (RIGHT SIDE) ··· REPLACEMENT	
	6B3	1.2
	6G7	2.1
	COMMON 6G7	2.1
111351 86	TIMING BELT FRONT UPPER COVER (LEFT SIDE) ··· REPLACEMENT	
	6B3	1.0
	6G7	2.2
	COMMON 6G7	2.2
111352 00	TIMING BELT FRONT LOWER COVER ··· REMOVAL AND INSTALLATION	
	4D5	1.4
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	1.6
	6G7	2.5
	COMMON 6G7	2.5
111352 10	TIMING BELT FRONT LOWER COVER ··· REPLACEMENT	
	4D5	1.4
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	1.6
	6G7	2.5
	COMMON 6G7	2.5
112110 00	PISTON ··· REMOVAL AND INSTALLATION (All)	
	4D5	12.9

CODE	DESCRIPTION	KG0W KH0W
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	7.0
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	14.0
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	12.6
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
112110 10	PISTON ··· REPLACEMENT (All)	
	4D5	12.9
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	7.0
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	14.0
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6

CODE	DESCRIPTION	KG0W KH0W
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	12.6
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
112120 00	PISTON RING ··· REMOVAL AND INSTALLATION (All)	
	4D5	12.9
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	7.0
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	14.0
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	12.6
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
112120 10	PISTON RING ··· REPLACEMENT (All)	
	4D5	12.9
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6

CODE	DESCRIPTION	KG0W KH0W
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	7.0
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	14.0
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	12.6
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
112210 00	CONNECTING ROD ASSEMBLY ··· REMOVAL AND INSTALLATION (All)	
	4D5	12.9
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	7.0
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	14.0
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	12.6
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
112210 10	CONNECTING ROD ASSEMBLY ··· REPLACEMENT (All)	
	4D5	12.9
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	7.0
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	14.0
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	12.6
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 6B3	14.3
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
112220 00	CONNECTING ROD BEARING (BIG END) ··· REMOVAL AND INSTALLATION (All)	
	4D5	12.9
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	7.0
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	14.0

CODE	DESCRIPTION	KG0W KH0W
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	14.3
	[Additional time allowance]	
	B1 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	12.6
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 6B3	14.3
	[Additional time allowance]	
	B1 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
112220 10	CONNECTING ROD BEARING (BIG END) ··· REPLACEMENT (All)	
	4D5	12.9
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	7.0
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	14.0
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	14.3
	[Additional time allowance]	
	B1 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	12.6
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 6B3	14.3
	[Additional time allowance]	
	B1 ··· With transfer	1.8

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
112310 00	CRANKSHAFT ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	14.7
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	9.5
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	17.7
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	16.1
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	13.1
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 4M4	17.7
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
112310 10	CRANKSHAFT ASSEMBLY ··· REPLACEMENT	
	4D5	14.7
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	9.5
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	17.7
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2

CODE	DESCRIPTION	KG0W KH0W
	6B3	16.1
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	13.1
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 4M4	17.7
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
112320 00	CRANKSHAFT MAIN BEARING ··· REMOVAL AND INSTALLATION (All)	
	4D5	14.7
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	9.5
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	17.7
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	16.1
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	13.1
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 4M4	17.7
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
112320 10	CRANKSHAFT MAIN BEARING ··· REPLACEMENT (All)	
	4D5	14.7

CODE	DESCRIPTION	KG0W KH0W
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.9
	4G6	9.5
	[Additional operation]	
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	4M4	17.7
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
	6B3	16.1
	[Additional time allowance]	
	C8 ··· With transfer	1.8
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	7.8
	6G7	13.1
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	6.2
	COMMON 4M4	17.7
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.4
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A1 ··· Cylinder head assembly ··· overhaul	4.2
112342 00	CRANKSHAFT OIL SEAL (FRONT) ··· REMOVAL AND INSTALLATION	
	4D5	2.0
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts – R&I	0.2
	4G6	2.3
	4M4	1.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	2.8
	6G7	2.9
	COMMON 6G7	2.9
112342 10	CRANKSHAFT OIL SEAL (FRONT) ··· REPLACEMENT	
	4D5	2.0
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts – R&I	0.2
	4G6	2.3
	4M4	1.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	2.8
	6G7	2.9
	COMMON 6G7	2.9

CODE	DESCRIPTION	KG0W KH0W
112352 00	CRANKSHAFT OIL SEAL (REAR) ··· REMOVAL AND INSTALLATION	
	4D5	4.2
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	3.6
	Q8 ··· Manual transmission, With transfer	3.7
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	4G6	2.5
	4M4	5.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	6B3	4.6
	[Additional time allowance]	
	B1 ··· With transfer	1.9
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	6G7	5.7
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.7
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
112352 10	CRANKSHAFT OIL SEAL (REAR) ··· REPLACEMENT	
	4D5	4.2
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	3.6
	Q8 ··· Manual transmission, With transfer	3.7
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	4G6	2.5
	4M4	5.3
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	6B3	4.6
	[Additional time allowance]	
	B1 ··· With transfer	1.9
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	6G7	5.7
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.7
	[Additional operation]	
	AA ··· Rear heater air duct – R&I	0.6
112370 00	CRANKSHAFT PULLEY ··· REMOVAL AND INSTALLATION	
	4D5	1.0
	4G6	0.8
	4M4	1.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	0.7
	6G7	0.6
	COMMON 4D5	1.0
112370 10	CRANKSHAFT PULLEY ··· REPLACEMENT	

CODE	DESCRIPTION	KG0W KH0W
	4D5	1.0
	4G6	0.8
	4M4	1.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	0.7
	6G7	0.6
	COMMON 4D5	1.0
112410 00	FLYWHEEL ··· REMOVAL AND INSTALLATION	
	4D5	4.7
	4G6	2.4
	4M4	5.1
	6G7	5.7
	COMMON 6G7	5.7
112410 10	FLYWHEEL ··· REPLACEMENT	
	4D5	4.7
	4G6	2.4
	4M4	5.1
	6G7	5.7
	COMMON 6G7	5.7
112411 00	FLYWHEEL RING GEAR ··· REMOVAL AND INSTALLATION	
	4D5	4.7
	4M4	5.1
	6G7	5.8
	COMMON 6G7	5.8
112411 10	FLYWHEEL RING GEAR ··· REPLACEMENT	
	4D5	4.7
	4M4	5.1
	6G7	5.8
	COMMON 6G7	5.8
112412 00	FLYWHEEL BALL (PILOT) BEARING ··· REMOVAL AND INSTALLATION	
	4D5	4.7
	4M4	5.2
	6G7	5.8
	COMMON 6G7	5.8
112412 10	FLYWHEEL BALL (PILOT) BEARING ··· REPLACEMENT	
	4D5	4.7
	4M4	5.2
	6G7	5.8
	COMMON 6G7	5.8
112420 00	DRIVE PLATE ··· REMOVAL AND INSTALLATION	
	4D5	3.0
	[Additional time allowance]	
	B2 ··· With transfer	1.6
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
	4M4	5.1
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
	6B3	4.5
	[Additional time allowance]	
	B2 ··· With transfer	1.9
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
	6G7	5.6

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.6
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
112420 10	DRIVE PLATE ··· REPLACEMENT	
	4D5	3.0
	[Additional time allowance]	
	B2 ··· With transfer	1.6
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
	4M4	5.1
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
	6B3	4.5
	[Additional time allowance]	
	B2 ··· With transfer	1.9
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
	6G7	5.6
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.6
	[Additional operation]	
	A5 ··· Rear heater air duct – R&I	0.6
112510 00	BALANCER SHAFT ASSEMBLY ··· REMOVAL AND INSTALLATION (All)	
	4D5	9.5
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.3
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
	4G6	7.5
	4M4	16.6
	[Additional time allowance]	
	B7 ··· Automatic transmission	0.4
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
	COMMON 4M4	16.6
	[Additional time allowance]	
	B7 ··· Automatic transmission	0.4
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
112510 10	BALANCER SHAFT ASSEMBLY ··· REPLACEMENT (All)	
	4D5	9.5
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.3
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
	4G6	7.5
	4M4	16.6
	[Additional time allowance]	
	B7 ··· Automatic transmission	0.4
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A3 ··· Rear heater air duct – R&I	0.6
	COMMON 4M4	16.6
	[Additional time allowance]	
	B7 ··· Automatic transmission	0.4
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
112511 00	BALANCER SHAFT BEARING (METAL) ··· REMOVAL AND INSTALLATION (All)	
	4D5	9.5
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.3
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
	4G6	7.5
	4M4	16.6
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.4
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
	COMMON 4M4	16.6
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.4
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
112511 10	BALANCER SHAFT BEARING (METAL) ··· REPLACEMENT (All)	
	4D5	9.5
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.3
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
	4G6	7.5
	4M4	16.6
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.4
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
	COMMON 4M4	16.6
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.4
	[Additional operation]	
	A3 ··· Rear heater air duct – R&I	0.6
112514 00	BALANCER SHAFT SPROCKET ··· REMOVAL AND INSTALLATION (All)	
	4D5	3.0
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts – R&I	0.2
	4G6	2.3
	COMMON 4D5	3.0
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts – R&I	0.2
112514 10	BALANCER SHAFT SPROCKET ··· REPLACEMENT (All)	
	4D5	3.0
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts – R&I	0.2
	4G6	2.3

CODE	DESCRIPTION	KG0W KH0W
	COMMON 4D5	3.0
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
112515 00	BALANCER SHAFT OIL SEAL ··· REMOVAL AND INSTALLATION (All)	
	4D5	3.1
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.3
	COMMON 4D5	3.1
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
112515 10	BALANCER SHAFT OIL SEAL ··· REPLACEMENT (All)	
	4D5	3.1
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.3
	COMMON 4D5	3.1
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
112530 00	CRANKSHAFT SPROCKET B ··· REMOVAL AND INSTALLATION	
	4D5	1.9
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.2
	COMMON 4G6	2.2
112530 10	CRANKSHAFT SPROCKET B ··· REPLACEMENT	
	4D5	1.9
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.2
	COMMON 4G6	2.2
112550 00	TIMING BELT B ··· REMOVAL AND INSTALLATION	
	4D5	1.9
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.2
	COMMON 4G6	2.2
112550 10	TIMING BELT B ··· REPLACEMENT	
	4D5	1.9
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.2
	COMMON 4G6	2.2
112551 00	TIMING BELT B TENSIONER ··· REMOVAL AND INSTALLATION	
	4D5	1.9
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.1
	COMMON 4G6	2.1
112551 10	TIMING BELT B TENSIONER ··· REPLACEMENT	
	4D5	1.9
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.1
	COMMON 4G6	2.1

CODE	DESCRIPTION	KG0W KH0W
113110 00	INLET VALVE ··· REMOVAL AND INSTALLATION (All)	
	4D5	10.1
	[Additional operation]	
	A1 ··· Exhaust valve (all) − R&I	1.5
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	B9 ··· Front under floor heat protector − R&I	0.2
	4G6	5.9
	[Additional operation]	
	A1 ··· Exhaust valve (all) − R&I	1.4
	4M4	9.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.3
	[Additional operation]	
	A1 ··· Exhaust valve (all) − R&I	1.6
	6B3	12.1
	[Additional operation]	
	A1 ··· Exhaust valve (all) − R&I	2.2
	6G7	11.2
	[Additional operation]	
	A1 ··· Exhaust valve (all) − R&I	1.9
	COMMON 6B3	12.1
	[Additional operation]	
	A1 ··· Exhaust valve (all) − R&I	2.2
113110 10	INLET VALVE ··· REPLACEMENT (All)	
	4D5	10.1
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	1.5
	A2 ··· Variable geometry turbocharger related parts − R&I	0.2
	B9 ··· Front under floor heat protector − R&I	0.2
	4G6	5.9
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	1.4
	4M4	9.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.3
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	1.6
	6B3	12.1
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	2.2
	6G7	11.2
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	1.9
	COMMON 6B3	12.1
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	2.2
113110 84	INLET VALVE (RIGHT SIDE) ··· REPLACEMENT (All)	
	6B3	9.2
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	1.1
	6G7	8.6
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	1.0
	COMMON 6B3	9.2
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A1 ··· Exhaust valve (all) ··· replacement	1.1
113110 86	INLET VALVE (LEFT SIDE) ··· REPLACEMENT (All)	
	6B3	9.6
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	1.1
	6G7	8.7
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	1.0
	COMMON 6B3	9.6
	[Additional operation]	
	A1 ··· Exhaust valve (all) ··· replacement	1.1
113113 00	INLET VALVE STEM SEAL ··· REMOVAL AND INSTALLATION (All)	
	4D5	6.5
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) – R&I	1.2
	A2 ··· Variable geometry turbocharger related parts – R&I	0.3
	4G6	2.5
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) – R&I	1.2
	4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) – R&I	1.0
	6B3	4.9
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) – R&I	2.0
	6G7	5.4
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) – R&I	2.0
	COMMON 4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) – R&I	1.0
113113 10	INLET VALVE STEM SEAL ··· REPLACEMENT (All)	
	4D5	6.5
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.2
	A2 ··· Variable geometry turbocharger related parts – R&I	0.3
	4G6	2.5
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.2
	4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.0
	6B3	4.9
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	2.0
	6G7	5.4
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	2.0
	COMMON 4M4	9.0

CODE	DESCRIPTION	KG0W KH0W
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.0
113113 84	INLET VALVE STEM SEAL (RIGHT SIDE) ··· REPLACEMENT (All)	
	6B3	2.7
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.0
	6G7	3.1
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.0
	COMMON 6G7	3.1
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.0
113113 86	INLET VALVE STEM SEAL (LEFT SIDE) ··· REPLACEMENT (All)	
	6B3	3.1
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.0
	6G7	3.5
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.0
	COMMON 6G7	3.5
	[Additional operation]	
	A1 ··· Exhaust valve stem seal (all) ··· replacement	1.0
113114 00	INLET VALVE SPRING ··· REMOVAL AND INSTALLATION (All)	
	4D5	6.5
	[Additional operation]	
	A1 ··· Exhaust valve spring − R&I	1.2
	A2 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.5
	[Additional operation]	
	A1 ··· Exhaust valve spring − R&I	1.2
	4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A1 ··· Exhaust valve spring − R&I	1.0
	6B3	4.9
	[Additional operation]	
	A1 ··· Exhaust valve spring − R&I	2.0
	6G7	5.4
	[Additional operation]	
	A1 ··· Exhaust valve spring − R&I	2.0
	COMMON 4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A1 ··· Exhaust valve spring − R&I	1.0
113114 10	INLET VALVE SPRING ··· REPLACEMENT (All)	
	4D5	6.5
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	1.2
	A2 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.5
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A1 ··· Exhaust valve spring ··· replacement	1.2
	4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	1.0
	6B3	4.9
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	2.0
	6G7	5.4
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	2.0
	COMMON 4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	1.0
113114 84	INLET VALVE SPRING (RIGHT SIDE) ··· REPLACEMENT (All)	
	6B3	2.7
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	1.0
	6G7	3.1
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	1.0
	COMMON 6G7	3.1
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	1.0
113114 86	INLET VALVE SPRING (LEFT SIDE) ··· REPLACEMENT (All)	
	6B3	3.1
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	1.0
	6G7	3.5
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	1.0
	COMMON 6G7	3.5
	[Additional operation]	
	A1 ··· Exhaust valve spring ··· replacement	1.0
113150 00	EXHAUST VALVE ··· REMOVAL AND INSTALLATION (All)	
	4D5	10.1
	[Additional operation]	
	A7 ··· Variable geometry turbocharger related parts − R&I	0.3
	B1 ··· Front under floor heat protector − R&I	0.2
	4G6	5.9
	4M4	9.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.3
	6B3	12.1
	6G7	11.2
	COMMON 6B3	12.1
113150 10	EXHAUST VALVE ··· REPLACEMENT (All)	
	4D5	10.1
	[Additional operation]	
	A7 ··· Variable geometry turbocharger related parts − R&I	0.3
	B1 ··· Front under floor heat protector − R&I	0.2
	4G6	5.9

CODE	DESCRIPTION	KG0W KH0W
	4M4	9.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.3
	6B3	12.1
	6G7	11.2
	COMMON 6B3	12.1
113150 84	EXHAUST VALVE (RIGHT SIDE) ··· REPLACEMENT (All)	
	6B3	9.2
	6G7	8.6
	COMMON 6B3	9.2
113150 86	EXHAUST VALVE (LEFT SIDE) ··· REPLACEMENT (All)	
	6B3	9.6
	6G7	8.7
	COMMON 6B3	9.6
113153 00	EXHAUST VALVE STEM SEAL ··· REMOVAL AND INSTALLATION (All)	
	4D5	6.5
	[Additional operation]	
	A3 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.5
	4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	4.7
	6G7	5.4
	COMMON 4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
113153 10	EXHAUST VALVE STEM SEAL ··· REPLACEMENT (All)	
	4D5	6.5
	[Additional operation]	
	A3 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.5
	4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	4.7
	6G7	5.4
	COMMON 4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
113153 84	EXHAUST VALVE STEM SEAL (RIGHT SIDE) ··· REPLACEMENT (All)	
	6B3	2.3
	6G7	3.1
	COMMON 6G7	3.1
113153 86	EXHAUST VALVE STEM SEAL (LEFT SIDE) ··· REPLACEMENT (All)	
	6B3	3.1
	6G7	3.5
	COMMON 6G7	3.5
113154 00	EXHAUST VALVE SPRING ··· REMOVAL AND INSTALLATION (All)	
	4D5	6.5
	[Additional operation]	
	A3 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.5
	4M4	9.0
	[Additional time allowance]	

CODE	DESCRIPTION	KG0W KH0W
	E8 ··· Automatic transmission	0.2
	6B3	4.7
	6G7	5.4
	COMMON 4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
113154 10	EXHAUST VALVE SPRING ··· REPLACEMENT (All)	
	4D5	6.5
	[Additional operation]	
	A3 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.5
	4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	4.7
	6G7	5.4
	COMMON 4M4	9.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
113154 84	EXHAUST VALVE SPRING (RIGHT SIDE) ··· REPLACEMENT (All)	
	6B3	2.3
	6G7	3.1
	COMMON 6G7	3.1
113154 86	EXHAUST VALVE SPRING (LEFT SIDE) ··· REPLACEMENT (All)	
	6B3	3.1
	6G7	3.5
	COMMON 6G7	3.5
113210 00	ROCKER ARM ASSEMBLY ··· REMOVAL AND INSTALLATION (All)	
	4D5	4.6
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	1.4
	4M4	3.1
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	1.9
	6G7	2.6
	COMMON 4D5	4.6
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
113210 10	ROCKER ARM ASSEMBLY ··· REPLACEMENT (All)	
	4D5	4.6
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	1.4
	4M4	3.1
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	COMMON 4D5	4.6
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
113210 84	ROCKER ARM ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT (All)	
	6B3	1.3
	6G7	1.9
	COMMON 6G7	1.9

CODE	DESCRIPTION	KG0W KH0W
113210 86	ROCKER ARM ASSEMBLY (LEFT SIDE) ··· REPLACEMENT (All)	
	6B3	1.9
	6G7	2.6
	COMMON 6G7	2.6
113215 15	AUTO LASH ADJUSTER ··· AIR BLEED WITH RACING	0.3
113215 30	AUTO LASH ADJUSTER ··· INSPECTION (All)	1.0
113215 32	AUTO LASH ADJUSTER (RIGHT SIDE) ··· INSPECTION (All)	
	6B3	0.9
	[Additional operation]	
	A2 ··· Both side inspection	0.9
	6G7	1.7
	[Additional operation]	
	A2 ··· Both side inspection	1.0
	COMMON 6G7	1.7
	[Additional operation]	
	A2 ··· Both side inspection	1.0
113215 34	AUTO LASH ADJUSTER (LEFT SIDE) ··· INSPECTION (All)	
	6B3	1.6
	6G7	2.4
	COMMON 6G7	2.4
113215 35	AUTO LASH ADJUSTER ··· LEAK DOWN TEST	1.6
113215 37	AUTO LASH ADJUSTER (RIGHT SIDE) ··· LEAK DOWN TEST	
	6B3	1.2
	[Additional operation]	
	A2 ··· Both side test	1.1
	6G7	2.2
	[Additional operation]	
	A2 ··· Both side test	1.5
	COMMON 6G7	2.2
	[Additional operation]	
	A2 ··· Both side test	1.5
113215 38	AUTO LASH ADJUSTER (LEFT SIDE) ··· LEAK DOWN TEST	
	6B3	1.8
	6G7	2.9
	COMMON 6G7	2.9
113220 00	ROCKER SHAFT ASSEMBLY ··· REMOVAL AND INSTALLATION	1.4
	6B3	1.9
	6G7	2.6
113220 10	ROCKER SHAFT ASSEMBLY ··· REPLACEMENT	1.4
113220 84	ROCKER SHAFT ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT	
	6B3	1.3
	6G7	1.9
	COMMON 6G7	1.9
113220 86	ROCKER SHAFT ASSEMBLY (LEFT SIDE) ··· REPLACEMENT	
	6B3	1.9
	6G7	2.6
	COMMON 6G7	2.6
113310 00	CAMSHAFT ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	
	4D5	4.6
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts – R&I	0.3
	4G6	4.0
	4M4	3.1
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2

CODE	DESCRIPTION	KG0W KH0W
	6B3	8.4
	6G7	7.7
	COMMON 6B3	8.4
113310 10	CAMSHAFT ASSEMBLY ··· REPLACEMENT (One piece)	
	4D5	4.6
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	4.0
	4M4	3.1
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	COMMON 4D5	4.6
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
113310 84	CAMSHAFT ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT (One piece)	
	6B3	8.0
	6G7	7.5
	COMMON 6B3	8.0
113310 86	CAMSHAFT ASSEMBLY (LEFT SIDE) ··· REPLACEMENT (One piece)	
	6B3	8.4
	6G7	7.7
	COMMON 6B3	8.4
113340 00	CAMSHAFT OIL SEAL ··· REMOVAL AND INSTALLATION (One piece)	
	4D5	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	1.4
	6B3	3.0
	6G7	2.9
	COMMON 6B3	3.0
113340 10	CAMSHAFT OIL SEAL ··· REPLACEMENT (One piece)	
	4D5	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	1.4
	COMMON 4D5	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
113340 84	CAMSHAFT OIL SEAL (RIGHT SIDE) ··· REPLACEMENT (One piece)	
	6B3	3.0
	6G7	2.9
	COMMON 6B3	3.0
113340 86	CAMSHAFT OIL SEAL (LEFT SIDE) ··· REPLACEMENT (One piece)	
	6B3	3.0
	6G7	2.9
	COMMON 6B3	3.0
113350 00	CIRCULAR PACKING ··· REMOVAL AND INSTALLATION (All)	
	4D5	2.4
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts − R&I	0.3
	6B3	2.7
	6G7	7.2
	COMMON 6G7	7.2
113350 10	CIRCULAR PACKING ··· REPLACEMENT (All)	2.4

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts − R&I	0.3
113350 84	CIRCULAR PACKING (RIGHT SIDE) ··· REPLACEMENT (One piece)	
	6B3	2.7
	6G7	3.2
	COMMON 6G7	3.2
113350 86	CIRCULAR PACKING (LEFT SIDE) ··· REPLACEMENT (One piece)	
	6B3	2.7
	6G7	7.2
	COMMON 6G7	7.2
113410 00	TIMING BELT A ··· REMOVAL AND INSTALLATION	
	4D5	1.7
	[Additional operation]	
	A1 ··· Timing belt tensioner − R&I	0.1
	A2 ··· Auto tensioner − R&I	0.1
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.1
	[Additional operation]	
	A1 ··· Timing belt tensioner − R&I	0.1
	A2 ··· Auto tensioner − R&I	0.1
	6B3	2.8
	[Additional operation]	
	A1 ··· Timing belt tensioner − R&I	0.1
	A2 ··· Auto tensioner − R&I	0.1
	6G7	2.8
	[Additional operation]	
	A1 ··· Timing belt tensioner − R&I	0.1
	A2 ··· Auto tensioner − R&I	0.1
	COMMON 6B3	2.8
	[Additional operation]	
	A1 ··· Timing belt tensioner − R&I	0.1
	A2 ··· Auto tensioner − R&I	0.1
113410 10	TIMING BELT A ··· REPLACEMENT	
	4D5	1.7
	[Additional operation]	
	A1 ··· Timing belt tensioner ··· replacement	0.1
	A2 ··· Auto tensioner ··· replacement	0.1
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.1
	[Additional operation]	
	A1 ··· Timing belt tensioner ··· replacement	0.1
	A2 ··· Auto tensioner ··· replacement	0.1
	6B3	2.8
	[Additional operation]	
	A1 ··· Timing belt tensioner ··· replacement	0.1
	A2 ··· Auto tensioner ··· replacement	0.1
	6G7	2.8
	[Additional operation]	
	A1 ··· Timing belt tensioner ··· replacement	0.1
	A2 ··· Auto tensioner ··· replacement	0.1
	COMMON 6B3	2.8
	[Additional operation]	
	A1 ··· Timing belt tensioner ··· replacement	0.1
	A2 ··· Auto tensioner ··· replacement	0.1
113420 00	TIMING CHAIN ··· REMOVAL AND INSTALLATION	14.0

CODE	DESCRIPTION	KG0W KH0W
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
113420 10	TIMING CHAIN ··· REPLACEMENT	14.0
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.5
113510 00	TIMING BELT TENSIONER ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	1.7
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.1
	6B3	2.8
	6G7	2.8
	COMMON 6B3	2.8
113510 10	TIMING BELT TENSIONER ASSEMBLY ··· REPLACEMENT	
	4D5	1.7
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.1
	6B3	2.8
	6G7	2.8
	COMMON 6B3	2.8
113520 00	TIMING CHAIN TENSIONER ASSEMBLY ··· REMOVAL AND INSTALLATION	2.2
113520 10	TIMING CHAIN TENSIONER ASSEMBLY ··· REPLACEMENT	2.2
113530 00	AUTO TENSIONER ··· REMOVAL AND INSTALLATION	
	4D5	1.7
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.1
	6B3	2.8
	6G7	2.8
	COMMON 6B3	2.8
113530 10	AUTO TENSIONER ··· REPLACEMENT	
	4D5	1.7
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.1
	6B3	2.8
	6G7	2.8
	COMMON 6B3	2.8
113540 00	IDLER PULLEY ··· REMOVAL AND INSTALLATION	
	4D5	1.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.1
	6B3	2.8
	6G7	2.9
	COMMON 6G7	2.9
113540 10	IDLER PULLEY ··· REPLACEMENT	
	4D5	1.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	2.1
	6B3	2.8
	6G7	2.9
	COMMON 6G7	2.9

CODE	DESCRIPTION	KG0W KH0W
113610 00	CRANKSHAFT SPROCKET ··· REMOVAL AND INSTALLATION	
	4D5	1.7
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.1
	6B3	2.8
	6G7	2.9
	COMMON 6G7	2.9
113610 10	CRANKSHAFT SPROCKET ··· REPLACEMENT	
	4D5	1.7
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.1
	6B3	2.8
	6G7	2.9
	COMMON 6G7	2.9
113611 00	CRANKSHAFT GEAR ··· REMOVAL AND INSTALLATION	14.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.4
113611 10	CRANKSHAFT GEAR ··· REPLACEMENT	14.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.4
113620 00	CAMSHAFT SPROCKET ··· REMOVAL AND INSTALLATION (One piece)	
	4D5	1.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	0.9
	4M4	7.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	2.8
	6G7	2.9
	COMMON 4M4	7.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
113620 10	CAMSHAFT SPROCKET ··· REPLACEMENT (One piece)	
	4D5	1.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	4G6	0.9
	4M4	7.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	COMMON 4M4	7.6
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
113620 84	CAMSHAFT SPROCKET (RIGHT SIDE) ··· REPLACEMENT (One piece)	
	6B3	2.8
	6G7	2.9
	COMMON 6G7	2.9
113620 86	CAMSHAFT SPROCKET (LEFT SIDE) ··· REPLACEMENT (One piece)	
	6B3	2.8
	6G7	2.9
	COMMON 6G7	2.9
113630 00	INJECTION PUMP SPROCKET ··· REMOVAL AND INSTALLATION	1.8

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts − R&I	0.2
113630 10	INJECTION PUMP SPROCKET ··· REPLACEMENT	1.8
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts − R&I	0.2
113640 00	OIL PUMP SPROCKET ··· REMOVAL AND INSTALLATION	
	4G6	2.1
	COMMON 4G6	2.1
113640 10	OIL PUMP SPROCKET ··· REPLACEMENT	
	4G6	2.1
	COMMON 4G6	2.1
118601 00	OIL CONTROL VALVE ··· REMOVAL AND INSTALLATION	0.3
118601 10	OIL CONTROL VALVE ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi−use tester	0.2
121010 00	OIL PUMP ASSEMBLY ··· REMOVAL AND INSTALLATION	14.2
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.5
	4G6	4.9
	4M4	14.2
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.5
121010 10	OIL PUMP ASSEMBLY ··· REPLACEMENT	
	4G6	4.9
	4M4	14.2
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.5
	COMMON 4M4	14.2
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.5
121010 20	OIL PUMP ASSEMBLY ··· OVERHAUL	
	4G6	5.1
	4M4	14.4
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.5
	COMMON 4M4	14.4
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.5
121013 00	INNER GEAR ··· REMOVAL AND INSTALLATION	
	4D5	5.0
	[Additional time allowance]	
	B4 ··· With transfer	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	6B3	6.6
	[Additional time allowance]	
	B4 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
	6G7	8.1
	COMMON 6G7	8.1
121013 10	INNER GEAR ··· REPLACEMENT	
	4D5	5.0
	[Additional time allowance]	
	B4 ··· With transfer	1.9

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
	6B3	6.6
	[Additional time allowance]	
	B4 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
	6G7	8.1
	COMMON 6G7	8.1
121014 00	OUTER GEAR ··· REMOVAL AND INSTALLATION	
	4D5	5.0
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	6B3	6.6
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
	6G7	8.1
	COMMON 6G7	8.1
121014 10	OUTER GEAR ··· REPLACEMENT	
	4D5	5.0
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.2
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
	6B3	6.6
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
	6G7	8.1
	COMMON 6G7	8.1
121042 00	OIL PUMP CASE ··· REMOVAL AND INSTALLATION	
	6B3	6.6
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
	6G7	7.9
	COMMON 6G7	7.9
121042 10	OIL PUMP CASE ··· REPLACEMENT	
	6B3	6.6
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
	6G7	7.9
	COMMON 6G7	7.9
121043 00	OIL PUMP GASKET ··· REMOVAL AND INSTALLATION	
	6B3	6.6

CODE	DESCRIPTION	KG0W KH0W
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	6G7	7.9
	COMMON 6G7	7.9
121043 10	OIL PUMP GASKET ··· REPLACEMENT	
	6B3	6.6
	[Additional time allowance]	
	B3 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	6G7	7.9
	COMMON 6G7	7.9
121061 00	OIL SCREEN (STRAINER) ··· REMOVAL AND INSTALLATION	
	4D5	1.8
	[Additional time allowance]	
	B2 ··· With transfer	2.1
	4G6	2.2
	4M4	4.3
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.5
	6B3	3.7
	[Additional time allowance]	
	B2 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	6G7	5.3
	COMMON 6G7	5.3
121061 10	OIL SCREEN (STRAINER) ··· REPLACEMENT	
	4D5	1.8
	[Additional time allowance]	
	B2 ··· With transfer	2.1
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	4G6	2.2
	4M4	4.3
	[Additional time allowance]	
	C1 ··· Automatic transmission	0.5
	6B3	3.7
	[Additional time allowance]	
	B2 ··· With transfer	1.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	6G7	5.3
	COMMON 6G7	5.3
122010 00	OIL FILTER BRACKET ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	2.0
	4G6	1.9
	4M4	1.7
	6B3	1.2
	6G7	1.0
	COMMON 4D5	2.0
122010 10	OIL FILTER BRACKET ASSEMBLY ··· REPLACEMENT	
	4D5	2.0

CODE	DESCRIPTION	KG0W KH0W
	4G6	1.9
	4M4	1.7
	6B3	1.2
	6G7	1.0
	COMMON 4D5	2.0
122020 00	OIL FILTER ASSEMBLY ··· REMOVAL AND INSTALLATION	
	Petrol	0.4
	Diesel	0.5
	COMMON Diesel	0.5
122020 10	OIL FILTER ASSEMBLY ··· REPLACEMENT	
	Petrol	0.4
	Diesel	0.5
	COMMON Diesel	0.5
123010 00	OIL COOLER ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	1.2
	4M4	3.3
	COMMON 4M4	3.3
123010 10	OIL COOLER ASSEMBLY ··· REPLACEMENT	
	4D5	1.2
	4M4	3.3
	COMMON 4M4	3.3
123011 00	ENGINE OIL COOLER ELEMENT ··· REMOVAL AND INSTALLATION	3.3
123011 10	ENGINE OIL COOLER ELEMENT ··· REPLACEMENT	3.3
123016 00	OIL COOLER COVER GASKET ··· REMOVAL AND INSTALLATION	3.3
123016 10	OIL COOLER COVER GASKET ··· REPLACEMENT	3.3
125012 00	OIL FILLER CAP ··· REMOVAL AND INSTALLATION	0.2
125012 10	OIL FILLER CAP ··· REPLACEMENT	0.2
128201 00	OIL PRESSURE SWITCH ··· REMOVAL AND INSTALLATION	0.5
128201 10	OIL PRESSURE SWITCH ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
133110 00	INJECTOR (ECI-MULTI) ··· REMOVAL AND INSTALLATION (All)	
	4G6	1.0
	6B3	1.8
	6G7	2.2
	COMMON 6G7	2.2
133110 10	INJECTOR (ECI-MULTI) ··· REPLACEMENT (All)	
	4G6	1.0
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6B3	1.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	2.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6G7	2.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
133111 00	INSULATOR (ECI-MPI) ··· REMOVAL AND INSTALLATION (All)	2.2
133111 10	INSULATOR (ECI-MPI) ··· REPLACEMENT (All)	
	4G6	1.0
	6G7	2.2
	COMMON 6G7	2.2
133121 00	THROTTLE BODY (ECI-MULTI) ··· REMOVAL AND INSTALLATION	

CODE	DESCRIPTION	KG0W KH0W
	6B3	0.9
	6G7	0.7
	COMMON 6B3	0.9
133121 10	THROTTLE BODY (ECI-MULTI) ··· REPLACEMENT	
	4G6	0.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6B3	0.9
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6B3	0.9
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
133132 00	DELIVERY PIPE (ECI-MULTI) ··· REMOVAL AND INSTALLATION	
	6B3	1.7
	6G7	2.2
	COMMON 6G7	2.2
133132 10	DELIVERY PIPE (ECI-MULTI) ··· REPLACEMENT	
	4G6	1.0
	6B3	1.7
	6G7	2.2
	COMMON 6G7	2.2
134210 00	THROTTLE BODY ··· REMOVAL AND INSTALLATION	0.4
134210 10	THROTTLE BODY ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
134212 00	CAMSHAFT ANGLE SENSOR ··· REMOVAL AND INSTALLATION	
	4D5	0.3
	4M4	0.5
	COMMON 4M4	0.5
134212 10	CAMSHAFT ANGLE SENSOR ··· REPLACEMENT	
	4D5	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	4M4	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 4M4	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
134215 00	CRANKSHAFT POSITION SENSOR ··· REMOVAL AND INSTALLATION	
	4D5	1.0
	4M4	0.4
	COMMON 4D5	1.0
134215 10	CRANKSHAFT POSITION SENSOR ··· REPLACEMENT	
	4D5	1.0
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	4M4	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 4D5	1.0

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
134310 00	COMMON RAIL INJECTOR ··· REMOVAL AND INSTALLATION (All)	
	4D5	2.6
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts - R&I	0.3
	4M4	1.9
	COMMON 4D5	2.6
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts - R&I	0.3
134310 10	COMMON RAIL INJECTOR ··· REPLACEMENT (All)	
	4D5	2.6
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts - R&I	0.3
	A9 ··· Inspection by multi-use tester	0.2
	4M4	1.9
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 4D5	2.6
	[Additional operation]	
	A2 ··· Variable geometry turbocharger related parts - R&I	0.3
	A9 ··· Inspection by multi-use tester	0.2
134312 00	COMMON RAIL INJECTOR GASKET ··· REMOVAL AND INSTALLATION (All)	
	4D5	2.6
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts - R&I	0.3
	4M4	1.9
	COMMON 4D5	2.6
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts - R&I	0.3
134312 10	COMMON RAIL INJECTOR GASKET ··· REPLACEMENT (All)	
	4D5	2.6
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts - R&I	0.3
	4M4	1.9
	COMMON 4D5	2.6
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts - R&I	0.3
134320 00	COMMON RAIL ··· REMOVAL AND INSTALLATION	
	4D5	2.8
	4M4	1.6
	COMMON 4D5	2.8
134320 10	COMMON RAIL ··· REPLACEMENT	
	4D5	2.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	4M4	1.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 4D5	2.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
134321 00	COMMON RAIL INJECTION PIPE (PUMP SIDE) ··· REMOVAL AND INSTALLATION	
	4D5	2.7
	4M4	0.4

CODE	DESCRIPTION	KG0W KH0W
	COMMON 4D5	2.7
134321 10	COMMON RAIL INJECTION PIPE (PUMP SIDE) ··· REPLACEMENT	
	4D5	2.7
	4M4	0.4
	COMMON 4D5	2.7
134322 00	COMMON RAIL INJECTOIN PIPE (INJECTOR SIDE) ··· REMOVAL AND INSTALLATION (All)	
	4D5	2.2
	4M4	1.3
	COMMON 4D5	2.2
134322 10	COMMON RAIL INJECTOIN PIPE (INJECTOR SIDE) ··· REPLACEMENT (All)	
	4D5	2.2
	4M4	1.3
	COMMON 4D5	2.2
134330 00	COMMON RAIL SUPPLY PUMP ··· REMOVAL AND INSTALLATION	
	4D5	4.1
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts - R&I	0.3
	4M4	4.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	COMMON 4M4	4.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
134330 10	COMMON RAIL SUPPLY PUMP ··· REPLACEMENT	
	4D5	4.1
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts - R&I	0.3
	A9 ··· Inspection by multi-use tester	0.2
	4M4	4.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 4M4	4.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
134336 00	COMMON RAIL SUPPLY PUMP SUCTION CONTROL VALVE ··· REMOVAL AND INST	0.5
134336 10	COMMON RAIL SUPPLY PUMP SUCTION CONTROL VALVE ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
135031 00	FUEL PUMP MODULE ··· REMOVAL AND INSTALLATION	0.5
135031 10	FUEL PUMP MODULE ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
136010 00	FUEL TANK ASSEMBLY ··· REMOVAL AND INSTALLATION	1.1
136010 10	FUEL TANK ASSEMBLY ··· REPLACEMENT	1.1
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
136011 00	FUEL IN-TANK FILTER ··· REMOVAL AND INSTALLATION	0.5
136011 10	FUEL IN-TANK FILTER ··· REPLACEMENT	0.5
136021 00	FUEL TANK FILLER NECK HOSE ··· REMOVAL AND INSTALLATION	0.7
136021 10	FUEL TANK FILLER NECK HOSE ··· REPLACEMENT	0.7
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A9 ··· Inspection by multi-use tester	0.2
136022 00	FUEL TANK BREATHER HOSE ··· REMOVAL AND INSTALLATION	0.7
136022 10	FUEL TANK BREATHER HOSE ··· REPLACEMENT	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
136024 00	FUEL TANK CAP ··· REMOVAL AND INSTALLATION	0.2
136024 10	FUEL TANK CAP ··· REPLACEMENT	0.2
136032 00	FUEL TANK VAPOR HOSE ··· REMOVAL AND INSTALLATION	0.7
136032 10	FUEL TANK VAPOR HOSE ··· REPLACEMENT	0.7
137010 00	FUEL FILTER (STRAINER) ASSEMBLY ··· REMOVAL AND INSTALLATION	0.5
137010 10	FUEL FILTER (STRAINER) ASSEMBLY ··· REPLACEMENT	0.5
137031 00	FUEL HOSE (ENGINE) ··· REMOVAL AND INSTALLATION	
	4D5	0.5
	4M4	0.5
	6B3	0.6
	[Additional operation]	
	A1 ··· Air intake plenum assy - R&I	0.9
	6G7	0.4
	COMMON 6B3	0.6
	[Additional operation]	
	A1 ··· Air intake plenum assy - R&I	0.9
137031 10	FUEL HOSE (ENGINE) ··· REPLACEMENT	
	4D5	0.5
	4G6	0.5
	4M4	0.5
	6B3	0.6
	[Additional operation]	
	A1 ··· Air intake plenum assy - R&I	0.9
	6G7	0.4
	COMMON 6B3	0.6
	[Additional operation]	
	A1 ··· Air intake plenum assy - R&I	0.9
137042 00	FUEL HOSE (REAR FLOOR) ··· REMOVAL AND INSTALLATION	0.6
137042 10	FUEL HOSE (REAR FLOOR) ··· REPLACEMENT	0.6
137051 00	FUEL HOSE (FUEL TANK) ··· REMOVAL AND INSTALLATION	1.0
137051 10	FUEL HOSE (FUEL TANK) ··· REPLACEMENT	1.0
137076 00	FUEL COOLER ··· REMOVAL AND INSTALLATION	0.6
137076 10	FUEL COOLER ··· REPLACEMENT	0.6
138221 00	WATER LEVEL SWITCH (SENSOR) (FUEL FILTER) ··· REMOVAL AND INSTALLATIOI	0.5
138221 10	WATER LEVEL SWITCH (SENSOR) (FUEL FILTER) ··· REPLACEMENT	0.5
138301 00	FUEL TANK GAUGE UNIT ··· REMOVAL AND INSTALLATION (One piece)	0.5
138301 10	FUEL TANK GAUGE UNIT ··· REPLACEMENT (One piece)	0.5
138311 00	WATER TEMPERATURE SENSOR ··· REMOVAL AND INSTALLATION	
	4D5	0.4
	4M4	0.5
	6B3	0.5
	6G7	0.4
	COMMON 4M4	0.5
138311 10	WATER TEMPERATURE SENSOR ··· REPLACEMENT	
	4D5	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	4G6	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2

CODE	DESCRIPTION	KG0W KH0W
	4M4	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6B3	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 4M4	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138312 10	OXYGEN SENSOR ··· REPLACEMENT (One piece)	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138314 00	AIR FLOW SENSOR ··· REMOVAL AND INSTALLATION	0.3
138314 10	AIR FLOW SENSOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138315 00	INTAKE AIR TEMPERATURE SENSOR ··· REMOVAL AND INSTALLATION	0.3
138315 10	INTAKE AIR TEMPERATURE SENSOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138322 00	MANIFOLD ABSOLUTE PRESSURE SENSOR ··· REMOVAL AND INSTALLATION	0.3
138322 10	MANIFOLD ABSOLUTE PRESSURE SENSOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138351 00	OXYGEN SENSOR (BEFORE FCC) ··· REMOVAL AND INSTALLATION	0.6
138351 84	OXYGEN SENSOR (BEFORE FCC) (RIGHT SIDE) ··· REPLACEMENT	
	6B3	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6G7	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138351 86	OXYGEN SENSOR (BEFORE FCC) (LEFT SIDE) ··· REPLACEMENT	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138352 00	OXYGEN SENSOR (AFTER FCC) ··· REMOVAL AND INSTALLATION	
	6B3	1.1
	6G7	1.3
	COMMON 6G7	1.3
138352 84	OXYGEN SENSOR (AFTER FCC) (RIGHT SIDE) ··· REPLACEMENT	
	6B3	1.1
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	1.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6G7	1.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2

CODE	DESCRIPTION	KG0W KH0W
138352 86	OXYGEN SENSOR (AFTER FCC) (LEFT SIDE) ··· REPLACEMENT	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138401 00	ECI CONTROL RELAY ··· REMOVAL AND INSTALLATION	0.2
138401 10	ECI CONTROL RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138402 00	FUEL PUMP CONTROL RELAY (UNIT) ··· REMOVAL AND INSTALLATION	0.2
138402 10	FUEL PUMP CONTROL RELAY (UNIT) ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138403 00	FUEL LINE HEATER RELAY ··· REMOVAL AND INSTALLATION	0.2
138403 10	FUEL LINE HEATER RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138461 00	ENGINE CONTROL RELAY (DIESEL) ··· REMOVAL AND INSTALLATION	0.2
138461 10	ENGINE CONTROL RELAY (DIESEL) ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138501 00	ECI CONTROL UNIT ··· REMOVAL AND INSTALLATION	0.5
138501 10	ECI CONTROL UNIT ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138501 13	ECI CONTROL UNIT ··· REPROGRAMMING	0.3
	[Additional operation]	
	A2 ··· learning drive	0.2
138502 00	ENGINE CONTROL UNIT (DIESEL) ··· REMOVAL AND INSTALLATION	0.5
138502 10	ENGINE CONTROL UNIT (DIESEL) ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
138502 13	ENGINE CONTROL UNIT (DIESEL) ··· REPROGRAMMING	0.3
	[Additional operation]	
	A2 ··· learning drive	0.2
141010 00	WATER PUMP ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	2.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts - R&I	0.3
	4G6	2.7
	4M4	1.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	3.0
	6G7	3.2
	COMMON 6G7	3.2
141010 10	WATER PUMP ASSEMBLY ··· REPLACEMENT	
	4D5	2.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts - R&I	0.3
	4G6	2.7
	4M4	1.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	3.0
	6G7	3.2
	COMMON 6G7	3.2

CODE	DESCRIPTION	KG0W KH0W
141016 00	WATER PUMP GASKET ··· REMOVAL AND INSTALLATION	
	4D5	2.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.7
	4M4	1.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	3.0
	6G7	3.2
	COMMON 6G7	3.2
141016 10	WATER PUMP GASKET ··· REPLACEMENT	
	4D5	2.8
	[Additional operation]	
	A6 ··· Variable geometry turbocharger related parts − R&I	0.3
	4G6	2.7
	4M4	1.2
	[Additional time allowance]	
	E8 ··· Automatic transmission	0.2
	6B3	3.0
	6G7	3.2
	COMMON 6G7	3.2
141021 00	WATER PUMP DRIVE BELT ··· REMOVAL AND INSTALLATION	0.5
141021 10	WATER PUMP DRIVE BELT ··· REPLACEMENT	0.5
141021 40	WATER PUMP DRIVE BELT ··· ADJUSTMENT	0.2
141023 00	WATER PUMP DRIVE BELT AUTO TENSIONER ··· REMOVAL AND INSTALLATION	0.5
141023 10	WATER PUMP DRIVE BELT AUTO TENSIONER ··· REPLACEMENT	0.5
142110 00	THERMOSTAT ··· REMOVAL AND INSTALLATION	
	4D5	0.9
	4G6	0.7
	4M4	0.6
	6B3	0.8
	6G7	0.6
	COMMON 4D5	0.9
142110 10	THERMOSTAT ··· REPLACEMENT	
	4D5	0.9
	4G6	0.7
	4M4	0.6
	6B3	0.8
	6G7	0.6
	COMMON 4D5	0.9
142111 00	WATER OUTLET FITTING ··· REMOVAL AND INSTALLATION	
	4D5	4.8
	4G6	0.8
	4M4	0.7
	6B3	0.7
	6G7	0.6
	COMMON 4D5	4.8
142111 10	WATER OUTLET FITTING ··· REPLACEMENT	
	4D5	4.8
	4G6	0.8
	4M4	0.7
	6B3	0.7
	6G7	0.6
	COMMON 4D5	4.8

CODE	DESCRIPTION	KG0W KH0W
142112 00	WATER OUTLET GASKET ··· REMOVAL AND INSTALLATION	
	4D5	4.5
	4G6	0.8
	4M4	0.7
	6B3	0.7
	6G7	0.6
	COMMON 4D5	4.5
142112 10	WATER OUTLET GASKET ··· REPLACEMENT	
	4D5	4.5
	4G6	0.8
	4M4	0.7
	6B3	0.7
	6G7	0.6
	COMMON 4D5	4.5
142113 00	THERMOSTAT CASE (HOUSING) ··· REMOVAL AND INSTALLATION	
	4G6	1.7
	4M4	3.1
	6B3	1.5
	6G7	2.7
	COMMON 4M4	3.1
142113 10	THERMOSTAT CASE (HOUSING) ··· REPLACEMENT	
	4G6	1.7
	4M4	3.1
	6B3	1.5
	6G7	2.7
	COMMON 4M4	3.1
142114 00	THERMOSTAT CASE GASKET ··· REMOVAL AND INSTALLATION	
	4G6	1.7
	4M4	3.1
	6B3	1.5
	6G7	2.7
	COMMON 4M4	3.1
142114 10	THERMOSTAT CASE GASKET ··· REPLACEMENT	
	4G6	1.7
	4M4	3.1
	6B3	1.5
	6G7	2.7
	COMMON 4M4	3.1
142211 00	WATER BY-PASS PIPE ··· REMOVAL AND INSTALLATION	
	4D5	2.2
	[Additional operation]	
	A1 ··· Front under floor heat protector - R&I	0.2
	A6 ··· Exhaust manifold assy - R&I	0.4
	4G6	1.8
	4M4	2.8
	COMMON 4M4	2.8
142211 10	WATER BY-PASS PIPE ··· REPLACEMENT	
	4D5	2.2
	[Additional operation]	
	A1 ··· Front under floor heat protector - R&I	0.2
	A6 ··· Exhaust manifold assy - R&I	0.4
	4G6	1.8
	4M4	2.8
	COMMON 4M4	2.8
142212 00	WATER SUCTION (INLET) PIPE ··· REMOVAL AND INSTALLATION	

CODE	DESCRIPTION	KG0W KH0W
	4G6	1.7
	6B3	2.0
	6G7	3.1
	COMMON 6G7	3.1
142212 10	WATER SUCTION (INLET) PIPE ··· REPLACEMENT	
	4G6	1.7
	6B3	2.0
	6G7	3.1
	COMMON 6G7	3.1
142213 00	WATER OUTLET PIPE ··· REMOVAL AND INSTALLATION	
	6B3	0.9
	6G7	1.5
	COMMON 6G7	1.5
142213 10	WATER OUTLET PIPE ··· REPLACEMENT	
	6B3	0.9
	6G7	1.5
	COMMON 6G7	1.5
142231 00	WATER PASSAGE ··· REMOVAL AND INSTALLATION	
	6B3	2.8
	6G7	2.6
	COMMON 6B3	2.8
142231 10	WATER PASSAGE ··· REPLACEMENT	
	6B3	2.8
	6G7	2.6
	COMMON 6B3	2.8
144011 00	COOLING FAN ··· REMOVAL AND INSTALLATION	
	4D5	0.7
	4G6	0.7
	4M4	0.7
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.2
	6B3	0.9
	6G7	0.8
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.2
	COMMON 6B3	0.9
144011 10	COOLING FAN ··· REPLACEMENT	
	4D5	0.7
	4G6	0.7
	4M4	0.7
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.2
	6B3	0.9
	6G7	0.8
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.2
	COMMON 6B3	0.9
144012 00	FAN CLUTCH ··· REMOVAL AND INSTALLATION	
	4D5	0.7
	4M4	0.7
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.2
	6B3	0.9
	6G7	0.8
	[Additional time allowance]	

CODE	DESCRIPTION	KG0W KH0W
	D9 ··· Automatic transmission	0.2
	COMMON 6B3	0.9
144012 10	FAN CLUTCH ··· REPLACEMENT	
	4D5	0.7
	4G6	0.7
	4M4	0.7
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.2
	6B3	0.9
	6G7	0.8
	[Additional time allowance]	
	D9 ··· Automatic transmission	0.2
	COMMON 6B3	0.9
145010 00	RADIATOR ASSEMBLY ··· REMOVAL AND INSTALLATION	0.9
	[Additional time allowance]	
	B5 ··· Automatic transmission	0.2
145010 10	RADIATOR ASSEMBLY ··· REPLACEMENT	0.9
	[Additional time allowance]	
	B5 ··· Automatic transmission	0.2
145034 00	RADIATOR SHROUD ··· REMOVAL AND INSTALLATION	0.7
	[Additional time allowance]	
	B5 ··· Automatic transmission	0.2
145034 10	RADIATOR SHROUD ··· REPLACEMENT	0.7
	[Additional time allowance]	
	B5 ··· Automatic transmission	0.2
145050 00	RESERVOIR (CONDENSE) TANK ASSEMBLY ··· REMOVAL AND INSTALLATION	0.4
145050 10	RESERVOIR (CONDENSE) TANK ASSEMBLY ··· REPLACEMENT	0.4
146021 00	RADIATOR HOSE (UPPER) ··· REMOVAL AND INSTALLATION (All)	0.6
146021 10	RADIATOR HOSE (UPPER) ··· REPLACEMENT (All)	0.6
146022 00	RADIATOR HOSE (LOWER) ··· REMOVAL AND INSTALLATION (All)	0.7
146022 10	RADIATOR HOSE (LOWER) ··· REPLACEMENT (All)	0.7
146023 00	RUBBER HOSE (RADIATOR TO TANK) ··· REMOVAL AND INSTALLATION (All)	0.3
146023 10	RUBBER HOSE (RADIATOR TO TANK) ··· REPLACEMENT (All)	0.3
148301 00	WATER TEMPERATURE GAUGE UNIT ··· REMOVAL AND INSTALLATION	
	4G6	0.5
	4M4	0.5
	6B3	0.5
	OTHERS	0.4
148301 10	WATER TEMPERATURE GAUGE UNIT ··· REPLACEMENT	
	4G6	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	4M4	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6B3	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	OTHERS	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
151110 00	INTAKE MANIFOLD ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	1.4
	4G6	2.0
	4M4	2.4

CODE	DESCRIPTION	KG0W KH0W
	6B3	1.9
	6G7	2.5
	COMMON 6G7	2.5
151110 10	INTAKE MANIFOLD ASSEMBLY ··· REPLACEMENT	
	4D5	1.4
	4G6	2.0
	4M4	2.4
	6B3	1.9
	6G7	2.5
	COMMON 6G7	2.5
151112 00	INTAKE MANIFOLD UPPER ··· REMOVAL AND INSTALLATION	1.9
151112 10	INTAKE MANIFOLD UPPER ··· REPLACEMENT	1.9
151120 00	INTAKE MANIFOLD GASKET ··· REMOVAL AND INSTALLATION	
	4D5	1.4
	4G6	2.0
	4M4	2.4
	6B3	1.9
	6G7	2.5
	COMMON 6G7	2.5
151120 10	INTAKE MANIFOLD GASKET ··· REPLACEMENT	
	4D5	1.4
	4G6	2.0
	4M4	2.4
	6B3	1.9
	6G7	2.5
	COMMON 6G7	2.5
151121 00	INTAKE MANIFOLD UPPER GASKET ··· REMOVAL AND INSTALLATION	1.9
151121 10	INTAKE MANIFOLD UPPER GASKET ··· REPLACEMENT	1.9
151161 00	AIR INTAKE FITTING ··· REMOVAL AND INSTALLATION	1.4
151161 10	AIR INTAKE FITTING ··· REPLACEMENT	1.4
151162 00	AIR INTAKE FITTING GASKET ··· REMOVAL AND INSTALLATION	1.4
151162 10	AIR INTAKE FITTING GASKET ··· REPLACEMENT	1.4
151210 00	AIR CLEANER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.4
151210 10	AIR CLEANER ASSEMBLY ··· REPLACEMENT	0.4
151211 00	AIR CLEANER ELEMENT ··· REMOVAL AND INSTALLATION	0.2
151211 10	AIR CLEANER ELEMENT ··· REPLACEMENT	0.2
151310 00	AIR INTAKE PLENUM ASSEMBLY ··· REMOVAL AND INSTALLATION	1.5
151310 10	AIR INTAKE PLENUM ASSEMBLY ··· REPLACEMENT	1.5
151311 00	AIR INTAKE PLENUM GASKET ··· REMOVAL AND INSTALLATION	1.5
151311 10	AIR INTAKE PLENUM GASKET ··· REPLACEMENT	1.5
151410 00	INTERCOOLER ASSEMBLY ··· REMOVAL AND INSTALLATION	1.2
151410 10	INTERCOOLER ASSEMBLY ··· REPLACEMENT	1.2
151523 00	INTAKE HOSE (TURBO TO INTER COOLER) ··· REMOVAL AND INSTALLATION	0.4
151523 10	INTAKE HOSE (TURBO TO INTER COOLER) ··· REPLACEMENT	0.4
151526 00	INTAKE HOSE (INTER COOLER TO THROTTLE BODY) ··· REMOVAL AND INSTALLA	0.4
	[Additional operation]	
	A1 ··· Front bumper assy – R&I	0.8
151526 10	INTAKE HOSE (INTER COOLER TO THROTTLE BODY) ··· REPLACEMENT	0.4
	[Additional operation]	
	A1 ··· Front bumper assy – R&I	0.8
153110 00	EXHAUST MANIFOLD ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	2.1
	[Additional operation]	
	A4 ··· Front under floor heat protector – R&I	0.2
	4G6	0.9

CODE	DESCRIPTION	KG0W KH0W
	4M4	2.6
	6B3	2.0
	6G7	2.1
	COMMON 4M4	2.6
153110 10	EXHAUST MANIFOLD ASSEMBLY ··· REPLACEMENT	
	4D5	2.1
	[Additional operation]	
	A4 ··· Front under floor heat protector – R&I	0.2
	4G6	0.9
	4M4	2.6
	COMMON 4M4	2.6
153110 84	EXHAUST MANIFOLD ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT	
	6B3	1.3
	6G7	1.7
	COMMON 6G7	1.7
153110 86	EXHAUST MANIFOLD ASSEMBLY (LEFT SIDE) ··· REPLACEMENT	
	6B3	2.0
	6G7	2.1
	COMMON 6G7	2.1
153120 00	EXHAUST MANIFOLD GASKET ··· REMOVAL AND INSTALLATION	
	4D5	2.1
	[Additional operation]	
	A4 ··· Front under floor heat protector – R&I	0.2
	4G6	0.9
	4M4	2.6
	6B3	2.0
	6G7	2.1
	COMMON 4M4	2.6
153120 10	EXHAUST MANIFOLD GASKET ··· REPLACEMENT	
	4D5	2.1
	[Additional operation]	
	A4 ··· Front under floor heat protector – R&I	0.2
	4G6	0.9
	4M4	2.6
	COMMON 4M4	2.6
153120 84	EXHAUST MANIFOLD GASKET (RIGHT SIDE) ··· REPLACEMENT	
	6B3	1.3
	6G7	1.7
	COMMON 6G7	1.7
153120 86	EXHAUST MANIFOLD GASKET (LEFT SIDE) ··· REPLACEMENT	
	6B3	2.0
	6G7	2.1
	COMMON 6G7	2.1
153210 00	FRONT EXHAUST PIPE ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	0.6
	4G6	0.6
	4M4	0.6
	6B3	1.5
	6G7	1.8
	COMMON 6G7	1.8
153210 10	FRONT EXHAUST PIPE ASSEMBLY ··· REPLACEMENT	
	4D5	0.6
	4G6	0.6
	4M4	0.6
	6B3	1.5

CODE	DESCRIPTION	KG0W KH0W
	6G7	1.8
	COMMON 6G7	1.8
153211 00	FRONT EXHAUST PIPE GASKET ··· REMOVAL AND INSTALLATION	
	4D5	0.6
	4G6	0.6
	4M4	0.6
	6B3	1.5
	6G7	1.8
	COMMON 6G7	1.8
153211 10	FRONT EXHAUST PIPE GASKET ··· REPLACEMENT	
	4D5	0.6
	4G6	0.6
	4M4	0.6
	6B3	1.5
	6G7	1.8
	COMMON 6G7	1.8
153310 00	CENTER EXHAUST PIPE ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	0.6
	4G6	0.6
	4M4	0.6
	6B3	0.8
	6G7	0.8
	COMMON 6B3	0.8
153310 10	CENTER EXHAUST PIPE ASSEMBLY ··· REPLACEMENT	
	4D5	0.6
	4G6	0.6
	4M4	0.6
	6B3	0.8
	6G7	0.8
	COMMON 6B3	0.8
153311 00	CENTER EXHAUST PIPE GASKET ··· REMOVAL AND INSTALLATION	
	4D5	0.6
	4G6	0.6
	4M4	0.6
	6B3	0.8
	6G7	0.8
	COMMON 6B3	0.8
153311 10	CENTER EXHAUST PIPE GASKET ··· REPLACEMENT	
	4D5	0.6
	4G6	0.6
	4M4	0.6
	6B3	0.8
	6G7	0.8
	COMMON 6B3	0.8
153510 00	MAIN MUFFLER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.6
153510 10	MAIN MUFFLER ASSEMBLY ··· REPLACEMENT	0.6
153710 00	CATALYTIC CONVERTER ASSEMBLY (FRONT) ··· REMOVAL AND INSTALLATION	
	4D5	0.8
	[Additional operation]	
	A1 ··· Front under floor heat protector – R&I	0.2
	4M4	1.2
	COMMON 4M4	1.2
153710 10	CATALYTIC CONVERTER ASSEMBLY (FRONT) ··· REPLACEMENT	
	4D5	0.8
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A1 ··· Front under floor heat protector – R&I	0.2
	A9 ··· Inspection by multi-use tester	0.2
	4M4	1.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 4M4	1.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
155010 00	TURBOCHARGER ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	1.9
	[Additional operation]	
	A2 ··· Front under floor heat protector – R&I	0.2
	4M4	2.3
	COMMON 4M4	2.3
155010 10	TURBOCHARGER ASSEMBLY ··· REPLACEMENT	
	4D5	1.9
	[Additional operation]	
	A2 ··· Front under floor heat protector – R&I	0.2
	4M4	2.3
	COMMON 4M4	2.3
155011 00	TURBOCHARGER WASTE GATE ACTUATOR ··· REMOVAL AND INSTALLATION	0.5
155011 10	TURBOCHARGER WASTE GATE ACTUATOR ··· REPLACEMENT	0.5
155051 00	TURBO OIL FEED PIPE ··· REMOVAL AND INSTALLATION	
	4D5	0.4
	4M4	1.7
	COMMON 4M4	1.7
155051 10	TURBO OIL FEED PIPE ··· REPLACEMENT	
	4D5	0.4
	4M4	1.7
	COMMON 4M4	1.7
155052 00	TURBO OIL RETURN PIPE ··· REMOVAL AND INSTALLATION	0.6
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts – R&I	1.1
	A2 ··· Front under floor heat protector – R&I	0.2
155052 10	TURBO OIL RETURN PIPE ··· REPLACEMENT	0.6
	[Additional operation]	
	A1 ··· Variable geometry turbocharger related parts – R&I	1.1
	A2 ··· Front under floor heat protector – R&I	0.2
155053 00	TURBO OIL RETURN HOSE ··· REMOVAL AND INSTALLATION	0.5
155053 10	TURBO OIL RETURN HOSE ··· REPLACEMENT	0.5
158602 00	VARIABLE AIR CONTROL SOLENOID VALVE ··· REMOVAL AND INSTALLATION	0.4
158602 10	VARIABLE AIR CONTROL SOLENOID VALVE ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
158604 00	VGT SOLENOID VALVE ··· REMOVAL AND INSTALLATION	0.3
158604 10	VGT SOLENOID VALVE ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
161110 00	ALTERNATOR ASSEMBLY ··· REMOVAL AND INSTALLATION	
	6B3	0.7
	6G7	0.6
	OTHERS	0.9
161110 10	ALTERNATOR ASSEMBLY ··· REPLACEMENT	
	4G6	0.7
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A9 ··· Inspection by multi-use tester	0.2
	6B3	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	OTHERS	0.9
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
161110 20	ALTERNATOR ASSEMBLY ··· OVERHAUL	
	4G6	1.7
	6B3	1.7
	6G7	1.6
	OTHERS	1.9
161121 00	ALTERNATOR IC REGULATOR ··· REMOVAL AND INSTALLATION	
	6B3	1.3
	6G7	1.2
	OTHERS	1.5
161121 10	ALTERNATOR IC REGULATOR ··· REPLACEMENT	
	4G6	1.3
	6B3	1.3
	6G7	1.2
	OTHERS	1.5
161122 00	ALTERNATOR BRUSH HOLDER ASSEMBLY ··· REMOVAL AND INSTALLATION	
	6B3	1.1
	6G7	1.0
	OTHERS	1.3
161122 10	ALTERNATOR BRUSH HOLDER ASSEMBLY ··· REPLACEMENT	
	4G6	1.1
	6B3	1.1
	6G7	1.0
	OTHERS	1.3
161125 00	ALTERNATOR RECTIFIER ··· REMOVAL AND INSTALLATION	
	6B3	1.1
	6G7	1.0
	OTHERS	1.3
161125 10	ALTERNATOR RECTIFIER ··· REPLACEMENT	
	4G6	1.1
	6B3	1.1
	6G7	1.0
	OTHERS	1.3
161161 00	ALTERNATOR DRIVE BELT ··· REMOVAL AND INSTALLATION	0.4
161161 10	ALTERNATOR DRIVE BELT ··· REPLACEMENT	0.4
161172 00	ALTERNATOR DRIVE BELT IDLER PULLEY ··· REMOVAL AND INSTALLATION	0.4
161172 10	ALTERNATOR DRIVE BELT IDLER PULLEY ··· REPLACEMENT	0.4
161175 00	ALTERNATOR DRIVE BELT AUTO TENSIONER ··· REMOVAL AND INSTALLATION	0.4
161175 10	ALTERNATOR DRIVE BELT AUTO TENSIONER ··· REPLACEMENT	0.4
162110 00	STARTER ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	0.6
	4G6	0.5
	4M4	0.6
	6B3	0.5
	6G7	1.3
	COMMON 6G7	1.3

CODE	DESCRIPTION	KG0W KH0W
162110 10	STARTER ASSEMBLY ··· REPLACEMENT	
	4D5	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	4G6	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	4M4	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6B3	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	1.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6G7	1.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
162110 20	STARTER ASSEMBLY ··· OVERHAUL	
	4D5	1.6
	4G6	1.5
	4M4	1.6
	6B3	1.5
	6G7	2.3
	COMMON 6G7	2.3
162112 00	STARTER SWITCH ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	0.9
	4M4	0.9
	6B3	0.8
	6G7	1.6
	COMMON 6G7	1.6
162112 10	STARTER SWITCH ASSEMBLY ··· REPLACEMENT	
	4D5	0.9
	4G6	0.8
	4M4	0.9
	6B3	0.8
	6G7	1.6
	COMMON 6G7	1.6
162121 00	STARTER BRUSH HOLDER ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	1.1
	4M4	1.1
	6B3	1.0
	6G7	1.8
	COMMON 6G7	1.8
162121 10	STARTER BRUSH HOLDER ASSEMBLY ··· REPLACEMENT	
	4D5	1.1
	4G6	1.0
	4M4	1.1
	6B3	1.0
	6G7	1.8
	COMMON 6G7	1.8
162124 00	STARTER OVERRUNNING CLUTCH ··· REMOVAL AND INSTALLATION	
	4D5	1.1
	4M4	1.1

CODE	DESCRIPTION	KG0W KH0W
	6B3	1.0
	6G7	1.8
	COMMON 6G7	1.8
162124 10	STARTER OVERRUNNING CLUTCH ··· REPLACEMENT	
	4D5	1.1
	4G6	1.0
	4M4	1.1
	6B3	1.0
	6G7	1.8
	COMMON 6G7	1.8
162210 00	GLOW PLUG ··· REMOVAL AND INSTALLATION (One piece)	0.7
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
162210 10	GLOW PLUG ··· REPLACEMENT (One piece)	0.7
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
163110 00	IGNITION COIL ASSEMBLY ··· REMOVAL AND INSTALLATION	0.5
	6B3	1.3
	6G7	2.0
163110 10	IGNITION COIL ASSEMBLY ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
163110 84	IGNITION COIL ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT	
	6B3	0.4
	[Additional operation]	
	A1 ··· Both side replace	1.0
	A9 ··· Inspection by multi-use tester	0.2
	6G7	1.2
	[Additional operation]	
	A1 ··· Both side replace	0.8
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6G7	1.2
	[Additional operation]	
	A1 ··· Both side replace	0.8
	A9 ··· Inspection by multi-use tester	0.2
163110 86	IGNITION COIL ASSEMBLY (LEFT SIDE) ··· REPLACEMENT	
	6B3	1.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	2.0
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6G7	2.0
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
163510 00	SPARK PLUG ASSEMBLY ··· REMOVAL AND INSTALLATION (All)	0.6
	6B3	1.3
	6G7	2.0
163510 10	SPARK PLUG ASSEMBLY ··· REPLACEMENT (All)	0.6
163510 55	SPARK PLUG ASSEMBLY ··· CLEANING (All)	0.7
163510 57	SPARK PLUG ASSEMBLY ··· CLEANING WITH RACING	0.3
163510 84	SPARK PLUG ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT (All)	
	6B3	0.5
	[Additional operation]	
	A1 ··· Both side replace	1.0

CODE	DESCRIPTION	KG0W KH0W
	6G7	1.3
	[Additional operation]	
	A1 ··· Both side replace	0.9
	COMMON 6G7	1.3
	[Additional operation]	
	A1 ··· Both side replace	0.9
163510 85	SPARK PLUG ASSEMBLY (RIGHT SIDE) ··· CLEANING (All)	
	6B3	0.5
	[Additional operation]	
	A1 ··· Both side cleaning	1.0
	6G7	1.4
	[Additional operation]	
	A1 ··· Both side cleaning	0.9
	COMMON 6G7	1.4
	[Additional operation]	
	A1 ··· Both side cleaning	0.9
163510 86	SPARK PLUG ASSEMBLY (LEFT SIDE) ··· REPLACEMENT (All)	
	6B3	1.3
	6G7	2.0
	COMMON 6G7	2.0
163510 87	SPARK PLUG ASSEMBLY (LEFT SIDE) ··· CLEANING (All)	
	6B3	1.4
	6G7	2.1
	COMMON 6G7	2.1
168301 00	KNOCK SENSOR ··· REMOVAL AND INSTALLATION	
	4G6	0.7
	6B3	2.0
	6G7	2.5
	COMMON 6G7	2.5
168301 10	KNOCK SENSOR ··· REPLACEMENT	
	4G6	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6B3	2.0
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	2.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6G7	2.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
168321 00	CRANKSHAFT ANGLE SENSOR ··· REMOVAL AND INSTALLATION	
	4G6	2.1
	6B3	0.4
	6G7	2.5
	COMMON 6G7	2.5
168321 10	CRANKSHAFT ANGLE SENSOR ··· REPLACEMENT	
	4G6	2.1
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6B3	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	2.5

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6G7	2.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
168322 00	CAMSHAFT ANGLE SENSOR ··· REMOVAL AND INSTALLATION	
	4G6	0.2
	6B3	0.3
	6G7	0.7
	COMMON 6G7	0.7
168322 10	CAMSHAFT ANGLE SENSOR ··· REPLACEMENT	
	4G6	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6B3	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 6G7	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
168401 00	STARTER RELAY ··· REMOVAL AND INSTALLATION	0.2
168401 10	STARTER RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
168431 00	GLOW PLUG RELAY ··· REMOVAL AND INSTALLATION (One piece)	0.4
168431 10	GLOW PLUG RELAY ··· REPLACEMENT (One piece)	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
171111 00	ACCELERATOR PEDAL ··· REMOVAL AND INSTALLATION	0.4
171111 10	ACCELERATOR PEDAL ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
173310 00	EGR VALVE ··· REMOVAL AND INSTALLATION	
	4D5	0.4
	4G6	0.4
	4M4	0.5
	6G7	0.3
	COMMON 4M4	0.5
173310 10	EGR VALVE ··· REPLACEMENT	
	4D5	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	4G6	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	4M4	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	6G7	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	COMMON 4M4	0.5

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
173311 00	EGR VALVE GASKET ··· REMOVAL AND INSTALLATION	
	4D5	0.4
	4G6	0.4
	4M4	0.5
	6G7	0.3
	COMMON 4M4	0.5
173311 10	EGR VALVE GASKET ··· REPLACEMENT	
	4D5	0.4
	4G6	0.4
	4M4	0.5
	6G7	0.3
	COMMON 4M4	0.5
173312 00	EGR PIPE ··· REMOVAL AND INSTALLATION	0.6
173312 10	EGR PIPE ··· REPLACEMENT	0.6
173313 00	EGR COOLER ··· REMOVAL AND INSTALLATION	
	4D5	1.3
	[Additional operation]	
	A2 ··· Starter assembly - R&I	0.4
	4M4	1.0
	COMMON 4D5	1.3
	[Additional operation]	
	A2 ··· Starter assembly - R&I	0.4
173313 10	EGR COOLER ··· REPLACEMENT	
	4D5	1.3
	[Additional operation]	
	A2 ··· Starter assembly - R&I	0.4
	4M4	1.0
	COMMON 4D5	1.3
	[Additional operation]	
	A2 ··· Starter assembly - R&I	0.4
173610 00	POSITIVE CRANKCASE VENTILATION VALVE ··· REMOVAL AND INSTALLATION	0.2
	4G6	0.4
	OTHERS	0.2
173610 10	POSITIVE CRANKCASE VENTILATION VALVE ··· REPLACEMENT	
	4G6	0.4
	OTHERS	0.2
173620 00	PCV HOSE ··· REMOVAL AND INSTALLATION	0.2
	4G6	0.4
	OTHERS	0.2
173620 10	PCV HOSE ··· REPLACEMENT	
	4G6	0.4
	OTHERS	0.2
173630 00	BREATHER HOSE ··· REMOVAL AND INSTALLATION	
	4G6	0.2
	6B3	0.7
	6G7	0.3
	COMMON 6B3	0.7
173630 10	BREATHER HOSE ··· REPLACEMENT	
	4G6	0.2
	6B3	0.7
	6G7	0.3
	COMMON 6B3	0.7
173641 00	BLOW-BY GAS HEATER ··· REMOVAL AND INSTALLATION	0.3

CODE	DESCRIPTION	KG0W KH0W
173641 10	BLOW-BY GAS HEATER ··· REPLACEMENT	0.3
178202 00	CLUTCH PEDAL SWITCH (AUTO CRUISE) ··· REMOVAL AND INSTALLATION	0.3
	[Additional time allowance]	
	L9 ··· Left-hand drive	0.2
178202 10	CLUTCH PEDAL SWITCH (AUTO CRUISE) ··· REPLACEMENT	0.3
	[Additional time allowance]	
	L9 ··· Left-hand drive	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
178203 00	AUTO CRUISE SWITCH ··· REMOVAL AND INSTALLATION	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
178203 10	AUTO CRUISE SWITCH ··· REPLACEMENT	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
178451 00	THROTTLE CONTROL SERVO RELAY ··· REMOVAL AND INSTALLATION	0.2
178451 10	THROTTLE CONTROL SERVO RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
178455 00	BLOW-BY HEATER RELAY ··· REMOVAL AND INSTALLATION	0.2
178455 10	BLOW-BY HEATER RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
178605 00	EGR SOLENOID VALVE ··· REMOVAL AND INSTALLATION	0.4
178605 10	EGR SOLENOID VALVE ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
178635 00	PURGE CONTROL VALVE ··· REMOVAL AND INSTALLATION	0.3
178635 10	PURGE CONTROL VALVE ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
211110 00	CLUTCH DISC ··· REMOVAL AND INSTALLATION	
	4D5	2.5
	[Additional time allowance]	
	C3 ··· With transfer	2.0
	[Additional operation]	
	B3 ··· Rear heater air duct - R&I	0.6
	4G6	2.2
	4M4	4.9
	[Additional operation]	
	B3 ··· Rear heater air duct - R&I	0.6
	6G7	5.5
	[Additional operation]	
	B3 ··· Rear heater air duct - R&I	0.6
	COMMON 6G7	5.5
	[Additional operation]	
	B3 ··· Rear heater air duct - R&I	0.6
211110 10	CLUTCH DISC ··· REPLACEMENT	
	4D5	2.5
	[Additional time allowance]	
	C3 ··· With transfer	2.0
	[Additional operation]	
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3

CODE	DESCRIPTION	KG0W KH0W
	B3 ··· Rear heater air duct – R&I	0.6
	4G6	2.2
	[Additional operation]	
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3
	4M4	4.9
	[Additional operation]	
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3
	B3 ··· Rear heater air duct – R&I	0.6
	6G7	5.5
	[Additional operation]	
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3
	B3 ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.5
	[Additional operation]	
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3
	B3 ··· Rear heater air duct – R&I	0.6
211120 00	CLUTCH COVER ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	2.5
	[Additional time allowance]	
	C3 ··· With transfer	2.0
	[Additional operation]	
	B3 ··· Rear heater air duct – R&I	0.6
	4G6	2.2
	4M4	4.9
	[Additional operation]	
	B3 ··· Rear heater air duct – R&I	0.6
	6G7	5.5
	[Additional operation]	
	B3 ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.5
	[Additional operation]	
	B3 ··· Rear heater air duct – R&I	0.6
211120 10	CLUTCH COVER ASSEMBLY ··· REPLACEMENT	
	4D5	2.5
	[Additional time allowance]	
	C3 ··· With transfer	2.0
	[Additional operation]	
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3
	B3 ··· Rear heater air duct – R&I	0.6
	4G6	2.2
	[Additional operation]	
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3
	4M4	4.9
	[Additional operation]	
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3
	B3 ··· Rear heater air duct – R&I	0.6
	6G7	5.5
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3
	B3 ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.5
	[Additional operation]	
	A1 ··· Release bearing ··· replacement	0.1
	A2 ··· Flywheel ··· replacement	0.3
	B3 ··· Rear heater air duct – R&I	0.6
212011 00	CLUTCH PEDAL ··· REMOVAL AND INSTALLATION	0.7
212011 10	CLUTCH PEDAL ··· REPLACEMENT	0.7
212011 40	CLUTCH PEDAL ··· ADJUSTMENT	0.2
212030 00	CLUTCH MASTER CYLINDER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.8
	[Additional time allowance]	
	L9 ··· Left-hand drive	0.3
212030 10	CLUTCH MASTER CYLINDER ASSEMBLY ··· REPLACEMENT	0.8
	[Additional time allowance]	
	L9 ··· Left-hand drive	0.3
212030 20	CLUTCH MASTER CYLINDER ASSEMBLY ··· OVERHAUL	1.1
	[Additional time allowance]	
	L9 ··· Left-hand drive	0.3
212050 00	CLUTCH RELEASE CYLINDER ASSEMBLY ··· REMOVAL AND INSTALLATION	1.0
212050 10	CLUTCH RELEASE CYLINDER ASSEMBLY ··· REPLACEMENT	1.0
212050 20	CLUTCH RELEASE CYLINDER ASSEMBLY ··· OVERHAUL	1.2
212071 00	CLUTCH RELEASE BEARING ··· REMOVAL AND INSTALLATION	
	4D5	2.5
	[Additional time allowance]	
	C3 ··· With transfer	2.0
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	4G6	2.2
	4M4	4.9
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	6G7	5.5
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.5
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
212071 10	CLUTCH RELEASE BEARING ··· REPLACEMENT	
	4D5	2.5
	[Additional time allowance]	
	C3 ··· With transfer	2.0
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	4G6	2.2
	4M4	4.9
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	6G7	5.5
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.5
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6

CODE	DESCRIPTION	KG0W KH0W
212074 00	CLUTCH RELEASE FORK (ROCKER ARM) ··· REMOVAL AND INSTALLATION	
	4D5	2.5
	[Additional time allowance]	
	C3 ··· With transfer	2.0
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	4G6	2.2
	4M4	4.9
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	6G7	5.5
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.5
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
212074 10	CLUTCH RELEASE FORK (ROCKER ARM) ··· REPLACEMENT	
	4D5	2.5
	[Additional time allowance]	
	C3 ··· With transfer	2.0
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	4G6	2.2
	4M4	4.9
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	6G7	5.5
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
	COMMON 6G7	5.5
	[Additional operation]	
	B1 ··· Rear heater air duct – R&I	0.6
212081 00	CLUTCH HOSE ··· REMOVAL AND INSTALLATION	1.1
212081 10	CLUTCH HOSE ··· REPLACEMENT	1.1
212083 00	CLUTCH DAMPER ··· REMOVAL AND INSTALLATION	1.3
212083 10	CLUTCH DAMPER ··· REPLACEMENT	1.3
221110 00	T/M SHIFT LEVER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.6
	[Additional time allowance]	
	C3 ··· With transfer	1.0
221110 10	T/M SHIFT LEVER ASSEMBLY ··· REPLACEMENT	0.6
	[Additional time allowance]	
	C3 ··· With transfer	1.0
221112 00	T/M SHIFT LEVER KNOB ··· REMOVAL AND INSTALLATION	0.2
221112 10	T/M SHIFT LEVER KNOB ··· REPLACEMENT	0.2
221115 00	T/M SHIFT LEVER BOOT (COVER) ··· REMOVAL AND INSTALLATION	0.6
221115 10	T/M SHIFT LEVER BOOT (COVER) ··· REPLACEMENT	0.6
221211 00	T/F CONTROL LEVER ··· REMOVAL AND INSTALLATION	0.7
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
221211 10	T/F CONTROL LEVER ··· REPLACEMENT	0.7
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
221212 00	T/F CONTROL LEVER KNOB ··· REMOVAL AND INSTALLATION	0.2
221212 10	T/F CONTROL LEVER KNOB ··· REPLACEMENT	0.2
222010 00	T/M ASSEMBLY ··· REMOVAL AND INSTALLATION	2.0

CODE	DESCRIPTION	KG0W KH0W
	[Additional time allowance]	
	C3 ··· With transfer	2.4
	C7 ··· 6G7	1.3
	G4 ··· 4M4	0.8
	L7 ··· 4D5	0.3
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover – R&I	0.2
	A2 ··· Flywheel – R&I	0.3
222010 10	T/M ASSEMBLY ··· REPLACEMENT	2.0
	[Additional time allowance]	
	C3 ··· With transfer	2.4
	C7 ··· 6G7	1.3
	G4 ··· 4M4	0.8
	L7 ··· 4D5	0.3
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
222010 20	T/M ASSEMBLY ··· OVERHAUL	
	R5MB	5.8
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	R5M2	5.1
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	V5MB	8.3
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	COMMON V5MB	8.3
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
222010 9A	T/M ASSEMBLY ··· GROUP WORK (A)	
	R5MB	2.7
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	R5M2	2.7
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	V5MB	5.2
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2

CODE	DESCRIPTION	KG0W KH0W
	A2 ··· Flywheel ··· replacement	0.3
	COMMON V5MB	5.2
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
222010 9B	T/M ASSEMBLY ··· GROUP WORK (B)	
	R5MB	3.2
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	R5M2	2.9
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	V5MB	5.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	COMMON V5MB	5.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
222010 9C	T/M ASSEMBLY ··· GROUP WORK (C)	
	R5MB	3.6
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	R5M2	4.4
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	V5MB	6.1
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	COMMON V5MB	6.1
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
222010 9D	T/M ASSEMBLY ··· GROUP WORK (D)	

CODE	DESCRIPTION	KG0W KH0W
	R5MB	4.3
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	R5M2	4.3
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	V5MB	6.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	COMMON V5MB	6.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
222010 9E	T/M ASSEMBLY ··· GROUP WORK (E)	
	R5MB	4.3
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	R5M2	4.6
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	V5MB	6.8
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	COMMON V5MB	6.8
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
222010 9F	T/M ASSEMBLY ··· GROUP WORK (F)	
	R5MB	5.0
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	V5MB	7.5
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	COMMON V5MB	7.5
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
222260 00	POPPET & INTERLOCK PLUNGER GENERAL ··· REMOVAL AND INSTALLATION	0.9
222260 90	POPPET BALL, SPRING AND PLUG ··· REPLACEMENT (All)	0.9
225010 00	T/F ASSEMBLY ··· REMOVAL AND INSTALLATION	4.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
225010 10	T/F ASSEMBLY ··· REPLACEMENT	4.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
225010 20	T/F ASSEMBLY ··· OVERHAUL	7.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
225010 9A	T/F ASSEMBLY ··· GROUP WORK (A)	5.2
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
225010 9B	T/F ASSEMBLY ··· GROUP WORK (B)	5.3
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
225010 9C	T/F ASSEMBLY ··· GROUP WORK (C)	6.6
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
225010 9D	T/F ASSEMBLY ··· GROUP WORK (D)	5.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
225113 00	T/F CASE OUTPUT SHAFT OIL SEAL ··· REMOVAL AND INSTALLATION	0.6
225113 10	T/F CASE OUTPUT SHAFT OIL SEAL ··· REPLACEMENT	0.6
225144 00	T/F EXTENSION HOUSING ··· REMOVAL AND INSTALLATION	1.3
225144 10	T/F EXTENSION HOUSING ··· REPLACEMENT	1.3
225145 00	T/F EXTENSION HOUSING OIL SEAL ··· REMOVAL AND INSTALLATION	0.7
225145 10	T/F EXTENSION HOUSING OIL SEAL ··· REPLACEMENT	0.7
225146 00	T/F EXTENSION HOUSING GASKET ··· REMOVAL AND INSTALLATION	1.3
225146 10	T/F EXTENSION HOUSING GASKET ··· REPLACEMENT	1.3
225164 00	T/F SIDE COVER GASKET ··· REMOVAL AND INSTALLATION	0.4
225164 10	T/F SIDE COVER GASKET ··· REPLACEMENT	0.4
225260 00	T/F POPPET & INTERLOCK PLUNGER GENERAL ··· REMOVAL AND INSTALLATION	0.9
225260 90	POPPET INTERLOCK PLUNGER ··· REPLACEMENT	0.9
225911 00	SPEEDOMETER DRIVEN GEAR SLEEVE ··· REMOVAL AND INSTALLATION	0.4
225911 10	SPEEDOMETER DRIVEN GEAR SLEEVE ··· REPLACEMENT	0.4
225913 00	SPEEDOMETER DRIVEN GEAR ··· REMOVAL AND INSTALLATION	0.4
225913 10	SPEEDOMETER DRIVEN GEAR ··· REPLACEMENT	0.4

CODE	DESCRIPTION	KG0W KH0W
228201 00	BACK-UP LAMP SWITCH ··· REMOVAL AND INSTALLATION	0.4
228201 10	BACK-UP LAMP SWITCH ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
228203 00	SHIFT POSITION SWITCH ··· REMOVAL AND INSTALLATION	0.4
228203 10	SHIFT POSITION SWITCH ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
228216 00	HI/LOW INDICATOR SWITCH ··· REMOVAL AND INSTALLATION	0.9
228216 10	HI/LOW INDICATOR SWITCH ··· REPLACEMENT	0.9
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
228252 00	4WD INDICATOR LAMP SWITCH ··· REMOVAL AND INSTALLATION	0.9
228252 10	4WD INDICATOR LAMP SWITCH ··· REPLACEMENT	0.9
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
228253 00	4WD DETECTION SWITCH ··· REMOVAL AND INSTALLATION	0.9
228253 10	4WD DETECTION SWITCH ··· REPLACEMENT	0.9
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
228255 00	CENTER DIFFERENTIAL LOCK SWITCH ··· REMOVAL AND INSTALLATION	0.9
228255 10	CENTER DIFFERENTIAL LOCK SWITCH ··· REPLACEMENT	0.9
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
228256 00	CENTER DIFFERENTIAL LOCK DETECTION SWITCH ··· REMOVAL AND INSTALLAT	0.9
228256 10	CENTER DIFFERENTIAL LOCK DETECTION SWITCH ··· REPLACEMENT	0.9
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
231110 00	T/M SELECTOR LEVER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.5
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
231110 10	T/M SELECTOR LEVER ASSEMBLY ··· REPLACEMENT	0.5
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
231112 00	T/M SELECTOR HANDLE ··· REMOVAL AND INSTALLATION	0.3
231112 10	T/M SELECTOR HANDLE ··· REPLACEMENT	0.3
231131 00	T/M CONTROL (SELECT) CABLE ··· REMOVAL AND INSTALLATION	0.8
	[Additional time allowance]	
	C3 ··· With transfer	0.2
231131 10	T/M CONTROL (SELECT) CABLE ··· REPLACEMENT	0.8
	[Additional time allowance]	
	C3 ··· With transfer	0.2
231311 00	T/F CONTROL LEVER ··· REMOVAL AND INSTALLATION	1.2
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
231311 10	T/F CONTROL LEVER ··· REPLACEMENT	1.2
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
231312 00	T/F CONTROL LEVER KNOB ··· REMOVAL AND INSTALLATION	0.2
231312 10	T/F CONTROL LEVER KNOB ··· REPLACEMENT	0.2
233010 00	T/M ASSEMBLY ··· REMOVAL AND INSTALLATION	
	R4A5	2.9
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	R5A5	2.9

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	A6 ··· Rear heater air duct - R&I	0.6
	V5A5	4.9
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	A6 ··· Rear heater air duct - R&I	0.6
	COMMON V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	A6 ··· Rear heater air duct - R&I	0.6
233010 10	T/M ASSEMBLY ··· REPLACEMENT	
	R4A5	2.9
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	A9 ··· Inspection by multi-use tester	0.2
	R5A5	2.9
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	A6 ··· Rear heater air duct - R&I	0.6
	A9 ··· Inspection by multi-use tester	0.2
	V5A5	4.9
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	A6 ··· Rear heater air duct - R&I	0.6
	A9 ··· Inspection by multi-use tester	0.2
	COMMON V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A1 ··· Oil line flush	0.4
	A6 ··· Rear heater air duct - R&I	0.6
	A9 ··· Inspection by multi-use tester	0.2
233010 20	T/M ASSEMBLY ··· OVERHAUL	
	R4A5	8.2

CODE	DESCRIPTION	KG0W KH0W
	R5A5	8.5
	V4A5	10.2
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct - R&I	0.6
	V5A5	10.5
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct - R&I	0.6
	COMMON V5A5	10.5
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct - R&I	0.6
233010 9A	T/M ASSEMBLY ··· GROUP WORK (A)	
	R4A5	4.7
	R5A5	4.7
	V4A5	6.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct - R&I	0.6
	V5A5	6.7
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct - R&I	0.6
	COMMON V4A5	6.7
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct - R&I	0.6
233010 9B	T/M ASSEMBLY ··· GROUP WORK (B)	
	R4A5	5.3
	R5A5	5.3
	V4A5	7.3
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct - R&I	0.6
	V5A5	7.3
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct - R&I	0.6
	COMMON V4A5	7.3
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
233010 9C	T/M ASSEMBLY ··· GROUP WORK (C)	
	R4A5	5.4
	R5A5	5.4
	V4A5	7.4
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	V5A5	7.4
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	COMMON V4A5	7.4
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
233010 9D	T/M ASSEMBLY ··· GROUP WORK (D)	
	R4A5	5.5
	R5A5	5.5
	V4A5	7.5
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	V5A5	7.5
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	COMMON V4A5	7.5
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
233010 9E	T/M ASSEMBLY ··· GROUP WORK (E)	
	R4A5	6.4
	R5A5	6.4
	V4A5	8.4
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	V5A5	8.4
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A6 ··· Rear heater air duct – R&I	0.6
	COMMON V4A5	8.4
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
233010 9F	T/M ASSEMBLY ··· GROUP WORK (F)	
	R4A5	6.0
	R5A5	6.1
	V4A5	8.0
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	V5A5	8.1
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	COMMON V5A5	8.1
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
233130 00	T/M CONVERTER HOUSING ASSEMBLY ··· REMOVAL AND INSTALLATION	
	R4A5	3.3
	R5A5	3.3
	V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
	V5A5	4.9
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
	COMMON V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
233130 10	T/M CONVERTER HOUSING ASSEMBLY ··· REPLACEMENT	
	R4A5	3.3
	R5A5	3.3
	V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6

CODE	DESCRIPTION	KG0W KH0W
	V5A5	4.9
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
	COMMON V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
233132 00	T/M CONVERTER HOUSING GASKET ··· REMOVAL AND INSTALLATION	
	R4A5	3.3
	R5A5	3.3
	V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
	V5A5	4.9
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
	COMMON V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
233132 10	T/M CONVERTER HOUSING GASKET ··· REPLACEMENT	
	R4A5	3.3
	R5A5	3.3
	V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
	V5A5	4.9
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
	COMMON V4A5	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A4 ··· Rear heater air duct – R&I	0.6
233141 00	T/M OIL PAN ··· REMOVAL AND INSTALLATION	1.9
233141 10	T/M OIL PAN ··· REPLACEMENT	1.9
233142 00	T/M OIL PAN GASKET ··· REMOVAL AND INSTALLATION	1.9
233142 10	T/M OIL PAN GASKET ··· REPLACEMENT	1.9

CODE	DESCRIPTION	KG0W KH0W
233731 00	T/M OIL FILTER ··· REMOVAL AND INSTALLATION	1.9
233731 10	T/M OIL FILTER ··· REPLACEMENT	1.9
233810 00	T/M VALVE BODY ASSEMBLY ··· REMOVAL AND INSTALLATION	2.3
233810 10	T/M VALVE BODY ASSEMBLY ··· REPLACEMENT	2.3
233810 20	T/M VALVE BODY ASSEMBLY ··· OVERHAUL	4.6
234510 00	TORQUE CONVERTER ··· REMOVAL AND INSTALLATION	
	R4A5	3.0
	R5A5	3.0
	V4A5	4.6
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	V5A5	4.6
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	COMMON V4A5	4.6
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
234510 10	TORQUE CONVERTER ··· REPLACEMENT	
	R4A5	3.0
	R5A5	3.0
	V4A5	4.6
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	V5A5	4.6
	[Additional time allowance]	
	V1 ··· 6B3	1.8
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
	COMMON V4A5	4.6
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	[Additional operation]	
	A6 ··· Rear heater air duct – R&I	0.6
235010 00	T/F ASSEMBLY ··· REMOVAL AND INSTALLATION	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	V1 ··· 6B3	1.8
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
235010 10	T/F ASSEMBLY ··· REPLACEMENT	4.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0

CODE	DESCRIPTION	KG0W KH0W
	G4 ··· 4M4	0.5
	V1 ··· 6B3	1.8
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
235010 20	T/F ASSEMBLY ··· OVERHAUL	7.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	V1 ··· 6B3	1.8
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
235010 9A	T/F ASSEMBLY ··· GROUP WORK (A)	5.4
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	V1 ··· 6B3	1.8
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
235010 9B	T/F ASSEMBLY ··· GROUP WORK (B)	5.5
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	V1 ··· 6B3	1.8
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
235010 9C	T/F ASSEMBLY ··· GROUP WORK (C)	6.8
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	V1 ··· 6B3	1.8
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
235010 9D	T/F ASSEMBLY ··· GROUP WORK (D)	5.9
	[Additional time allowance]	
	C7 ··· 6G7	1.0
	G4 ··· 4M4	0.5
	V1 ··· 6B3	1.8
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
235113 00	T/F CASE OUTPUT SHAFT OIL SEAL ··· REMOVAL AND INSTALLATION	0.6
235113 10	T/F CASE OUTPUT SHAFT OIL SEAL ··· REPLACEMENT	0.6
235144 00	T/F EXTENSION HOUSING ··· REMOVAL AND INSTALLATION	1.3
235144 10	T/F EXTENSION HOUSING ··· REPLACEMENT	1.3
235145 00	T/F EXTENSION HOUSING OIL SEAL ··· REMOVAL AND INSTALLATION	0.7
235145 10	T/F EXTENSION HOUSING OIL SEAL ··· REPLACEMENT	0.7
235146 00	T/F EXTENSION HOUSING GASKET ··· REMOVAL AND INSTALLATION	1.3
235146 10	T/F EXTENSION HOUSING GASKET ··· REPLACEMENT	1.3
235164 00	T/F SIDE COVER GASKET ··· REMOVAL AND INSTALLATION	0.4
235164 10	T/F SIDE COVER GASKET ··· REPLACEMENT	0.4
235911 00	SPEEDOMETER DRIVEN GEAR SLEEVE ··· REMOVAL AND INSTALLATION	0.4
235911 10	SPEEDOMETER DRIVEN GEAR SLEEVE ··· REPLACEMENT	0.4
235913 00	SPEEDOMETER DRIVEN GEAR ··· REMOVAL AND INSTALLATION	0.4
235913 10	SPEEDOMETER DRIVEN GEAR ··· REPLACEMENT	0.4
237500 55	T/M & OIL LINE FLUSHING	0.7
237510 00	T/M OIL HOSE ··· REMOVAL AND INSTALLATION (All)	1.5

CODE	DESCRIPTION	KG0W KH0W
237510 10	T/M OIL HOSE ··· REPLACEMENT (All)	1.5
237520 00	T/M OIL PIPE ··· REMOVAL AND INSTALLATION (All)	2.0
237520 10	T/M OIL PIPE ··· REPLACEMENT (All)	2.0
237530 00	T/M OIL COOLER ··· REMOVAL AND INSTALLATION	1.1
237530 10	T/M OIL COOLER ··· REPLACEMENT	1.1
238201 00	SWITCH, PARK/NEUTRAL POSITION ··· REMOVAL AND INSTALLATION	0.7
238201 10	SWITCH, PARK/NEUTRAL POSITION ··· REPLACEMENT	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
238205 00	PADDLE SHIFT ASSY ··· REMOVAL AND INSTALLATION	0.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
238205 10	PADDLE SHIFT ASSY ··· REPLACEMENT	0.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
238214 00	HI/LOW INDICATOR SWITCH ··· REMOVAL AND INSTALLATION	0.8
238214 10	HI/LOW INDICATOR SWITCH ··· REPLACEMENT	0.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
238252 00	4WD INDICATOR LAMP SWITCH ··· REMOVAL AND INSTALLATION	0.8
238252 10	4WD INDICATOR LAMP SWITCH ··· REPLACEMENT	0.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
238253 00	4WD DETECTION SWITCH ··· REMOVAL AND INSTALLATION	0.8
	[Additional operation]	
	A1 ··· T/F extension housing - R&I	0.7
238253 10	4WD DETECTION SWITCH ··· REPLACEMENT	0.8
	[Additional operation]	
	A1 ··· T/F extension housing - R&I	0.7
	A9 ··· Inspection by multi-use tester	0.2
238255 00	CENTER DIFFERENTIAL LOCK SWITCH ··· REMOVAL AND INSTALLATION	0.8
238255 10	CENTER DIFFERENTIAL LOCK SWITCH ··· REPLACEMENT	0.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
238256 00	CENTER DIFFERENTIAL LOCK DETECTION SWITCH ··· REMOVAL AND INSTALLATI	0.8
238256 10	CENTER DIFFERENTIAL LOCK DETECTION SWITCH ··· REPLACEMENT	0.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
238301 00	PULSE GENERATOR ASSEMBLY (ELC) ··· REMOVAL AND INSTALLATION	0.5
238301 10	PULSE GENERATOR ASSEMBLY (ELC) ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
238307 00	OIL TEMPERATURE SENSOR ··· REMOVAL AND INSTALLATION	2.0
238307 10	OIL TEMPERATURE SENSOR ··· REPLACEMENT	2.0
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
238413 00	A/T RELAY ··· REMOVAL AND INSTALLATION	0.2
238413 10	A/T RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
238501 00	T/M ELC CONTROL UNIT ··· REMOVAL AND INSTALLATION	0.4
238501 10	T/M ELC CONTROL UNIT ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2

CODE	DESCRIPTION	KG0W KH0W
238501 13	T/M ELC CONTROL UNIT ··· REPROGRAMMING	0.3
238601 00	T/M VALVE BODY SOLENOID VALVE ASSEMBLY ··· REMOVAL AND INSTALLATIOI	2.1
238601 10	T/M VALVE BODY SOLENOID VALVE ASSEMBLY ··· REPLACEMENT	2.1
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
251010 00	PROPELLER SHAFT ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.7
251010 10	PROPELLER SHAFT ASSEMBLY ··· REPLACEMENT (One piece)	0.7
251020 00	PROPELLER SHAFT UNIVERSAL JOINT ASSEMBLY ··· REMOVAL AND INSTALLATI	1.1
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
251020 10	PROPELLER SHAFT UNIVERSAL JOINT ASSEMBLY ··· REPLACEMENT (One piece)	1.1
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
251041 00	PROPELLER SHAFT SLEEVE YOKE ··· REMOVAL AND INSTALLATION (One piece)	1.1
251041 10	PROPELLER SHAFT SLEEVE YOKE ··· REPLACEMENT (One piece)	1.1
251060 00	PROPELLER SHAFT CENTER BEARING ASSEMBLY ··· REMOVAL AND INSTALLATI	1.1
251060 10	PROPELLER SHAFT CENTER BEARING ASSEMBLY ··· REPLACEMENT (One piece)	1.1
253010 00	PROPELLER SHAFT ASSEMBLY ··· REMOVAL AND INSTALLATION	0.6
253010 10	PROPELLER SHAFT ASSEMBLY ··· REPLACEMENT	0.6
253020 00	PROPELLER SHAFT UNIVERSAL JOINT ASSEMBLY ··· REMOVAL AND INSTALLATI	1.0
253020 10	PROPELLER SHAFT UNIVERSAL JOINT ASSEMBLY ··· REPLACEMENT (One piece)	1.0
253041 00	PROPELLER SHAFT SLEEVE YOKE ··· REMOVAL AND INSTALLATION	0.7
253041 10	PROPELLER SHAFT SLEEVE YOKE ··· REPLACEMENT	0.7
261121 00	STEERING KNUCKLE ··· REMOVAL AND INSTALLATION (One side)	1.1
261121 10	STEERING KNUCKLE ··· REPLACEMENT (One side)	1.1
	[Additional operation]	
	01 ··· Per 1 pc.	0.7
261141 00	FRONT WHEEL HUB ··· REMOVAL AND INSTALLATION (One side)	0.8
261141 10	FRONT WHEEL HUB ··· REPLACEMENT (One side)	0.8
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
261142 00	FRONT WHEEL HUB BOLT ··· REMOVAL AND INSTALLATION (One side)	0.9
261142 10	FRONT WHEEL HUB BOLT ··· REPLACEMENT (One side)	0.9
	[Additional operation]	
	01 ··· Per 1 pc.	0.5
266112 00	FRONT AXLE HOUSING TUBE ··· REMOVAL AND INSTALLATION	3.0
266112 10	FRONT AXLE HOUSING TUBE ··· REPLACEMENT	3.0
266121 00	FRONT DRIVE KNUCKLE ··· REMOVAL AND INSTALLATION (One side)	1.1
266121 10	FRONT DRIVE KNUCKLE ··· REPLACEMENT (One side)	1.1
	[Additional operation]	
	01 ··· Per 1 pc.	0.7
266141 00	FRONT WHEEL HUB ··· REMOVAL AND INSTALLATION (One side)	0.8
266141 10	FRONT WHEEL HUB ··· REPLACEMENT (One side)	0.8
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
266142 00	FRONT WHEEL HUB BOLT ··· REMOVAL AND INSTALLATION (One side)	0.9
266142 10	FRONT WHEEL HUB BOLT ··· REPLACEMENT (One side)	0.9
	[Additional operation]	
	01 ··· Per 1 pc.	0.5
266169 00	FREE-WHEEL CLUTCH ASSEMBLY ··· REMOVAL AND INSTALLATION	3.1
266169 10	FREE-WHEEL CLUTCH ASSEMBLY ··· REPLACEMENT	3.1
266171 00	FRONT AXLE SHAFT ··· REMOVAL AND INSTALLATION (One side)	2.0
266171 10	FRONT AXLE SHAFT ··· REPLACEMENT (One side)	2.0
266172 00	FRONT AXLE SHAFT BEARING ··· REMOVAL AND INSTALLATION (One side)	2.0
266172 10	FRONT AXLE SHAFT BEARING ··· REPLACEMENT (One side)	2.0

CODE	DESCRIPTION	KG0W KH0W
266174 00	FRONT AXLE SHAFT OIL SEAL ··· REMOVAL AND INSTALLATION (One side)	1.9
266174 10	FRONT AXLE SHAFT OIL SEAL ··· REPLACEMENT (One side)	1.9
266180 00	FRONT DRIVE SHAFT ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	1.3
	[Additional operation]	
	A1 ··· Both side R&I	0.8
266180 80	FRONT DRIVE SHAFT ASSEMBLY (LEFT SIDE) ··· REPLACEMENT	1.3
	[Additional operation]	
	A1 ··· Both side replace	0.8
266180 81	FRONT DRIVE SHAFT ASSEMBLY (LEFT SIDE) ··· OVERHAUL	1.7
	[Additional operation]	
	A1 ··· Both side overhaul	1.2
266180 82	FRONT DRIVE SHAFT ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT	1.3
266180 83	FRONT DRIVE SHAFT ASSEMBLY (RIGHT SIDE) ··· OVERHAUL	1.7
266183 00	DRIVE SHAFT BOOT ··· REMOVAL AND INSTALLATION (One side)	1.6
	[Additional operation]	
	A1 ··· Both side R&I	1.1
266183 80	DRIVE SHAFT BOOT (LEFT SIDE) ··· REPLACEMENT	1.6
	[Additional operation]	
	A1 ··· Both side replace	1.1
266183 82	DRIVE SHAFT BOOT (RIGHT SIDE) ··· REPLACEMENT	1.6
266221 00	DIFFERENTIAL CASE ··· REMOVAL AND INSTALLATION	6.7
266221 10	DIFFERENTIAL CASE ··· REPLACEMENT	6.7
266222 00	DIFFERENTIAL SIDE & PINION GEAR SET ··· REMOVAL AND INSTALLATION	4.2
266222 10	DIFFERENTIAL SIDE & PINION GEAR SET ··· REPLACEMENT	4.2
266224 00	DIFFERENTIAL SIDE BEARING ··· REMOVAL AND INSTALLATION	5.7
266224 10	DIFFERENTIAL SIDE BEARING ··· REPLACEMENT	5.7
266225 00	DIFFERENTIAL SIDE GEAR OIL SEAL ··· REMOVAL AND INSTALLATION (One side)	3.0
266225 80	DIFFERENTIAL SIDE OIL SEAL (LEFT SIDE) ··· REPLACEMENT	1.3
	[Additional operation]	
	A1 ··· Both side replace	1.7
266225 82	DIFFERENTIAL SIDE OIL SEAL (RIGHT SIDE) ··· REPLACEMENT	3.0
266230 00	FINAL DRIVE GEAR SET ··· REMOVAL AND INSTALLATION	6.6
266230 10	FINAL DRIVE GEAR SET ··· REPLACEMENT	6.6
266231 00	DRIVE PINION BEARING ··· REMOVAL AND INSTALLATION	6.2
266231 10	DRIVE PINION BEARING ··· REPLACEMENT	6.2
266232 00	DRIVE PINION OIL SEAL ··· REMOVAL AND INSTALLATION	0.8
266232 10	DRIVE PINION OIL SEAL ··· REPLACEMENT	0.8
266234 00	COMPANION FLANGE ··· REMOVAL AND INSTALLATION	0.8
266234 10	COMPANION FLANGE ··· REPLACEMENT	0.8
266240 00	DIFFERENTIAL CARRIER ASSEMBLY ··· REMOVAL AND INSTALLATION	3.0
266240 10	DIFFERENTIAL CARRIER ASSEMBLY ··· REPLACEMENT	3.0
266240 20	DIFFERENTIAL CARRIER ASSEMBLY ··· OVERHAUL	7.6
266242 00	DIFFERENTIAL CARRIER GASKET ··· REMOVAL AND INSTALLATION	2.9
266242 10	DIFFERENTIAL CARRIER GASKET ··· REPLACEMENT	2.9
268101 00	FREE-WHEEL CLUTCH ACTUATOR ··· REMOVAL AND INSTALLATION	0.6
268101 10	FREE-WHEEL CLUTCH ACTUATOR ··· REPLACEMENT	0.6
268203 00	FREE-WHEEL CLUTCH DETECTION SWITCH ··· REMOVAL AND INSTALLATION	0.6
268203 10	FREE-WHEEL CLUTCH DETECTION SWITCH ··· REPLACEMENT	0.6
268531 00	4WD INDICATOR CONTROL UNIT ··· REMOVAL AND INSTALLATION	0.4
268531 10	4WD INDICATOR CONTROL UNIT ··· REPLACEMENT	0.4
268601 00	FREE-WHEEL CLUTCH SOLENOID VALVE ··· REMOVAL AND INSTALLATION	0.5
268601 10	FREE-WHEEL CLUTCH SOLENOID VALVE ··· REPLACEMENT	0.5
276110 00	REAR AXLE HOUSING ASSEMBLY ··· REMOVAL AND INSTALLATION	4.1
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6

CODE	DESCRIPTION	KG0W KH0W
276110 10	REAR AXLE HOUSING ASSEMBLY ··· REPLACEMENT	4.1
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276142 00	REAR WHEEL HUB BOLT ··· REMOVAL AND INSTALLATION (One side)	0.8
276142 10	REAR WHEEL HUB BOLT ··· REPLACEMENT (One side)	0.8
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
276171 00	REAR AXLE SHAFT ··· REMOVAL AND INSTALLATION (One side)	2.4
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.3
276171 10	REAR AXLE SHAFT ··· REPLACEMENT (One side)	2.4
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.3
	[Additional operation]	
	A1 ··· Both side replace (for rear disk brake)	0.3
	01 ··· Per 1 pc.	1.8
276173 00	REAR AXLE SHAFT OIL SEAL ··· REMOVAL AND INSTALLATION (One side)	1.2
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.3
276173 10	REAR AXLE SHAFT OIL SEAL ··· REPLACEMENT (One side)	1.2
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.3
	[Additional operation]	
	A1 ··· Both side replace (for rear disk brake)	0.3
	01 ··· Per 1 pc.	0.7
276174 00	REAR AXLE SHAFT BEARING ··· REMOVAL AND INSTALLATION (One side)	2.4
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.3
276174 10	REAR AXLE SHAFT BEARING ··· REPLACEMENT (One side)	2.4
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.3
	[Additional operation]	
	A1 ··· Both side replace (for rear disk brake)	0.3
	01 ··· Per 1 pc.	1.8
276220 00	DIFFERENTIAL CASE ASSEMBLY ··· REMOVAL AND INSTALLATION	6.4
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276220 10	DIFFERENTIAL CASE ASSEMBLY ··· REPLACEMENT	6.4
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276222 00	DIFFERENTIAL SIDE & PINION GEAR SET ··· REMOVAL AND INSTALLATION	4.2
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276222 10	DIFFERENTIAL SIDE & PINION GEAR SET ··· REPLACEMENT	4.2
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276224 00	DIFFERENTIAL SIDE BEARING ··· REMOVAL AND INSTALLATION	5.2
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276224 10	DIFFERENTIAL SIDE BEARING ··· REPLACEMENT	5.2
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276230 00	FINAL DRIVE GEAR SET ··· REMOVAL AND INSTALLATION	6.5
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6

CODE	DESCRIPTION	KG0W KH0W
276230 10	FINAL DRIVE GEAR SET ··· REPLACEMENT	6.5
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276231 00	DRIVE PINION BEARING ··· REMOVAL AND INSTALLATION	5.7
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276231 10	DRIVE PINION BEARING ··· REPLACEMENT	5.7
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276232 00	DRIVE PINION OIL SEAL ··· REMOVAL AND INSTALLATION	0.9
276232 10	DRIVE PINION OIL SEAL ··· REPLACEMENT	0.9
276234 00	DIFFERENTIAL COMPANION FLANGE ··· REMOVAL AND INSTALLATION	0.9
276234 10	DIFFERENTIAL COMPANION FLANGE ··· REPLACEMENT	0.9
276240 00	DIFFERENTIAL CARRIER ASSEMBLY ··· REMOVAL AND INSTALLATION	3.1
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276240 10	DIFFERENTIAL CARRIER ASSEMBLY ··· REPLACEMENT	3.1
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276240 20	DIFFERENTIAL CARRIER ASSEMBLY ··· OVERHAUL	7.2
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276242 00	DIFFERENTIAL CARRIER GASKET ··· REMOVAL AND INSTALLATION	3.1
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276242 10	DIFFERENTIAL CARRIER GASKET ··· REPLACEMENT	3.1
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
276271 00	DIFFERENTIAL LOCK AIR PUMP ··· REMOVAL AND INSTALLATION	0.6
276271 10	DIFFERENTIAL LOCK AIR PUMP ··· REPLACEMENT	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
278101 00	DIFFERENTIAL LOCK ACTUATOR ··· REMOVAL AND INSTALLATION	5.4
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
278101 10	DIFFERENTIAL LOCK ACTUATOR ··· REPLACEMENT	5.4
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
278201 00	DIFFERENTIAL LOCK SWITCH ··· REMOVAL AND INSTALLATION	0.4
278201 10	DIFFERENTIAL LOCK SWITCH ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
278202 00	DIFFERENTIAL LOCK DETECTION SWITCH ··· REMOVAL AND INSTALLATION	3.2
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
278202 10	DIFFERENTIAL LOCK DETECTION SWITCH ··· REPLACEMENT	3.2
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
278501 00	DIFFERENTIAL LOCK CONTROL UNIT ··· REMOVAL AND INSTALLATION	0.4
278501 10	DIFFERENTIAL LOCK CONTROL UNIT ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
311010 00	WHEEL ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.4

CODE	DESCRIPTION	KG0W KH0W
311010 05	WHEEL ASSY ··· ROTATION (One side)	0.3
311010 10	WHEEL ASSEMBLY ··· REPLACEMENT (One piece)	0.4
311010 67	WHEEL ASSEMBLY ··· BALANCE (One piece)	0.5
	[Additional operation]	
	01 ··· Per 1 pc.	0.2
311015 00	DISC WHEEL ··· REMOVAL AND INSTALLATION (One piece)	0.8
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
311015 10	DISC WHEEL ··· REPLACEMENT (One piece)	0.8
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
312012 00	CENTER CAP ··· REMOVAL AND INSTALLATION (One piece)	0.4
312012 10	CENTER CAP ··· REPLACEMENT (One piece)	0.4
314021 00	SPARE TYRE CARRIER (HANGER) ··· REMOVAL AND INSTALLATION	0.7
	[Additional operation]	
	A1 ··· Quarter trim lower – R&I	0.2
314021 10	SPARE TYRE CARRIER (HANGER) ··· REPLACEMENT	0.7
	[Additional operation]	
	A1 ··· Quarter trim lower – R&I	0.2
321130 00	NO.2 CROSSMEMBER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.6
321130 10	NO.2 CROSSMEMBER ASSEMBLY ··· REPLACEMENT	0.6
321211 00	FRONT MOUNTING INSULATOR ··· REMOVAL AND INSTALLATION (One side)	
	4D5	6.3
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.3
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
321211 00	FRONT MOUNTING INSULATOR ··· REMOVAL AND INSTALLATION (All)	
	4G6	5.1
321211 00	FRONT MOUNTING INSULATOR ··· REMOVAL AND INSTALLATION (One side)	
	4M4	8.4
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
	6B3	9.1
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
	6G7	7.9
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
	COMMON 6B3	9.1
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
321211 10	FRONT MOUNTING INSULATOR ··· REPLACEMENT (All)	
	4D5	6.3
	[Additional time allowance]	
	M6 ··· Automatic transmission, With transfer	1.5
	Q8 ··· Manual transmission, With transfer	1.3
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
	4G6	5.1

CODE	DESCRIPTION	KG0W KH0W
	4M4	8.4
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
	6B3	9.1
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
	6G7	7.9
	[Additional time allowance]	
	C3 ··· Automatic transmission	0.3
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
	COMMON 6B3	9.1
	[Additional operation]	
	A1 ··· Rear heater air duct – R&I	0.6
321212 00	REAR MOUNTING INSULATOR ··· REMOVAL AND INSTALLATION	0.6
321212 10	REAR MOUNTING INSULATOR ··· REPLACEMENT	0.6
321213 00	T/F MOUNTING INSULATOR ··· REMOVAL AND INSTALLATION	0.4
321213 10	T/F MOUNTING INSULATOR ··· REPLACEMENT	0.4
322110 00	FRONT DIFFERENTIAL CROSSMEMBER ASSEMBLY ··· REMOVAL AND INSTALLATI	0.7
322110 10	FRONT DIFFERENTIAL CROSSMEMBER ASSEMBLY ··· REPLACEMENT	0.7
322112 00	FRONT DIFFERENTIAL MOUNTING BRACKET ··· REMOVAL AND INSTALLATION	2.7
322112 10	FRONT DIFFERENTIAL MOUNTING BRACKET ··· REPLACEMENT	2.7
322211 00	FRONT DIFFERENTIAL MOUNTING INSULATOR ··· REMOVAL AND INSTALLATION	0.6
322211 10	FRONT DIFFERENTIAL MOUNTING INSULATOR ··· REPLACEMENT	0.6
330000 91	WHEEL ALIGNMENT	1.0
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
335110 00	LOWER ARM ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	1.5
	[Additional time allowance]	
	B1 ··· With transfer	0.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
335110 10	LOWER ARM ASSEMBLY ··· REPLACEMENT (One side)	1.5
	[Additional time allowance]	
	B1 ··· With transfer	0.5
	[Additional operation]	
	A1 ··· Both side replace (for 4WD)	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.5
335112 00	LOWER ARM BUSHING ··· REMOVAL AND INSTALLATION (One side)	1.6
	[Additional time allowance]	
	B1 ··· With transfer	0.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
335112 10	LOWER ARM BUSHING ··· REPLACEMENT (One side)	1.6
	[Additional time allowance]	
	B1 ··· With transfer	0.5
	[Additional operation]	
	A1 ··· Both side replace (for 4WD)	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.6
335114 00	LOWER ARM BALL JOINT ··· REMOVAL AND INSTALLATION (One side)	1.4
	[Additional time allowance]	

CODE	DESCRIPTION	KG0W KH0W
	B1 ··· With transfer	0.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
335114 10	LOWER ARM BALL JOINT ··· REPLACEMENT (One side)	1.4
	[Additional time allowance]	
	B1 ··· With transfer	0.5
	[Additional operation]	
	A1 ··· Both side replace (for 4WD)	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.4
335130 00	UPPER ARM ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	1.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
335130 10	UPPER ARM ASSEMBLY ··· REPLACEMENT (One side)	1.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.5
335135 00	UPPER ARM BALL JOINT ··· REMOVAL AND INSTALLATION (One side)	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
335135 10	UPPER ARM BALL JOINT ··· REPLACEMENT (One side)	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.4
335138 00	UPPER ARM BUMP STOPPER ··· REMOVAL AND INSTALLATION (One side)	0.5
335138 10	UPPER ARM BUMP STOPPER ··· REPLACEMENT (One side)	0.5
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
335211 00	FRONT COIL SPRING ··· REMOVAL AND INSTALLATION (One side)	1.7
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
335211 10	FRONT COIL SPRING ··· REPLACEMENT (One side)	1.7
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	1.0
335310 00	FRONT SHOCK ABSORBER ASSEMBLY ··· REMOVAL AND INSTALLATION (One sid	1.2
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
335310 10	FRONT SHOCK ABSORBER ASSEMBLY ··· REPLACEMENT (One side)	1.2
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.5
335311 00	FRONT SHOCK ABSORBER ··· REMOVAL AND INSTALLATION (One side)	1.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
335311 10	FRONT SHOCK ABSORBER ··· REPLACEMENT (One side)	1.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.8
335411 00	FRONT STABILIZER BAR ··· REMOVAL AND INSTALLATION	0.7
335411 10	FRONT STABILIZER BAR ··· REPLACEMENT	0.7
335412 00	FRONT STABILIZER BUSHING ··· REMOVAL AND INSTALLATION	0.5
335412 10	FRONT STABILIZER BUSHING ··· REPLACEMENT	0.5
335414 00	FRONT STABILIZER LINK KIT ··· REMOVAL AND INSTALLATION (One side)	0.5
335414 10	FRONT STABILIZER LINK KIT ··· REPLACEMENT (One side)	0.5

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
346110 00	LOWER ARM ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.7
346110 10	LOWER ARM ASSEMBLY ··· REPLACEMENT (One side)	0.7
	[Additional operation]	
	01 ··· Per 1 pc.	0.3
346112 00	LOWER ARM BUSHING ··· REMOVAL AND INSTALLATION (One side)	0.8
346112 10	LOWER ARM BUSHING ··· REPLACEMENT (One side)	0.8
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
346135 00	BUMP STOPPER ··· REMOVAL AND INSTALLATION (One side)	0.5
346135 10	BUMP STOPPER ··· REPLACEMENT (One side)	0.5
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
346211 00	REAR COIL SPRING ··· REMOVAL AND INSTALLATION (One side)	1.4
346211 10	REAR COIL SPRING ··· REPLACEMENT (One side)	1.4
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
346212 00	REAR COIL SPRING SEAT ··· REMOVAL AND INSTALLATION (One side)	1.4
346212 10	REAR COIL SPRING SEAT ··· REPLACEMENT (One side)	1.4
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
346311 00	REAR SHOCK ABSORBER ··· REMOVAL AND INSTALLATION (One side)	0.6
346311 10	REAR SHOCK ABSORBER ··· REPLACEMENT (One side)	0.6
	[Additional operation]	
	01 ··· Per 1 pc.	0.2
346411 00	REAR STABILIZER BAR ··· REMOVAL AND INSTALLATION	0.9
346411 10	REAR STABILIZER BAR ··· REPLACEMENT	0.9
346412 00	REAR STABILIZER BUSHING ··· REMOVAL AND INSTALLATION (All)	0.9
346412 10	REAR STABILIZER BUSHING ··· REPLACEMENT (All)	0.9
346414 00	REAR STABILIZER LINK KIT ··· REMOVAL AND INSTALLATION (One side)	0.5
346414 10	REAR STABILIZER LINK KIT ··· REPLACEMENT (One side)	0.5
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
346510 00	LATERAL ROD ASSEMBLY ··· REMOVAL AND INSTALLATION	0.9
346510 10	LATERAL ROD ASSEMBLY ··· REPLACEMENT	0.9
346512 00	LATERAL ROD BUSHING ··· REMOVAL AND INSTALLATION	1.0
346512 10	LATERAL ROD BUSHING ··· REPLACEMENT	1.0
350000 94	BRAKE SYSTEM ··· BLEED	0.4
351110 00	BRAKE MASTER CYLINDER ASSEMBLY ··· REMOVAL AND INSTALLATION	1.4
351110 10	BRAKE MASTER CYLINDER ASSEMBLY ··· REPLACEMENT	1.4
351110 20	BRAKE MASTER CYLINDER ASSEMBLY ··· OVERHAUL	2.0
351210 00	BRAKE BOOSTER ASSEMBLY ··· REMOVAL AND INSTALLATION	1.6
351210 10	BRAKE BOOSTER ASSEMBLY ··· REPLACEMENT	1.6
352211 00	FRONT BRAKE DISC (ROTOR) ··· REMOVAL AND INSTALLATION (One side)	0.6
	[Additional operation]	
	A1 ··· Disc brake pad assembly - R&I	0.1
352211 10	FRONT BRAKE DISC (ROTOR) ··· REPLACEMENT (One side)	0.6
	[Additional operation]	
	A1 ··· Disc brake pad assembly ··· replacement	0.1
	01 ··· Per 1 pc.	0.2
352211 89	FRONT BRAKE DISC (ROTOR) ··· ON-VEHICLE GRINDING (Both side)	1.6
	[Additional operation]	
	A1 ··· Disc brake pad assembly ··· replacement	0.1
352220 00	DISC BRAKE CALIPER ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.8

CODE	DESCRIPTION	KG0W KH0W
352220 10	DISC BRAKE CALIPER ASSEMBLY ··· REPLACEMENT (One side)	0.8
	[Additional operation]	
	01 ··· Per 1 pc.	0.3
352220 20	DISC BRAKE CALIPER ASSEMBLY ··· OVERHAUL (One side)	1.1
	[Additional operation]	
	01 ··· Per 1 pc.	0.6
352226 00	DISC BRAKE PAD ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.5
352226 10	DISC BRAKE PAD ASSEMBLY ··· REPLACEMENT (One side)	0.5
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
352520 00	DRUM BRAKE SHOE & LINING ASSEMBLY ··· REMOVAL AND INSTALLATION (One	0.7
352520 10	DRUM BRAKE SHOE & LINING ASSEMBLY ··· REPLACEMENT (One side)	0.7
	[Additional operation]	
	01 ··· Per 1 pc.	0.2
352530 00	DRUM BRAKE WHEEL CYLINDER ASSEMBLY ··· REMOVAL AND INSTALLATION (Or	0.8
352530 10	DRUM BRAKE WHEEL CYLINDER ASSEMBLY ··· REPLACEMENT (One side)	0.8
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
352530 20	DRUM BRAKE WHEEL CYLINDER ASSEMBLY ··· OVERHAUL (One side)	0.9
	[Additional operation]	
	01 ··· Per 1 pc.	0.5
352551 00	DRUM BRAKE BACKING PLATE ··· REMOVAL AND INSTALLATION (One side)	2.4
352551 10	DRUM BRAKE BACKING PLATE ··· REPLACEMENT (One side)	2.4
	[Additional operation]	
	01 ··· Per 1 pc.	1.8
352570 00	DRUM BRAKE SHOE ADJUSTER ASSEMBLY (AUTO) ··· REMOVAL AND INSTALLAT	0.7
352570 10	DRUM BRAKE SHOE ADJUSTER ASSEMBLY (AUTO) ··· REPLACEMENT (One side)	0.7
	[Additional operation]	
	01 ··· Per 1 pc.	0.2
352591 00	BRAKE DRUM ··· REMOVAL AND INSTALLATION (One side)	0.5
352591 10	BRAKE DRUM ··· REPLACEMENT (One side)	0.5
	[Additional operation]	
	01 ··· Per 1 pc.	0.1
352611 00	REAR BRAKE DISC ··· REMOVAL AND INSTALLATION (One side)	0.8
	[Additional operation]	
	A1 ··· Disc brake pad assembly - R&I	0.1
352611 10	REAR BRAKE DISC ··· REPLACEMENT (One side)	0.8
	[Additional operation]	
	A1 ··· Disc brake pad assembly ··· replacement	0.1
	01 ··· Per 1 pc.	0.2
352611 89	REAR BRAKE DISC (ROTOR) ··· ON-VEHICLE GRINDING (Both side)	1.6
	[Additional operation]	
	A1 ··· Disc brake pad assembly ··· replacement	0.1
352620 00	DISC BRAKE CALIPER ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.8
352620 10	DISC BRAKE CALIPER ASSEMBLY ··· REPLACEMENT (One side)	0.8
	[Additional operation]	
	01 ··· Per 1 pc.	0.4
352620 20	DISC BRAKE CALIPER ASSEMBLY ··· OVERHAUL (One side)	1.1
	[Additional operation]	
	01 ··· Per 1 pc.	0.7
352626 00	DISC BRAKE PAD ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.6
352626 10	DISC BRAKE PAD ASSEMBLY ··· REPLACEMENT (One side)	0.6
	[Additional operation]	
	01 ··· Per 1 pc.	0.2
353121 00	BRAKE HOSE (FRONT) ··· REMOVAL AND INSTALLATION (One side)	0.7

CODE	DESCRIPTION	KG0W KH0W
353121 10	BRAKE HOSE (FRONT) ··· REPLACEMENT (One side)	0.7
	[Additional operation]	
	01 ··· Per 1 pc.	0.3
353122 00	BRAKE HOSE (MAIN) ··· REMOVAL AND INSTALLATION	0.7
353122 10	BRAKE HOSE (MAIN) ··· REPLACEMENT	0.7
353123 00	BRAKE HOSE (REAR) ··· REMOVAL AND INSTALLATION (One side)	0.7
353123 10	BRAKE HOSE (REAR) ··· REPLACEMENT (One side)	0.7
	[Additional operation]	
	01 ··· Per 1 pc.	0.3
353140 00	OIL RESERVOIR TANK ASSEMBLY ··· REMOVAL AND INSTALLATION	1.4
353140 10	OIL RESERVOIR TANK ASSEMBLY ··· REPLACEMENT	1.4
353221 00	VACUUM HOSE ··· REMOVAL AND INSTALLATION	0.3
353221 10	VACUUM HOSE ··· REPLACEMENT	0.3
353260 00	BRAKE VACUUM PUMP ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	0.8
	4M4	0.6
	COMMON 4D5	0.8
353260 10	BRAKE VACUUM PUMP ASSEMBLY ··· REPLACEMENT	
	4D5	0.8
	4M4	0.6
	COMMON 4D5	0.8
354011 00	BRAKE PEDAL ··· REMOVAL AND INSTALLATION	0.5
354011 10	BRAKE PEDAL ··· REPLACEMENT	0.5
354011 40	BRAKE PEDAL ··· ADJUSTMENT	0.2
354520 00	HYDRAULIC UNIT ASSEMBLY ··· REMOVAL AND INSTALLATION	1.6
354520 10	HYDRAULIC UNIT ASSEMBLY ··· REPLACEMENT	1.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
358201 00	STOP LAMP SWITCH ··· REMOVAL AND INSTALLATION	0.3
358201 10	STOP LAMP SWITCH ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
358206 00	ASC SWITCH ··· REMOVAL AND INSTALLATION	0.4
358206 10	ASC SWITCH ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
358221 00	BRAKE OIL LEVEL SWITCH (SENSOR) ··· REMOVAL AND INSTALLATION	1.4
358221 10	BRAKE OIL LEVEL SWITCH (SENSOR) ··· REPLACEMENT	1.4
358301 00	LONGITUDINAL G SENSOR (ABS) ··· REMOVAL AND INSTALLATION (One piece)	0.5
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
358301 10	LONGITUDINAL G SENSOR (ABS) ··· REPLACEMENT (One piece)	0.5
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
	A9 ··· Inspection by multi-use tester	0.2
358308 00	STEERING WHEEL ANGULAR VELOCITY SENSOR ··· REMOVAL AND INSTALLATIOI	0.7
358308 10	STEERING WHEEL ANGULAR VELOCITY SENSOR ··· REPLACEMENT	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
358311 00	FRONT SPEED SENSOR (ABS,AYC,ACD) ··· REMOVAL AND INSTALLATION (One pi	0.7
358311 10	FRONT SPEED SENSOR (ABS,AYC,ACD) ··· REPLACEMENT (One piece)	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	01 ··· Per 1 pc.	0.2
358312 00	REAR SPEED SENSOR (ABS,AYC,ACD) ··· REMOVAL AND INSTALLATION (One piec	0.7

CODE	DESCRIPTION	KG0W KH0W
358312 10	REAR SPEED SENSOR (ABS,AYC,ACD) ··· REPLACEMENT (One piece)	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
	01 ··· Per 1 pc.	0.3
358331 00	YAW RATE SENSOR ··· REMOVAL AND INSTALLATION	0.5
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
358331 10	YAW RATE SENSOR ··· REPLACEMENT	0.5
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
	A9 ··· Inspection by multi-use tester	0.2
358402 00	ABS HYDRAULIC UNIT MOTOR RELAY ··· REMOVAL AND INSTALLATION	0.2
358402 10	ABS HYDRAULIC UNIT MOTOR RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
358405 00	ABS POWER RELAY VALVE ··· REMOVAL AND INSTALLATION	0.2
358405 10	ABS POWER RELAY VALVE ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
361010 00	PARKING BRAKE LEVER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.4
361010 10	PARKING BRAKE LEVER ASSEMBLY ··· REPLACEMENT	0.4
361010 40	PARKING BRAKE LEVER ASSEMBLY ··· ADJUSTMENT	0.2
361040 00	FRONT PARKING BRAKE CABLE ASSEMBLY ··· REMOVAL AND INSTALLATION	0.6
361040 10	FRONT PARKING BRAKE CABLE ASSEMBLY ··· REPLACEMENT	0.6
361050 00	REAR PARKING BRAKE CABLE ASSEMBLY ··· REMOVAL AND INSTALLATION (One	0.9
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.3
361050 10	REAR PARKING BRAKE CABLE ASSEMBLY ··· REPLACEMENT (One piece)	0.9
	[Additional time allowance]	
	G4 ··· Disc brake (rear)	0.3
	[Additional operation]	
	A3 ··· Both side replace (for rear disk brake)	0.4
	01 ··· Per 1 pc.	0.4
362110 00	SHOE AND LINING ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	1.2
362110 10	SHOE AND LINING ASSEMBLY ··· REPLACEMENT (One side)	1.2
	[Additional operation]	
	01 ··· Per 1 pc.	0.5
362120 00	PARKING BRAKE SHOE ADJUSTER ASSEMBLY ··· REMOVAL AND INSTALLATION (	1.0
362120 10	PARKING BRAKE SHOE ADJUSTER ASSEMBLY ··· REPLACEMENT (One side)	1.0
	[Additional operation]	
	01 ··· Per 1 pc.	0.5
362140 00	BACKING PLATE ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	2.7
362140 10	BACKING PLATE ASSEMBLY ··· REPLACEMENT (One side)	2.7
	[Additional operation]	
	01 ··· Per 1 pc.	2.1
368201 00	PARKING BRAKE SWITCH ··· REMOVAL AND INSTALLATION	0.3
368201 10	PARKING BRAKE SWITCH ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
371010 00	STEERING WHEEL ASSEMBLY ··· REMOVAL AND INSTALLATION	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
371010 10	STEERING WHEEL ASSEMBLY ··· REPLACEMENT	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2

CODE	DESCRIPTION	KG0W KH0W
371010 40	STEERING WHEEL ASSEMBLY ··· ADJUSTMENT AT TIE ROD ENDS	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
372010 00	STEERING SHAFT ASSEMBLY ··· REMOVAL AND INSTALLATION	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
372010 10	STEERING SHAFT ASSEMBLY ··· REPLACEMENT	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
372050 00	STEERING SHAFT JOINT ASSEMBLY ··· REMOVAL AND INSTALLATION	0.7
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
372050 10	STEERING SHAFT JOINT ASSEMBLY ··· REPLACEMENT	0.7
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
372070 00	STEERING COLUMN COVER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.3
372070 10	STEERING COLUMN COVER ASSEMBLY ··· REPLACEMENT	0.3
372090 00	STEERING LOCK ··· REMOVAL AND INSTALLATION	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
372090 10	STEERING LOCK ··· REPLACEMENT	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
374050 00	STEERING GEAR ASSEMBLY (RACK & PINION) ··· REMOVAL AND INSTALLATION	1.9
	[Additional time allowance]	
	B1 ··· With transfer	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
374050 10	STEERING GEAR ASSEMBLY (RACK & PINION) ··· REPLACEMENT	1.9
	[Additional time allowance]	
	B1 ··· With transfer	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
374050 20	STEERING GEAR ASSEMBLY (RACK & PINION) ··· OVERHAUL	3.1
	[Additional time allowance]	
	B1 ··· With transfer	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
374056 00	STEERING GEAR BOX PINION OIL SEAL ··· REMOVAL AND INSTALLATION	2.5
	[Additional time allowance]	
	B1 ··· With transfer	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
374056 10	STEERING GEAR BOX PINION OIL SEAL ··· REPLACEMENT	2.5
	[Additional time allowance]	
	B1 ··· With transfer	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
374058 00	STEERING GEAR BOX BELLOWS ··· REMOVAL AND INSTALLATION (One side)	2.0
	[Additional time allowance]	
	B1 ··· With transfer	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
374058 10	STEERING GEAR BOX BELLOWS ··· REPLACEMENT (One side)	2.0
	[Additional time allowance]	

CODE	DESCRIPTION	KG0W KH0W
	B1 ··· With transfer	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.1
375010 00	POWER STEERING OIL PUMP ASSEMBLY ··· REMOVAL AND INSTALLATION	
	4D5	0.9
	4G6	0.9
	4M4	1.5
	6B3	1.1
	6G7	1.0
	COMMON 4M4	1.5
375010 10	POWER STEERING OIL PUMP ASSEMBLY ··· REPLACEMENT	
	4D5	0.9
	4G6	0.9
	4M4	1.5
	6B3	1.1
	6G7	1.0
	COMMON 4M4	1.5
375010 20	POWER STEERING OIL PUMP ASSEMBLY ··· OVERHAUL	
	4D5	1.4
	4G6	1.4
	6B3	1.6
	6G7	1.5
	COMMON 6B3	1.6
375015 00	POWER STEERING OIL PIPE O-RING ··· REMOVAL AND INSTALLATION	0.8
375015 10	POWER STEERING OIL PIPE O-RING ··· REPLACEMENT	0.8
375020 00	POWER STEERING OIL RESERVOIR ASSEMBLY ··· REMOVAL AND INSTALLATION	0.6
375020 10	POWER STEERING OIL RESERVOIR ASSEMBLY ··· REPLACEMENT	0.6
375041 00	POWER STEERING OIL PUMP V-BELT ··· REMOVAL AND INSTALLATION	0.3
375041 10	POWER STEERING OIL PUMP V-BELT ··· REPLACEMENT	0.3
375041 40	POWER STEERING OIL PUMP V-BELT ··· ADJUSTMENT	0.2
375051 00	POWER STEERING PRESSURE HOSE ··· REMOVAL AND INSTALLATION	0.8
375051 10	POWER STEERING PRESSURE HOSE ··· REPLACEMENT	0.8
375054 00	POWER STEERING RETURN HOSE ··· REMOVAL AND INSTALLATION	0.9
375054 10	POWER STEERING RETURN HOSE ··· REPLACEMENT	0.9
375057 00	POWER STEERING SUCTION HOSE ··· REMOVAL AND INSTALLATION	0.6
375057 10	POWER STEERING SUCTION HOSE ··· REPLACEMENT	0.6
376040 40	TOE-IN ··· ADJUSTMENT	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
376041 00	TIE ROD ··· REMOVAL AND INSTALLATION (One side)	2.1
	[Additional time allowance]	
	B1 ··· With transfer	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.2
376041 10	TIE ROD ··· REPLACEMENT (One side)	2.1
	[Additional time allowance]	
	B1 ··· With transfer	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.2
376042 00	TIE ROD END ··· REMOVAL AND INSTALLATION (One side)	0.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2

CODE	DESCRIPTION	KG0W KH0W
376042 10	TIE ROD END ··· REPLACEMENT (One side)	0.9
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	01 ··· Per 1 pc.	0.2
421024 00	FRONT DECK PANEL ··· REMOVAL AND INSTALLATION	0.7
421024 10	FRONT DECK PANEL ··· REPLACEMENT	0.7
422022 00	FRONT FENDER PANEL ··· REMOVAL AND INSTALLATION (One side)	1.7
422022 10	FRONT FENDER PANEL ··· REPLACEMENT (One side)	1.7
422022 40	FRONT FENDER PANEL ··· ADJUSTMENT (One side)	0.4
422025 00	FRONT FENDER SPLASH SHIELD PANEL ··· REMOVAL AND INSTALLATION (One si	0.8
422025 10	FRONT FENDER SPLASH SHIELD PANEL ··· REPLACEMENT (One side)	0.8
422062 00	UNDER COVER ··· REMOVAL AND INSTALLATION	0.5
422062 10	UNDER COVER ··· REPLACEMENT	0.5
423121 00	FRONT WINDOW GLASS ··· REMOVAL AND INSTALLATION	3.0
	[Additional operation]	
	A3 ··· Auto lighting control sensor R&I	0.2
423121 10	FRONT WINDOW GLASS ··· REPLACEMENT	3.0
	[Additional operation]	
	A3 ··· Auto lighting control sensor R&I	0.2
423421 00	QUARTER WINDOW GLASS ··· REMOVAL AND INSTALLATION (One side)	1.8
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
423421 10	QUARTER WINDOW GLASS ··· REPLACEMENT (One side)	1.8
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
423621 00	SUNROOF GLASS ··· REMOVAL AND INSTALLATION (One piece)	0.4
423621 10	SUNROOF GLASS ··· REPLACEMENT (One piece)	0.4
423633 00	SUNROOF FRONT DRAIN HOSE ··· REMOVAL AND INSTALLATION (One piece)	2.8
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
423633 10	SUNROOF FRONT DRAIN HOSE ··· REPLACEMENT (One piece)	2.8
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
423634 00	SUNROOF REAR DRAIN HOSE ··· REMOVAL AND INSTALLATION (One piece)	1.9
	[Additional operation]	
	A3 ··· Third seat R&I	0.7
423634 10	SUNROOF REAR DRAIN HOSE ··· REPLACEMENT (One piece)	1.9
	[Additional operation]	
	A3 ··· Third seat R&I	0.7
423665 00	SUNROOF DRIVE CABLE ··· REMOVAL AND INSTALLATION	2.4
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
423665 10	SUNROOF DRIVE CABLE ··· REPLACEMENT	2.4
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
423691 00	SUNROOF DEFLECTOR ··· REMOVAL AND INSTALLATION	2.3
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
423691 10	SUNROOF DEFLECTOR ··· REPLACEMENT	2.3
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
423692 00	SUNROOF HOUSING ··· REMOVAL AND INSTALLATION	2.5
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A1 ··· Third seat R&I	0.7
423692 10	SUNROOF HOUSING ··· REPLACEMENT	2.5
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
423693 00	SUNROOF SUNSHADE ··· REMOVAL AND INSTALLATION	2.3
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
423693 10	SUNROOF SUNSHADE ··· REPLACEMENT	2.3
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
424110 00	FRONT DOOR ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	1.0
424110 40	FRONT DOOR ASSEMBLY ··· ADJUSTMENT (One side)	0.8
424111 00	FRONT DOOR PANEL ··· REMOVAL AND INSTALLATION (One side)	2.6
	[Additional operation]	
	A3 ··· Front door protect moulding – R&I	0.3
424111 10	FRONT DOOR PANEL ··· REPLACEMENT (One side)	2.6
	[Additional operation]	
	A3 ··· Front door protect moulding – R&I	0.3
424112 00	FRONT DOOR SASH ··· REMOVAL AND INSTALLATION (One side)	0.6
424112 10	FRONT DOOR SASH ··· REPLACEMENT (One side)	0.6
424113 00	FRONT DOOR HINGE ··· REMOVAL AND INSTALLATION (One side)	1.4
424113 10	FRONT DOOR HINGE ··· REPLACEMENT (One side)	1.4
424114 00	FRONT DOOR CHECK ··· REMOVAL AND INSTALLATION (One side)	0.5
424114 10	FRONT DOOR CHECK ··· REPLACEMENT (One side)	0.5
424121 00	FRONT DOOR GLASS ··· REMOVAL AND INSTALLATION (One side)	0.7
424121 10	FRONT DOOR GLASS ··· REPLACEMENT (One side)	0.7
424121 40	FRONT DOOR GLASS ··· ADJUSTMENT (One side)	0.5
424125 00	FRONT DOOR RUNCHANNEL ··· REMOVAL AND INSTALLATION (One side)	0.6
424125 10	FRONT DOOR RUNCHANNEL ··· REPLACEMENT (One side)	0.6
424131 00	FRONT DOOR WEATHERSTRIP (BODY SIDE) ··· REMOVAL AND INSTALLATION (Or	0.3
424131 10	FRONT DOOR WEATHERSTRIP (BODY SIDE) ··· REPLACEMENT (One side)	0.3
424132 00	FRONT DOOR WEATHERSTRIP (DOOR SIDE) ··· REMOVAL AND INSTALLATION (Or	0.5
424132 10	FRONT DOOR WEATHERSTRIP (DOOR SIDE) ··· REPLACEMENT (One side)	0.5
424133 00	FRONT DOOR WEATHERSTRIP (BELT INNER) ··· REMOVAL AND INSTALLATION (O	0.4
424133 10	FRONT DOOR WEATHERSTRIP (BELT INNER) ··· REPLACEMENT (One side)	0.4
424140 40	FRONT DOOR MECHANISM ··· ADJUSTMENT (One side)	0.5
424141 00	FRONT DOOR LATCH (LOCK) ··· REMOVAL AND INSTALLATION (One side)	0.8
424141 10	FRONT DOOR LATCH (LOCK) ··· REPLACEMENT (One side)	0.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
424141 40	FRONT DOOR LATCH (LOCK) ··· ADJUSTMENT (One side)	0.7
424142 00	FRONT DOOR STRIKER ··· REMOVAL AND INSTALLATION (One side)	0.2
424142 10	FRONT DOOR STRIKER ··· REPLACEMENT (One side)	0.2
424142 40	FRONT DOOR STRIKER ··· ADJUSTMENT (One side)	0.2
424143 00	FRONT DOOR LOCK CYLINDER ··· REMOVAL AND INSTALLATION (One side)	0.6
424143 10	FRONT DOOR LOCK CYLINDER ··· REPLACEMENT (One side)	0.6
424144 00	FRONT DOOR OUTSIDE HANDLE ··· REMOVAL AND INSTALLATION (One side)	0.6
424144 10	FRONT DOOR OUTSIDE HANDLE ··· REPLACEMENT (One side)	0.6
424145 00	FRONT DOOR INSIDE HANDLE ··· REMOVAL AND INSTALLATION (One side)	0.4
424145 10	FRONT DOOR INSIDE HANDLE ··· REPLACEMENT (One side)	0.4
424148 00	FRONT DOOR INSIDE LOCK ROD ··· REMOVAL AND INSTALLATION (One side)	0.7
424148 10	FRONT DOOR INSIDE LOCK ROD ··· REPLACEMENT (One side)	0.7
424161 00	FRONT DOOR REGULATOR ··· REMOVAL AND INSTALLATION (One side)	0.8
424161 10	FRONT DOOR REGULATOR ··· REPLACEMENT (One side)	0.8
424210 00	REAR (SLIDE) DOOR ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.5

CODE	DESCRIPTION	KG0W KH0W
424210 40	REAR (SLIDE) DOOR ASSEMBLY ··· ADJUSTMENT (One side)	0.4
424211 00	REAR (SLIDE) DOOR PANEL ··· REMOVAL AND INSTALLATION (One side)	2.2
	[Additional operation]	
	A2 ··· Rear door protect moulding – R&I	0.2
424211 10	REAR (SLIDE) DOOR PANEL ··· REPLACEMENT (One side)	2.2
	[Additional operation]	
	A2 ··· Rear door protect moulding – R&I	0.2
424212 00	REAR (SLIDE) DOOR SASH ··· REMOVAL AND INSTALLATION (One side)	0.9
424212 10	REAR (SLIDE) DOOR SASH ··· REPLACEMENT (One side)	0.9
424213 00	REAR (SLIDE) DOOR HINGE ··· REMOVAL AND INSTALLATION (One side)	0.5
424213 10	REAR (SLIDE) DOOR HINGE ··· REPLACEMENT (One side)	0.5
424214 00	REAR (SLIDE) DOOR CHECK ··· REMOVAL AND INSTALLATION (One side)	0.4
424214 10	REAR (SLIDE) DOOR CHECK ··· REPLACEMENT (One side)	0.4
424221 00	REAR (SLIDE) DOOR GLASS ··· REMOVAL AND INSTALLATION (One side)	0.9
424221 10	REAR (SLIDE) DOOR GLASS ··· REPLACEMENT (One side)	0.9
424221 40	REAR (SLIDE) DOOR GLASS ··· ADJUSTMENT (One side)	0.5
424225 00	REAR (SLIDE) DOOR RUNCHANNEL ··· REMOVAL AND INSTALLATION (One side)	0.8
424225 10	REAR (SLIDE) DOOR RUNCHANNEL ··· REPLACEMENT (One side)	0.8
424231 00	REAR (SLIDE) DOOR WEATHERSTRIP (BODY) ··· REMOVAL AND INSTALLATION (O	0.3
424231 10	REAR (SLIDE) DOOR WEATHERSTRIP (BODY) ··· REPLACEMENT (One side)	0.3
424232 00	REAR (SLIDE) DOOR WEATHERSTRIP (DOOR) ··· REMOVAL AND INSTALLATION (O	0.4
424232 10	REAR (SLIDE) DOOR WEATHERSTRIP (DOOR) ··· REPLACEMENT (One side)	0.4
424233 00	REAR (SLIDE) DOOR WEATHERSTRIP (BELT INNER) ··· REMOVAL AND INSTALLAT	0.4
424233 10	REAR (SLIDE) DOOR WEATHERSTRIP (BELT INNER) ··· REPLACEMENT (One side)	0.4
424240 40	REAR (SLIDE) DOOR MECHANISM ··· ADJUSTMENT (One side)	0.5
424241 00	REAR (SLIDE) DOOR LATCH ··· REMOVAL AND INSTALLATION (One side)	0.6
424241 10	REAR (SLIDE) DOOR LATCH ··· REPLACEMENT (One side)	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
424241 40	REAR (SLIDE) DOOR LATCH ··· ADJUSTMENT (One side)	0.6
424242 00	REAR (SLIDE) DOOR STRIKER ··· REMOVAL AND INSTALLATION (One side)	0.2
424242 10	REAR (SLIDE) DOOR STRIKER ··· REPLACEMENT (One side)	0.2
424242 40	REAR (SLIDE) DOOR STRIKER ··· ADJUSTMENT (One side)	0.2
424244 00	REAR (SLIDE) DOOR OUTSIDE HANDLE ··· REMOVAL AND INSTALLATION (One sid	0.6
424244 10	REAR (SLIDE) DOOR OUTSIDE HANDLE ··· REPLACEMENT (One side)	0.6
424245 00	REAR (SLIDE) DOOR INSIDE HANDLE ··· REMOVAL AND INSTALLATION (One side)	0.4
424245 10	REAR (SLIDE) DOOR INSIDE HANDLE ··· REPLACEMENT (One side)	0.4
424248 00	REAR (SLIDE) DOOR INSIDE LOCK ROD ··· REMOVAL AND INSTALLATION (One sid	0.6
424248 10	REAR (SLIDE) DOOR INSIDE LOCK ROD ··· REPLACEMENT (One side)	0.6
424261 00	REAR (SLIDE) DOOR REGULATOR ··· REMOVAL AND INSTALLATION (One side)	0.7
424261 10	REAR (SLIDE) DOOR REGULATOR ··· REPLACEMENT (One side)	0.7
424291 00	STATIONARY WINDOW GLASS ··· REMOVAL AND INSTALLATION (One side)	0.9
424291 10	STATIONARY WINDOW GLASS ··· REPLACEMENT (One side)	0.9
424292 00	STATIONARY WINDOW WEATHERSTRIP ··· REMOVAL AND INSTALLATION (One sid	0.9
424292 10	STATIONARY WINDOW WEATHERSTRIP ··· REPLACEMENT (One side)	0.9
424310 00	BACK DOOR (TAILGATE) ASSEMBLY ··· REMOVAL AND INSTALLATION	0.7
424310 40	BACK DOOR (TAILGATE) ASSEMBLY ··· ADJUSTMENT	0.2
424311 00	BACK DOOR (TAILGATE) PANEL ··· REMOVAL AND INSTALLATION (One piece)	3.7
424311 10	BACK DOOR (TAILGATE) PANEL ··· REPLACEMENT (One piece)	3.7
424313 00	BACK DOOR (TAILGATE) HINGE ··· REMOVAL AND INSTALLATION	2.0
	[Additional operation]	
	A4 ··· Third seat R&I	0.7
424313 10	BACK DOOR (TAILGATE) HINGE ··· REPLACEMENT	2.0
	[Additional operation]	
	A4 ··· Third seat R&I	0.7

CODE	DESCRIPTION	KG0W KH0W
424321 00	BACK DOOR (TAILGATE) GLASS ··· REMOVAL AND INSTALLATION	2.4
424321 10	BACK DOOR (TAILGATE) GLASS ··· REPLACEMENT	2.4
424331 00	BACK DOOR WEATHERSTRIP (BODY SIDE) ··· REMOVAL AND INSTALLATION	0.3
424331 10	BACK DOOR WEATHERSTRIP (BODY SIDE) ··· REPLACEMENT	0.3
424341 00	BACK DOOR (TAILGATE) LATCH ··· REMOVAL AND INSTALLATION	0.3
424341 10	BACK DOOR (TAILGATE) LATCH ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
424341 40	BACK DOOR (TAILGATE) LATCH ··· ADJUSTMENT	0.3
424342 00	BACK DOOR (TAILGATE) STRIKER ··· REMOVAL AND INSTALLATION	0.4
424342 10	BACK DOOR (TAILGATE) STRIKER ··· REPLACEMENT	0.4
424342 40	BACK DOOR (TAILGATE) STRIKER ··· ADJUSTMENT	0.3
424343 00	BACK DOOR (TAILGATE) LOCK CYLINDER ··· REMOVAL AND INSTALLATION	0.4
424343 10	BACK DOOR (TAILGATE) LOCK CYLINDER ··· REPLACEMENT	0.4
424344 00	BACK DOOR (TAILGATE) OUTER HANDLE ··· REMOVAL AND INSTALLATION	0.3
424344 10	BACK DOOR (TAILGATE) OUTER HANDLE ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
424353 00	BACK DOOR (TAILGATE) STOPPER ··· REMOVAL AND INSTALLATION (One piece)	0.3
424353 10	BACK DOOR (TAILGATE) STOPPER ··· REPLACEMENT (One piece)	0.3
425110 00	HOOD ASSEMBLY ··· REMOVAL AND INSTALLATION	0.4
425110 40	HOOD ASSEMBLY ··· ADJUSTMENT	0.3
425111 00	HOOD PANEL ··· REMOVAL AND INSTALLATION	0.6
425111 10	HOOD PANEL ··· REPLACEMENT	0.6
425113 00	HOOD HINGE ··· REMOVAL AND INSTALLATION	0.6
425113 10	HOOD HINGE ··· REPLACEMENT	0.6
425141 00	HOOD CATCH ··· REMOVAL AND INSTALLATION	0.4
425141 10	HOOD CATCH ··· REPLACEMENT	0.4
425151 00	HOOD OPENER CABLE ··· REMOVAL AND INSTALLATION	1.2
425151 10	HOOD OPENER CABLE ··· REPLACEMENT	1.2
425311 00	FUEL FILLER LID ··· REMOVAL AND INSTALLATION	0.2
425311 10	FUEL FILLER LID ··· REPLACEMENT	0.2
425341 00	FUEL FILLER LID LATCH ··· REMOVAL AND INSTALLATION	0.2
425341 10	FUEL FILLER LID LATCH ··· REPLACEMENT	0.2
425351 00	FUEL FILLER LID OPENER CABLE ··· REMOVAL AND INSTALLATION	0.8
	[Additional time allowance]	
	E7 ··· With heater	0.3
	H6 ··· Right-hand drive	2.7
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
	A2 ··· Third seat R&I	0.4
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
425351 10	FUEL FILLER LID OPENER CABLE ··· REPLACEMENT	0.8
	[Additional time allowance]	
	E7 ··· With heater	0.3
	H6 ··· Right-hand drive	2.7
	[Additional operation]	
	A1 ··· Rear heater air duct - R&I	0.6
	A2 ··· Third seat R&I	0.4
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
425352 00	FUEL FILLER LID OPENER LEVER ··· REMOVAL AND INSTALLATION	0.3
425352 10	FUEL FILLER LID OPENER LEVER ··· REPLACEMENT	0.3
428101 00	POWER WINDOW MOTOR (FRONT DOOR) ··· REMOVAL AND INSTALLATION (One s	0.8
428101 10	POWER WINDOW MOTOR (FRONT DOOR) ··· REPLACEMENT (One side)	0.8
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A9 ··· Inspection by multi-use tester	0.2
428102 00	POWER WINDOW MOTOR (REAR DOOR) ··· REMOVAL AND INSTALLATION (One sid	0.7
428102 10	POWER WINDOW MOTOR (REAR DOOR) ··· REPLACEMENT (One side)	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
428121 00	SUNROOF MOTOR ··· REMOVAL AND INSTALLATION	1.9
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
428121 10	SUNROOF MOTOR ··· REPLACEMENT	1.9
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
	A9 ··· Inspection by multi-use tester	0.2
428201 00	POWER WINDOW SWITCH (MAIN) ··· REMOVAL AND INSTALLATION	0.3
428201 10	POWER WINDOW SWITCH (MAIN) ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
428202 00	POWER WINDOW SWITCH (SUB) ··· REMOVAL AND INSTALLATION (One piece)	0.3
428202 10	POWER WINDOW SWITCH (SUB) ··· REPLACEMENT (One piece)	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
428205 00	REAR POWER WINDOW SWITCH (SUB) ··· REMOVAL AND INSTALLATION (One side	0.3
428205 10	REAR POWER WINDOW SWITCH (SUB) ··· REPLACEMENT (One side)	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
428241 00	SUNROOF SWITCH ··· REMOVAL AND INSTALLATION	0.3
428241 10	SUNROOF SWITCH ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
428401 00	POWER WINDOW RELAY ··· REMOVAL AND INSTALLATION	0.2
428401 10	POWER WINDOW RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
428702 00	KEYLESS ENTRY TRANSMITTER ··· REMOVAL AND INSTALLATION	0.3
428702 10	KEYLESS ENTRY TRANSMITTER ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
511120 00	FRONT WINDOW WIPER ARM ASSEMBLY ··· REMOVAL AND INSTALLATION (One si	0.3
511120 10	FRONT WINDOW WIPER ARM ASSEMBLY ··· REPLACEMENT (One side)	0.3
511130 00	FRONT WINDOW WIPER BLADE ASSEMBLY ··· REMOVAL AND INSTALLATION (One	0.3
511130 10	FRONT WINDOW WIPER BLADE ASSEMBLY ··· REPLACEMENT (One side)	0.3
511132 00	FRONT WINDOW WIPER BLADE RUBBER ··· REMOVAL AND INSTALLATION (One pi	0.3
511132 10	FRONT WINDOW WIPER BLADE RUBBER ··· REPLACEMENT (One piece)	0.3
511140 00	FRONT WINDOW WIPER LINK ASSEMBLY ··· REMOVAL AND INSTALLATION	0.6
511140 10	FRONT WINDOW WIPER LINK ASSEMBLY ··· REPLACEMENT	0.6
511220 00	REAR WINDOW WIPER ARM ASSEMBLY ··· REMOVAL AND INSTALLATION	0.2
511220 10	REAR WINDOW WIPER ARM ASSEMBLY ··· REPLACEMENT	0.2
511230 00	REAR WINDOW WIPER BLADE ASSEMBLY ··· REMOVAL AND INSTALLATION	0.2
511230 10	REAR WINDOW WIPER BLADE ASSEMBLY ··· REPLACEMENT	0.2
511232 00	REAR WINDOW WIPER BLADE RUBBER ··· REMOVAL AND INSTALLATION	0.2
511232 10	REAR WINDOW WIPER BLADE RUBBER ··· REPLACEMENT	0.2
512121 00	FRONT WINDOW WASHER TANK ··· REMOVAL AND INSTALLATION	0.7
512121 10	FRONT WINDOW WASHER TANK ··· REPLACEMENT	0.7
512131 00	FRONT WINDOW WASHER NOZZLE ··· REMOVAL AND INSTALLATION (One piece)	0.2
512131 10	FRONT WINDOW WASHER NOZZLE ··· REPLACEMENT (One piece)	0.2
512231 00	REAR WINDOW WASHER NOZZLE ··· REMOVAL AND INSTALLATION (One piece)	0.2

CODE	DESCRIPTION	KG0W KH0W
512231 10	REAR WINDOW WASHER NOZZLE ··· REPLACEMENT (One piece)	0.2
512332 00	HEADLAMP WASHER TUBE ··· REMOVAL AND INSTALLATION (All)	1.1
512332 10	HEADLAMP WASHER TUBE ··· REPLACEMENT (All)	1.1
512335 00	HEADLAMP WASHER ACTUATOR ··· REMOVAL AND INSTALLATION (One piece)	1.1
512335 10	HEADLAMP WASHER ACTUATOR ··· REPLACEMENT (One piece)	1.1
513010 00	REAR VIEW MIRROR ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.3
513010 10	REAR VIEW MIRROR ASSEMBLY ··· REPLACEMENT (One side)	0.3
514110 00	FRONT BUMPER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.9
514110 10	FRONT BUMPER ASSEMBLY ··· REPLACEMENT	0.9
514121 00	FRONT BUMPER FACE ··· REMOVAL AND INSTALLATION	1.5
	[Additional time allowance]	
	H1 ··· With head lamp washer	0.2
514121 10	FRONT BUMPER FACE ··· REPLACEMENT	1.5
	[Additional time allowance]	
	H1 ··· With head lamp washer	0.2
514131 00	FRONT BUMPER (INERTIA ABSORBER) STAY ··· REMOVAL AND INSTALLATION	1.1
514131 10	FRONT BUMPER (INERTIA ABSORBER) STAY ··· REPLACEMENT	1.1
514210 00	REAR BUMPER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.8
514210 10	REAR BUMPER ASSEMBLY ··· REPLACEMENT	0.8
514221 00	REAR BUMPER FACE ··· REMOVAL AND INSTALLATION	1.3
514221 10	REAR BUMPER FACE ··· REPLACEMENT	1.3
515110 00	OVER FENDER (FRONT) ··· REMOVAL AND INSTALLATION (One side)	0.7
515110 10	OVER FENDER (FRONT) ··· REPLACEMENT (One side)	0.7
515120 00	OVER FENDER (REAR) ··· REMOVAL AND INSTALLATION (One side)	0.4
515120 10	OVER FENDER (REAR) ··· REPLACEMENT (One side)	0.4
515130 00	OVER FENDER (DOOR) ··· REMOVAL AND INSTALLATION (One side)	0.4
515130 10	OVER FENDER (DOOR) ··· REPLACEMENT (One side)	0.4
516111 00	FRONT GRILLE ··· REMOVAL AND INSTALLATION (One piece)	0.3
516111 10	FRONT GRILLE ··· REPLACEMENT (One piece)	0.3
516116 00	FRONT DECK GARNISH ··· REMOVAL AND INSTALLATION	0.4
516116 10	FRONT DECK GARNISH ··· REPLACEMENT	0.4
516122 00	REAR QUARTER GARNISH ··· REMOVAL AND INSTALLATION (One side)	1.8
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
516122 10	REAR QUARTER GARNISH ··· REPLACEMENT (One side)	1.8
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
516139 00	SIDE SILL GARNISH ··· REMOVAL AND INSTALLATION (One side)	0.3
516139 10	SIDE SILL GARNISH ··· REPLACEMENT (One side)	0.3
516155 00	FENDER GARNISH ··· REMOVAL AND INSTALLATION (One piece)	0.2
516155 10	FENDER GARNISH ··· REPLACEMENT (One piece)	0.2
516172 00	TAILGATE UPPER GARNISH ··· REMOVAL AND INSTALLATION	0.4
516172 10	TAILGATE UPPER GARNISH ··· REPLACEMENT	0.4
516173 00	TAILGATE LOWER GARNISH ··· REMOVAL AND INSTALLATION	0.8
516173 10	TAILGATE LOWER GARNISH ··· REPLACEMENT	0.8
516211 00	FRONT WINDOW MOULDING ··· REMOVAL AND INSTALLATION (All)	3.0
516211 10	FRONT WINDOW MOULDING ··· REPLACEMENT (All)	3.0
516233 00	DRIP RAIL MOULDING ··· REMOVAL AND INSTALLATION (One piece)	0.3
516233 10	DRIP RAIL MOULDING ··· REPLACEMENT (One piece)	0.3
516252 00	FRONT DOOR BELT LINE MOULDING ··· REMOVAL AND INSTALLATION (One side)	0.3
516252 10	FRONT DOOR BELT LINE MOULDING ··· REPLACEMENT (One side)	0.3
516253 00	FRONT DOOR PROTECTOR MOULDING ··· REMOVAL AND INSTALLATION (One sid	0.5
516253 10	FRONT DOOR PROTECTOR MOULDING ··· REPLACEMENT (One side)	0.5
516262 00	REAR DOOR BELT LINE MOULDING ··· REMOVAL AND INSTALLATION (One side)	0.3
516262 10	REAR DOOR BELT LINE MOULDING ··· REPLACEMENT (One side)	0.3

CODE	DESCRIPTION	KG0W KH0W
516263 00	REAR DOOR PROTECTOR MOULDING ··· REMOVAL AND INSTALLATION (One side	0.5
516263 10	REAR DOOR PROTECTOR MOULDING ··· REPLACEMENT (One side)	0.5
516411 00	FRONT MARK ··· REMOVAL AND INSTALLATION (One piece)	0.3
516411 10	FRONT MARK ··· REPLACEMENT (One piece)	0.3
516421 00	REAR MARK ··· REMOVAL AND INSTALLATION (One piece)	0.2
516421 10	REAR MARK ··· REPLACEMENT (One piece)	0.2
516461 00	FRONT DOOR SASH BLACK OUT TAPE (OUTSIDE) ··· REMOVAL AND INSTALLATI	1.1
516461 10	FRONT DOOR SASH BLACK OUT TAPE (OUTSIDE) ··· REPLACEMENT (One side)	1.1
516463 00	REAR DOOR SASH BLACK OUT TAPE (OUTSIDE) ··· REMOVAL AND INSTALLATIO	1.5
516463 10	REAR DOOR SASH BLACK OUT TAPE (OUTSIDE) ··· REPLACEMENT (One side)	1.5
516465 00	CENTER PILLAR BLACK OUT TAPE ··· REMOVAL AND INSTALLATION (One side)	0.3
516465 10	CENTER PILLAR BLACK OUT TAPE ··· REPLACEMENT (One side)	0.3
517011 00	FRONT MUDGUARD ··· REMOVAL AND INSTALLATION (One side)	0.4
517011 10	FRONT MUDGUARD ··· REPLACEMENT (One side)	0.4
517015 00	REAR MUDGUARD ··· REMOVAL AND INSTALLATION (One side)	0.7
517015 10	REAR MUDGUARD ··· REPLACEMENT (One side)	0.7
517033 00	SIDE STEP ··· REMOVAL AND INSTALLATION (One side)	1.0
517033 10	SIDE STEP ··· REPLACEMENT (One side)	1.0
517034 00	SIDE STEP COVER ··· REMOVAL AND INSTALLATION (One side)	0.9
517034 10	SIDE STEP COVER ··· REPLACEMENT (One side)	0.9
517043 00	ROOF RAIL ASSEMBLY ··· REMOVAL AND INSTALLATION	1.9
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
517043 10	ROOF RAIL ASSEMBLY ··· REPLACEMENT	1.9
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
518101 00	WIPER MOTOR (FRONT WINDOW) ··· REMOVAL AND INSTALLATION	0.6
518101 10	WIPER MOTOR (FRONT WINDOW) ··· REPLACEMENT	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
518102 00	WIPER MOTOR (REAR WINDOW) ··· REMOVAL AND INSTALLATION	0.4
518102 10	WIPER MOTOR (REAR WINDOW) ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
518111 00	WASHER MOTOR (FRONT WINDOW) ··· REMOVAL AND INSTALLATION	0.5
518111 10	WASHER MOTOR (FRONT WINDOW) ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
518113 00	WASHER MOTOR (HEADLAMP) ··· REMOVAL AND INSTALLATION	0.5
518113 10	WASHER MOTOR (HEADLAMP) ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
518201 00	WIPER SWITCH (FRONT WINDOW) ··· REMOVAL AND INSTALLATION	0.3
518201 10	WIPER SWITCH (FRONT WINDOW) ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
518241 00	REMOTE CONTROL MIRROR SWITCH ··· REMOVAL AND INSTALLATION	0.3
518241 10	REMOTE CONTROL MIRROR SWITCH ··· REPLACEMENT	0.3
518421 00	HEADLAMP WASHER CONTROL RELAY ··· REMOVAL AND INSTALLATION	0.2
518421 10	HEADLAMP WASHER CONTROL RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
521120 00	FRONT SEAT CUSHION ASSEMBLY (DRIVER) ··· REMOVAL AND INSTALLATION	0.8
521120 10	FRONT SEAT CUSHION ASSEMBLY (DRIVER) ··· REPLACEMENT	0.8
521121 00	FRONT SEAT CUSHION COVER (DRIVER) ··· REMOVAL AND INSTALLATION	0.9

CODE	DESCRIPTION	KG0W KH0W
521121 10	FRONT SEAT CUSHION COVER (DRIVER) ··· REPLACEMENT	0.9
521130 00	FRONT SEAT BACK ASSEMBLY (DRIVER) ··· REMOVAL AND INSTALLATION	0.6
521130 10	FRONT SEAT BACK ASSEMBLY (DRIVER) ··· REPLACEMENT	0.6
521131 00	FRONT SEAT BACK COVER (DRIVER) ··· REMOVAL AND INSTALLATION	0.8
521131 10	FRONT SEAT BACK COVER (DRIVER) ··· REPLACEMENT	0.8
521141 00	FRONT SEAT HEAD RESTRAINT (DRIVER) ··· REMOVAL AND INSTALLATION	0.2
521141 10	FRONT SEAT HEAD RESTRAINT (DRIVER) ··· REPLACEMENT	0.2
521152 00	FRONT SEAT SLIDE ADJUSTER (DRIVER) ··· REMOVAL AND INSTALLATION	1.0
521152 10	FRONT SEAT SLIDE ADJUSTER (DRIVER) ··· REPLACEMENT	1.0
521220 00	FRONT SEAT CUSHION ASSEMBLY (PASSENGER) ··· REMOVAL AND INSTALLATIC	0.7
521220 10	FRONT SEAT CUSHION ASSEMBLY (PASSENGER) ··· REPLACEMENT	0.7
521221 00	FRONT SEAT CUSHION COVER (PASSENGER) ··· REMOVAL AND INSTALLATION	0.8
521221 10	FRONT SEAT CUSHION COVER (PASSENGER) ··· REPLACEMENT	0.8
521230 00	FRONT SEAT BACK ASSEMBLY (PASSENGER) ··· REMOVAL AND INSTALLATION	0.6
521230 10	FRONT SEAT BACK ASSEMBLY (PASSENGER) ··· REPLACEMENT	0.6
521231 00	FRONT SEAT BACK COVER (PASSENGER) ··· REMOVAL AND INSTALLATION	0.8
521231 10	FRONT SEAT BACK COVER (PASSENGER) ··· REPLACEMENT	0.8
521241 00	FRONT SEAT HEAD RESTRAINT (PASSENGER) ··· REMOVAL AND INSTALLATION	0.2
521241 10	FRONT SEAT HEAD RESTRAINT (PASSENGER) ··· REPLACEMENT	0.2
521252 00	FRONT SEAT SLIDE ADJUSTER (PASSENGER) ··· REMOVAL AND INSTALLATION	0.9
521252 10	FRONT SEAT SLIDE ADJUSTER (PASSENGER) ··· REPLACEMENT	0.9
521520 00	REAR SEAT CUSHION ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.8
521520 80	REAR SEAT CUSHION ASSEMBLY (LEFT SIDE) ··· REPLACEMENT	0.8
521520 82	REAR SEAT CUSHION ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT	0.7
521521 00	REAR SEAT CUSHION COVER ··· REMOVAL AND INSTALLATION (One piece)	1.2
521521 80	REAR SEAT CUSHION COVER (LEFT SIDE) ··· REPLACEMENT	1.2
521521 82	REAR SEAT CUSHION COVER (RIGHT SIDE) ··· REPLACEMENT	1.1
521530 00	REAR SEAT BACK ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.8
521530 80	REAR SEAT BACK ASSEMBLY (LEFT SIDE) ··· REPLACEMENT	0.8
521530 82	REAR SEAT BACK ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT	0.8
521531 00	REAR SEAT BACK COVER ··· REMOVAL AND INSTALLATION (One piece)	1.3
521531 80	REAR SEAT BACK COVER (LEFT SIDE) ··· REPLACEMENT	1.3
521531 82	REAR SEAT BACK COVER (RIGHT SIDE) ··· REPLACEMENT	1.2
521532 00	REAR SEAT BACK ARMREST ··· REMOVAL AND INSTALLATION (One piece)	0.3
521532 10	REAR SEAT BACK ARMREST ··· REPLACEMENT (One piece)	0.3
521541 00	REAR SEAT HEAD RESTRAINT ··· REMOVAL AND INSTALLATION (One piece)	0.2
521541 10	REAR SEAT HEAD RESTRAINT ··· REPLACEMENT (One piece)	0.2
521552 00	REAR SEAT SLIDE ADJUSTER ··· REMOVAL AND INSTALLATION (One piece)	1.2
521552 80	REAR SEAT SLIDE ADJUSTER (LEFT SIDE) ··· REPLACEMENT	1.2
521552 82	REAR SEAT SLIDE ADJUSTER (RIGHT SIDE) ··· REPLACEMENT	1.0
521556 00	REAR SEAT CUSHION CONTROL CABLE ··· REMOVAL AND INSTALLATION	1.0
521556 80	REAR SEAT CUSHION CONTROL CABLE (LEFT SIDE) ··· REPLACEMENT	1.0
521556 82	REAR SEAT CUSHION CONTROL CABLE (RIGHT SIDE) ··· REPLACEMENT	0.9
521557 00	REAR SEAT BACK CONTROL CABLE ··· REMOVAL AND INSTALLATION (One piece	1.6
521557 80	REAR SEAT BACK CONTROL CABLE (LEFT SIDE) ··· REPLACEMENT	1.6
521557 82	REAR SEAT BACK CONTROL CABLE (RIGHT SIDE) ··· REPLACEMENT	1.4
521620 00	THIRD SEAT CUSHION ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.8
521620 10	THIRD SEAT CUSHION ASSEMBLY ··· REPLACEMENT (One piece)	0.8
521621 00	THIRD SEAT CUSHION COVER ··· REMOVAL AND INSTALLATION (One piece)	1.3
521621 10	THIRD SEAT CUSHION COVER ··· REPLACEMENT (One piece)	1.3
521630 00	THIRD SEAT BACK ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.8
521630 10	THIRD SEAT BACK ASSEMBLY ··· REPLACEMENT (One piece)	0.8
521631 00	THIRD SEAT BACK COVER ··· REMOVAL AND INSTALLATION (One piece)	1.2
521631 10	THIRD SEAT BACK COVER ··· REPLACEMENT (One piece)	1.2
521641 00	THIRD SEAT HEAD RESTRAINT ··· REMOVAL AND INSTALLATION (One piece)	0.3

CODE	DESCRIPTION	KG0W KH0W
521641 10	THIRD SEAT HEAD RESTRAINT ··· REPLACEMENT (One piece)	0.3
521651 00	THIRD SEAT RECLINING ADJUSTER ··· REMOVAL AND INSTALLATION (One piece)	1.1
521651 10	THIRD SEAT RECLINING ADJUSTER ··· REPLACEMENT (One piece)	1.1
521652 00	THIRD SEAT CUSHION LATCH ··· REMOVAL AND INSTALLATION (One piece)	0.3
521652 10	THIRD SEAT CUSHION LATCH ··· REPLACEMENT (One piece)	0.3
521657 00	THIRD SEAT BACK CONTROL CABLE ··· REMOVAL AND INSTALLATION (One piece	1.1
521657 10	THIRD SEAT BACK CONTROL CABLE ··· REPLACEMENT (One piece)	1.1
522011 00	FRONT SEAT BELT RETRACTOR (DRIVER) ··· REMOVAL AND INSTALLATION	0.4
522011 10	FRONT SEAT BELT RETRACTOR (DRIVER) ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Pre-tensioner (squib) ··· inspection by multi-use tester	0.2
522012 00	FRONT SEAT BELT BUCKLE STALK (DRIVER) ··· REMOVAL AND INSTALLATION	0.4
522012 10	FRONT SEAT BELT BUCKLE STALK (DRIVER) ··· REPLACEMENT	0.4
522013 00	FRONT SEAT BELT ANCHOR PLATE ··· REMOVAL AND INSTALLATION	0.4
522013 10	FRONT SEAT BELT ANCHOR PLATE ··· REPLACEMENT	0.4
522021 00	FRONT SEAT BELT RETRACTOR (PASSENGER) ··· REMOVAL AND INSTALLATION	0.4
522021 10	FRONT SEAT BELT RETRACTOR (PASSENGER) ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Pre-tensioner (squib) ··· inspection by multi-use tester	0.2
522022 00	FRONT SEAT BELT BUCKLE STALK (PASSENGER) ··· REMOVAL AND INSTALLATI	0.4
522022 10	FRONT SEAT BELT BUCKLE STALK (PASSENGER) ··· REPLACEMENT	0.4
522023 00	FRONT SEAT BELT ANCHOR PLATE (PASSENGER) ··· REMOVAL AND INSTALLATI	0.4
522023 10	FRONT SEAT BELT ANCHOR PLATE (PASSENGER) ··· REPLACEMENT	0.4
522052 00	REAR (SECOND) SEAT BELT RETRACTOR ··· REMOVAL AND INSTALLATION (One	0.5
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
522052 10	REAR (SECOND) SEAT BELT RETRACTOR ··· REPLACEMENT (One piece)	0.5
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
522053 00	REAR (SECOND) SEAT BELT BUCKLE STALK ··· REMOVAL AND INSTALLATION (O	0.9
522053 80	REAR (SECOND) SEAT BELT BUCKLE STALK (LEFT SIDE) ··· REPLACEMENT	0.9
522053 82	REAR (SECOND) SEAT BELT BUCKLE STALK (RIGHT SIDE) ··· REPLACEMENT	0.8
522061 00	THIRD SEAT BELT RETRACTOR ··· REMOVAL AND INSTALLATION (One piece)	1.0
522061 10	THIRD SEAT BELT RETRACTOR ··· REPLACEMENT (One piece)	1.0
522062 00	THIRD SEAT BELT BUCKLE STALK ··· REMOVAL AND INSTALLATION (One piece)	0.3
522062 10	THIRD SEAT BELT BUCKLE STALK ··· REPLACEMENT (One piece)	0.3
522080 00	REAR SEAT BELT ASSEMBLY (CENTER) ··· REMOVAL AND INSTALLATION (One pi	0.9
522080 10	REAR SEAT BELT ASSEMBLY (CENTER) ··· REPLACEMENT (One piece)	0.9
522081 00	REAR (SECOND) SEAT BELT RETRACTOR (CENTER) ··· REMOVAL AND INSTALLA	1.9
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
522081 10	REAR (SECOND) SEAT BELT RETRACTOR (CENTER) ··· REPLACEMENT	1.9
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
522082 00	REAR (SECOND) SEAT BELT BUCKLE STALK (CENTER) ··· REMOVAL AND INSTAL	0.7
522082 10	REAR (SECOND) SEAT BELT BUCKLE STALK (CENTER) ··· REPLACEMENT	0.7
523110 00	INSTRUMENT PANEL ASSEMBLY ··· REMOVAL AND INSTALLATION	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
523110 10	INSTRUMENT PANEL ASSEMBLY ··· REPLACEMENT	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
523111 00	INSTRUMENT PANEL ··· REMOVAL AND INSTALLATION	1.6
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2

CODE	DESCRIPTION	KG0W KH0W
523111 10	INSTRUMENT PANEL ··· REPLACEMENT	1.6
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
523114 00	INSTRUMENT PANEL METER HOOD (COVER) ··· REMOVAL AND INSTALLATION	0.4
523114 10	INSTRUMENT PANEL METER HOOD (COVER) ··· REPLACEMENT	0.4
523116 00	INSTRUMENT PANEL LOWER COVER ··· REMOVAL AND INSTALLATION	0.4
523116 10	INSTRUMENT PANEL LOWER COVER ··· REPLACEMENT	0.4
523130 00	INSTRUMENT PANEL GLOVEBOX ASSEMBLY ··· REMOVAL AND INSTALLATION	0.2
523130 10	INSTRUMENT PANEL GLOVEBOX ASSEMBLY ··· REPLACEMENT	0.2
523132 00	INSTRUMENT PANEL GLOVEBOX LOCK & STRIKER ··· REMOVAL AND INSTALLATI	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
523132 10	INSTRUMENT PANEL GLOVEBOX LOCK & STRIKER ··· REPLACEMENT	1.3
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
523137 00	INSTRUMENT PANEL GLOVEBOX OUTER CASE ··· REMOVAL AND INSTALLATION	0.3
523137 10	INSTRUMENT PANEL GLOVEBOX OUTER CASE ··· REPLACEMENT	0.3
523140 00	INSTRUMENT PANEL ASHTRAY ··· REMOVAL AND INSTALLATION	0.2
523140 10	INSTRUMENT PANEL ASHTRAY ··· REPLACEMENT	0.2
523161 00	INSTRUMENT PANEL OUTLET (GARNISH) (CENTER) ··· REMOVAL AND INSTALLAT	0.6
	[Additional operation]	
	A1 ··· Heater control cable - R&I	0.2
523161 10	INSTRUMENT PANEL OUTLET (GARNISH) (CENTER) ··· REPLACEMENT (One piece)	0.6
	[Additional operation]	
	A1 ··· Heater control cable - R&I	0.2
523162 00	INSTRUMENT PANEL OUTLET (GARNISH) (SIDE) ··· REMOVAL AND INSTALLATION	1.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
523162 10	INSTRUMENT PANEL OUTLET (GARNISH) (SIDE) ··· REPLACEMENT (One piece)	1.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
523311 00	FLOOR CONSOLE (FRONT) ··· REMOVAL AND INSTALLATION	0.5
523311 10	FLOOR CONSOLE (FRONT) ··· REPLACEMENT	0.5
523312 00	FLOOR CONSOLE (REAR) ··· REMOVAL AND INSTALLATION	0.4
523312 10	FLOOR CONSOLE (REAR) ··· REPLACEMENT	0.4
523313 00	FLOOR CONSOLE PANEL ··· REMOVAL AND INSTALLATION	0.5
523313 10	FLOOR CONSOLE PANEL ··· REPLACEMENT	0.5
523345 00	FLOOR CONSOLE PARCEL (ACCESSORY) BOX ··· REMOVAL AND INSTALLATION	0.4
523345 10	FLOOR CONSOLE PARCEL (ACCESSORY) BOX ··· REPLACEMENT	0.4
523346 00	FLOOR CONSOLE PARCEL (ACCESSORY) BOX LID ··· REMOVAL AND INSTALLATI	0.4
523346 10	FLOOR CONSOLE PARCEL (ACCESSORY) BOX LID ··· REPLACEMENT	0.4
524101 00	HEADLINING ··· REMOVAL AND INSTALLATION	1.8
	[Additional operation]	
	A2 ··· Third seat R&I	0.7
524101 10	HEADLINING ··· REPLACEMENT	1.8
	[Additional operation]	
	A2 ··· Third seat R&I	0.7
524110 00	FLOOR CARPET (MAT) ASSEMBLY ··· REMOVAL AND INSTALLATION (All)	1.2
524110 10	FLOOR CARPET (MAT) ASSEMBLY ··· REPLACEMENT (All)	1.2
524113 00	TRUNK (CARGO) FLOOR CARPET (MAT) ··· REMOVAL AND INSTALLATION	0.7
	[Additional operation]	
	A1 ··· Third seat R&I	0.6
524113 10	TRUNK (CARGO) FLOOR CARPET (MAT) ··· REPLACEMENT	0.7
	[Additional operation]	
	A1 ··· Third seat R&I	0.6

CODE	DESCRIPTION	KG0W KH0W
524221 00	REAR SHELF TRIM (CENTER) ··· REMOVAL AND INSTALLATION	0.2
524221 10	REAR SHELF TRIM (CENTER) ··· REPLACEMENT	0.2
524224 00	REAR END TRIM ··· REMOVAL AND INSTALLATION	0.2
	[Additional operation]	
	A1 ··· Cargo floor box R&I	0.2
524224 10	REAR END TRIM ··· REPLACEMENT	0.2
	[Additional operation]	
	A1 ··· Cargo floor box R&I	0.2
524231 00	FRONT PILLAR TRIM ··· REMOVAL AND INSTALLATION (One piece)	0.3
524231 10	FRONT PILLAR TRIM ··· REPLACEMENT (One piece)	0.3
524236 00	SCUFF PLATE (FRONT) ··· REMOVAL AND INSTALLATION (One piece)	0.2
524236 10	SCUFF PLATE (FRONT) ··· REPLACEMENT (One piece)	0.2
524237 00	SCUFF PLATE (REAR) ··· REMOVAL AND INSTALLATION (One piece)	0.2
524237 10	SCUFF PLATE (REAR) ··· REPLACEMENT (One piece)	0.2
524249 00	QUARTER TRIM (UPPER) ··· REMOVAL AND INSTALLATION (One piece)	0.6
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
524249 10	QUARTER TRIM (UPPER) ··· REPLACEMENT (One piece)	0.6
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
524250 00	QUARTER TRIM (LOWER) ··· REMOVAL AND INSTALLATION (One piece)	0.5
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
524250 10	QUARTER TRIM (LOWER) ··· REPLACEMENT (One piece)	0.5
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
524260 00	FRONT DOOR TRIM ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.4
524260 10	FRONT DOOR TRIM ASSEMBLY ··· REPLACEMENT (One piece)	0.4
524270 00	REAR (SLIDE) DOOR TRIM ASSEMBLY ··· REMOVAL AND INSTALLATION (One piec	0.4
524270 10	REAR (SLIDE) DOOR TRIM ASSEMBLY ··· REPLACEMENT (One piece)	0.4
524281 00	TAILGATE (BACK DOOR) TRIM (UPPER) ··· REMOVAL AND INSTALLATION (One pie	0.2
524281 10	TAILGATE (BACK DOOR) TRIM (UPPER) ··· REPLACEMENT (One piece)	0.2
524282 00	TAILGATE (BACK DOOR) TRIM (LOWER) ··· REMOVAL AND INSTALLATION	0.3
524282 10	TAILGATE (BACK DOOR) TRIM (LOWER) ··· REPLACEMENT	0.3
524283 00	TAILGATE (BACK DOOR) TRIM (SIDE) ··· REMOVAL AND INSTALLATION (One piece	0.3
524283 10	TAILGATE (BACK DOOR) TRIM (SIDE) ··· REPLACEMENT (One piece)	0.3
524311 00	CENTER PILLAR TRIM (UPPER) ··· REMOVAL AND INSTALLATION (One side)	0.4
524311 10	CENTER PILLAR TRIM (UPPER) ··· REPLACEMENT (One side)	0.4
524312 00	CENTER PILLAR TRIM (LOWER) ··· REMOVAL AND INSTALLATION (One side)	0.3
524312 10	CENTER PILLAR TRIM (LOWER) ··· REPLACEMENT (One side)	0.3
525010 00	SRS MODULE ··· REMOVAL AND INSTALLATION	0.4
525010 10	SRS MODULE ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
525020 00	SRS MODULE (PASSENGER SIDE) ··· REMOVAL AND INSTALLATION	0.4
525020 10	SRS MODULE (PASSENGER SIDE) ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
525030 00	CURTAIN AIR BAG MODULE ··· REMOVAL AND INSTALLATION (One piece)	2.0
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
	01 ··· Per 1 pc.	0.2
525030 10	CURTAIN AIR BAG MODULE ··· REPLACEMENT (One piece)	2.0
	[Additional operation]	
	A1 ··· Third seat R&I	0.7

CODE	DESCRIPTION	KG0W KH0W
	A9 ··· Inspection by multi-use tester	0.2
	01 ··· Per 1 pc.	0.2
527074 00	ASSIST GRIP ··· REMOVAL AND INSTALLATION (One piece)	0.3
527074 10	ASSIST GRIP ··· REPLACEMENT (One piece)	0.3
527077 00	ROOM MIRROR ··· REMOVAL AND INSTALLATION	0.2
527077 10	ROOM MIRROR ··· REPLACEMENT	0.2
527078 00	SUN VISOR & SUNSHADE ··· REMOVAL AND INSTALLATION (One piece)	0.3
527078 10	SUN VISOR & SUNSHADE ··· REPLACEMENT (One piece)	0.3
528201 00	FRONT SEAT HEATER SWITCH ··· REMOVAL AND INSTALLATION (One piece)	0.3
528201 10	FRONT SEAT HEATER SWITCH ··· REPLACEMENT (One piece)	0.3
528211 00	POWER SEAT SWITCH ··· REMOVAL AND INSTALLATION (One piece)	0.4
528211 10	POWER SEAT SWITCH ··· REPLACEMENT (One piece)	0.4
528271 00	PASSENGER SIDE AIR BAG CUT OFF SWITCH ··· REMOVAL AND INSTALLATION	0.4
528271 10	PASSENGER SIDE AIR BAG CUT OFF SWITCH ··· REPLACEMENT	0.4
528311 00	FRONT IMPACT SENSOR ··· REMOVAL AND INSTALLATION (One piece)	0.4
528311 84	FRONT IMPACT SENSOR (RIGHT SIDE) ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
528311 86	FRONT IMPACT SENSOR (LEFT SIDE) ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
528321 00	SIDE IMPACT SENSOR ··· REMOVAL AND INSTALLATION (One piece)	0.4
528321 10	SIDE IMPACT SENSOR ··· REPLACEMENT (One piece)	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
528421 00	HEATED SEAT RELAY ··· REMOVAL AND INSTALLATION	0.2
528421 10	HEATED SEAT RELAY ··· REPLACEMENT	0.2
528511 00	SRS DIAGNOSIS UNIT ··· REMOVAL AND INSTALLATION	0.6
	[Additional operation]	
	A2 ··· Rear heater air duct - R&I	0.6
528511 10	SRS DIAGNOSIS UNIT ··· REPLACEMENT	0.6
	[Additional operation]	
	A2 ··· Rear heater air duct - R&I	0.6
	A9 ··· Inspection by multi-use tester	0.2
541001 00	FRONT EXTERIOR LAMP BULB ··· REMOVAL AND INSTALLATION (One piece)	0.2
541001 10	FRONT EXTERIOR LAMP BULB ··· REPLACEMENT (One piece)	0.2
541010 93	HEADLAMP ··· AIMING	0.3
541011 00	HEADLAMP UNIT ··· REMOVAL AND INSTALLATION (One piece)	1.1
541011 10	HEADLAMP UNIT ··· REPLACEMENT (One piece)	1.1
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
541013 00	HEADLAMP BULB ··· REMOVAL AND INSTALLATION (One piece)	0.3
	[Additional operation]	
	A1 ··· Headlamp unit R&I (for discharge headlamp)	0.9
541013 10	HEADLAMP BULB ··· REPLACEMENT (One piece)	0.3
	[Additional operation]	
	A1 ··· Headlamp unit R&I (for discharge headlamp)	0.9
	A9 ··· Inspection by multi-use tester	0.2
541040 00	FRONT SIDE TURN SIGNAL LAMP ASSEMBLY ··· REMOVAL AND INSTALLATION (C	0.3
541040 10	FRONT SIDE TURN SIGNAL LAMP ASSEMBLY ··· REPLACEMENT (One side)	0.3
541070 00	FRONT FOG LAMP ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.3
541070 10	FRONT FOG LAMP ASSEMBLY ··· REPLACEMENT (One side)	0.3
541070 93	FOG LAMP ··· AIMING	0.2
541305 00	TAILGATE COMBINATION LAMP ASSEMBLY ··· REMOVAL AND INSTALLATION (On	0.3
541305 10	TAILGATE COMBINATION LAMP ASSEMBLY ··· REPLACEMENT (One side)	0.3

CODE	DESCRIPTION	KG0W KH0W
541310 00	REAR COMBINATION LAMP ASSEMBLY ··· REMOVAL AND INSTALLATION (One sid	0.3
541310 10	REAR COMBINATION LAMP ASSEMBLY ··· REPLACEMENT (One side)	0.3
541311 00	REAR COMBINATION LAMP UNIT ··· REMOVAL AND INSTALLATION (One side)	0.3
541311 10	REAR COMBINATION LAMP UNIT ··· REPLACEMENT (One side)	0.3
541315 00	REAR COMBINATION LAMP SOCKET ASSEMBLY ··· REMOVAL AND INSTALLATION	0.3
541315 10	REAR COMBINATION LAMP SOCKET ASSEMBLY ··· REPLACEMENT (One side)	0.3
541340 00	BACKUP LAMP ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.7
541340 10	BACKUP LAMP ASSEMBLY ··· REPLACEMENT (One piece)	0.7
541350 00	LICENCE PLATE LAMP ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.2
541350 10	LICENCE PLATE LAMP ASSEMBLY ··· REPLACEMENT (One piece)	0.2
541380 00	REAR FOG LAMP ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.7
541380 10	REAR FOG LAMP ASSEMBLY ··· REPLACEMENT (One piece)	0.7
541390 00	HIGH MOUNT STOP LAMP ··· REMOVAL AND INSTALLATION	0.3
541390 10	HIGH MOUNT STOP LAMP ··· REPLACEMENT	0.3
541801 00	INTERIOR LAMP BULB ··· REMOVAL AND INSTALLATION (One piece)	0.2
541801 10	INTERIOR LAMP BULB ··· REPLACEMENT (One piece)	0.2
541810 00	ROOM LAMP ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.3
541810 10	ROOM LAMP ASSEMBLY ··· REPLACEMENT (One piece)	0.3
541815 00	MAP LAMP ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.3
541815 10	MAP LAMP ASSEMBLY ··· REPLACEMENT (One piece)	0.3
541817 00	MAP LAMP LENS ··· REMOVAL AND INSTALLATION (One piece)	0.2
541817 10	MAP LAMP LENS ··· REPLACEMENT (One piece)	0.2
541822 00	DOOR LAMP LENS ··· REMOVAL AND INSTALLATION (One piece)	0.2
541822 10	DOOR LAMP LENS ··· REPLACEMENT (One piece)	0.2
541830 00	CARGO ROOM (LUGGAGE COMPARTMENT) LAMP ASSEMBLY ··· REMOVAL AND I	0.3
541830 10	CARGO ROOM (LUGGAGE COMPARTMENT) LAMP ASSEMBLY ··· REPLACEMENT (	0.3
541832 00	CARGO ROOM (LUGGAGE COMPARTMENT) LAMP LENS ··· REMOVAL AND INSTAL	0.2
541832 10	CARGO ROOM (LUGGAGE COMPARTMENT) LAMP LENS ··· REPLACEMENT (One p	0.2
542001 00	BULB FOR METER & GAUGE ··· REMOVAL AND INSTALLATION	0.5
542001 10	BULB FOR METER & GAUGE ··· REPLACEMENT	0.5
542010 00	COMBINATION METER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.4
542010 10	COMBINATION METER ASSEMBLY ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
542026 00	CENTER DISPLAY ··· REMOVAL AND INSTALLATION	0.3
542026 10	CENTER DISPLAY ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
542465 00	HEAD LAMP AUTO LEVELING INDICATOR ··· REMOVAL AND INSTALLATION	0.4
542465 10	HEAD LAMP AUTO LEVELING INDICATOR ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
542471 00	PASSENGER AIR BAG OFF INDICATOR LAMP ··· REMOVAL AND INSTALLATION	0.7
542471 10	PASSENGER AIR BAG OFF INDICATOR LAMP ··· REPLACEMENT	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
543010 00	BATTERY ··· REMOVAL AND INSTALLATION (One piece)	0.3
543010 10	BATTERY ··· REPLACEMENT (One piece)	0.3
	[Additional operation]	
	A9 ··· Test & inspection	0.2
543010 52	BATTERY ··· ELECTRICAL CHARGE (One piece)	0.2
543501 00	FUSE ··· REMOVAL AND INSTALLATION	0.2
543501 10	FUSE ··· REPLACEMENT	0.2
543510 00	BATTERY CABLE ··· REMOVAL AND INSTALLATION	0.7
543510 10	BATTERY CABLE ··· REPLACEMENT	0.7

CODE	DESCRIPTION	KG0W KH0W
543530 00	FUSIBLE LINK ASSEMBLY ··· REMOVAL AND INSTALLATION	0.2
543530 10	FUSIBLE LINK ASSEMBLY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
543541 00	INSTRUMENT PANEL HARNESS (WIRING HARNESS A) ··· REMOVAL AND INSTALLA	2.5
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
543541 10	INSTRUMENT PANEL HARNESS (WIRING HARNESS A) ··· REPLACEMENT	2.5
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
543542 00	BODY (FRONT) HARNESS (WIRING HARNESS B) ··· REMOVAL AND INSTALLATION	2.8
543542 10	BODY (FRONT) HARNESS (WIRING HARNESS B) ··· REPLACEMENT	2.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
543543 00	BODY (REAR) HARNESS (WIRING HARNESS C) ··· REMOVAL AND INSTALLATION	4.3
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
543543 10	BODY (REAR) HARNESS (WIRING HARNESS C) ··· REPLACEMENT	4.3
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
	A9 ··· Inspection by multi-use tester	0.2
543544 00	ROOF HARNESS ··· REMOVAL AND INSTALLATION	2.1
	[Additional operation]	
	A2 ··· Third seat R&I	0.7
	A3 ··· Curtain air bag module - R&I	0.3
543544 10	ROOF HARNESS ··· REPLACEMENT	2.1
	[Additional operation]	
	A2 ··· Third seat R&I	0.7
	A3 ··· Curtain air bag module - R&I	0.3
	A9 ··· Inspection by multi-use tester	0.2
543555 00	REAR GATE HARNESS ··· REMOVAL AND INSTALLATION	0.5
543555 10	REAR GATE HARNESS ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
543563 00	ENGINE CONTROL HARNESS ··· REMOVAL AND INSTALLATION	4.8
	[Additional operation]	
	A2 ··· Rear heater duct R&I	0.6
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
543563 10	ENGINE CONTROL HARNESS ··· REPLACEMENT	4.8
	[Additional operation]	
	A2 ··· Rear heater duct R&I	0.6
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
543566 00	FRONT DOOR HARNESS ··· REMOVAL AND INSTALLATION (One side)	0.7
543566 10	FRONT DOOR HARNESS ··· REPLACEMENT (One side)	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
543567 00	REAR DOOR HARNESS ··· REMOVAL AND INSTALLATION (One side)	0.6
543567 10	REAR DOOR HARNESS ··· REPLACEMENT (One side)	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
544011 00	HORN ··· REMOVAL AND INSTALLATION (One piece)	0.3
544011 10	HORN ··· REPLACEMENT (One piece)	0.3
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A9 ··· Inspection by multi-use tester	0.2
545013 00	AUDIO (CASSETTE STEREO ASSEMBLY) ··· REMOVAL AND INSTALLATION	0.3
545013 10	AUDIO (CASSETTE STEREO ASSEMBLY) ··· REPLACEMENT	0.3
545014 00	AUDIO POWER AMPLIFIER ··· REMOVAL AND INSTALLATION	0.4
	[Additional operation]	
	A1 ··· Front seat assy - R&I	0.2
545014 10	AUDIO POWER AMPLIFIER ··· REPLACEMENT	0.4
	[Additional operation]	
	A1 ··· Front seat assy - R&I	0.2
	A9 ··· Inspection by multi-use tester	0.2
545033 00	DOOR SPEAKER ··· REMOVAL AND INSTALLATION (One piece)	0.4
545033 10	DOOR SPEAKER ··· REPLACEMENT (One piece)	0.4
545043 00	REAR DOOR SPEAKER ··· REMOVAL AND INSTALLATION (One piece)	0.4
545043 10	REAR DOOR SPEAKER ··· REPLACEMENT (One piece)	0.4
545051 00	ANTENNA ASSEMBLY ··· REMOVAL AND INSTALLATION	1.8
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
545051 10	ANTENNA ASSEMBLY ··· REPLACEMENT	1.8
	[Additional operation]	
	A1 ··· Third seat R&I	0.7
545052 00	ANTENNA POLE ··· REMOVAL AND INSTALLATION	0.2
545052 10	ANTENNA POLE ··· REPLACEMENT	0.2
545055 00	ANTENNA FEEDER ··· REMOVAL AND INSTALLATION	2.4
	[Additional operation]	
	A2 ··· Third seat R&I	0.7
545055 10	ANTENNA FEEDER ··· REPLACEMENT	2.4
	[Additional operation]	
	A2 ··· Third seat R&I	0.7
545094 00	USB BOX ··· REMOVAL AND INSTALLATION	0.4
545094 10	USB BOX ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
547010 00	CLOCK ASSEMBLY ··· REMOVAL AND INSTALLATION	0.3
547010 10	CLOCK ASSEMBLY ··· REPLACEMENT	0.3
547015 00	CLOCK SPRING (SRS) ··· REMOVAL AND INSTALLATION	0.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
547015 10	CLOCK SPRING (SRS) ··· REPLACEMENT	0.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
547020 00	CIGARETTE LIGHTER ASSEMBLY ··· REMOVAL AND INSTALLATION (One piece)	0.3
547020 10	CIGARETTE LIGHTER ASSEMBLY ··· REPLACEMENT (One piece)	0.3
547025 25	REAR WINDOW DEFOGGER ··· REPAIR	0.6
547042 00	MICROPHONE ··· REMOVAL AND INSTALLATION	0.3
547042 10	MICROPHONE ··· REPLACEMENT	0.3
547046 00	HAND FREE REMOTE CONTROL SWITCH ··· REMOVAL AND INSTALLATION	0.3
547046 10	HAND FREE REMOTE CONTROL SWITCH ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
547047 00	HAND FREE MODULE ··· REMOVAL AND INSTALLATION	0.4
547047 10	HAND FREE MODULE ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
547053 00	NAVIGATION UNIT ··· REMOVAL AND INSTALLATION	0.4

CODE	DESCRIPTION	KG0W KH0W
547053 10	NAVIGATION UNIT ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
547054 00	GPS ANTENNA ··· REMOVAL AND INSTALLATION	0.4
547054 10	GPS ANTENNA ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
547067 00	AUDIO AND VIDEO ADAPTOR ··· REMOVAL AND INSTALLATION	0.3
547067 10	AUDIO AND VIDEO ADAPTOR ··· REPLACEMENT	0.3
547070 00	REAR VIEW MONITOR CAMERA ··· REMOVAL AND INSTALLATION	0.4
547070 10	REAR VIEW MONITOR CAMERA ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
547091 00	IMMOBILIZER KEY RING ANTENNA ··· REMOVAL AND INSTALLATION	0.6
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
547091 10	IMMOBILIZER KEY RING ANTENNA ··· REPLACEMENT	0.6
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
547092 00	IMMOBILIZER TRANSPONDER ··· REMOVAL AND INSTALLATION	0.3
547092 10	IMMOBILIZER TRANSPONDER ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548201 00	DOOR SWITCH ··· REMOVAL AND INSTALLATION (One piece)	0.2
548201 10	DOOR SWITCH ··· REPLACEMENT (One piece)	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548210 00	CORNER SENSOR SWITCH ··· REMOVAL AND INSTALLATION	0.3
548210 10	CORNER SENSOR SWITCH ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548211 00	COLUMN (COMBINATION, LEVER) SWITCH ··· REMOVAL AND INSTALLATION	0.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
548211 10	COLUMN (COMBINATION, LEVER) SWITCH ··· REPLACEMENT	0.5
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
548212 00	TURN SIGNAL & LIGHTING SWITCH ··· REMOVAL AND INSTALLATION	0.3
548212 10	TURN SIGNAL & LIGHTING SWITCH ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548215 00	HAZARD WARNING LAMP SWITCH ··· REMOVAL AND INSTALLATION	0.7
548215 10	HAZARD WARNING LAMP SWITCH ··· REPLACEMENT	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548261 00	IGNITION SWITCH / ELECTRIC MOTOR SWITCH ··· REMOVAL AND INSTALLATION	0.5
548261 10	IGNITION SWITCH / ELECTRIC MOTOR SWITCH ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548263 00	KEY REMINDER SWITCH ··· REMOVAL AND INSTALLATION	0.6
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
548263 10	KEY REMINDER SWITCH ··· REPLACEMENT	0.6

CODE	DESCRIPTION	KG0W KH0W
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
548266 00	HEADLAMP LEVELING SWITCH ··· REMOVAL AND INSTALLATION	0.4
548266 10	HEADLAMP LEVELING SWITCH ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548271 00	RADIO REMOTE CONTROL SWITCH ··· REMOVAL AND INSTALLATION	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
548271 10	RADIO REMOTE CONTROL SWITCH ··· REPLACEMENT	0.4
	[Additional operation]	
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
548311 00	AUTO LIGHTING CONTROL SENSOR ··· REMOVAL AND INSTALLATION	0.4
548311 10	AUTO LIGHTING CONTROL SENSOR ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548312 00	FRONT HEIGHT SENSOR (HEAD LAMP AUTO LEVELING) ··· REMOVAL AND INSTA	0.6
548312 10	FRONT HEIGHT SENSOR (HEAD LAMP AUTO LEVELING) ··· REPLACEMENT	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548313 00	REAR HEIGHT SENSOR (HEAD LAMP AUTO LEVELING) ··· REMOVAL AND INSTALL	0.5
548313 10	REAR HEIGHT SENSOR (HEAD LAMP AUTO LEVELING) ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548331 00	VEHICLE SPEED SENSOR ··· REMOVAL AND INSTALLATION	0.3
548331 10	VEHICLE SPEED SENSOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548341 00	AIR-THERMO SENSOR ··· REMOVAL AND INSTALLATION	0.3
548341 10	AIR-THERMO SENSOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548353 00	BACK SONAR SENSOR ··· REMOVAL AND INSTALLATION	0.3
548353 10	BACK SONAR SENSOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548356 00	CORNER SENSOR (REAR SIDE) ··· REMOVAL AND INSTALLATION (One piece)	0.7
548356 10	CORNER SENSOR (REAR SIDE) ··· REPLACEMENT	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548412 00	HEADLAMP LIGHTING RELAY ··· REMOVAL AND INSTALLATION	0.2
548412 10	HEADLAMP LIGHTING RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548421 00	FOG LAMP RELAY ··· REMOVAL AND INSTALLATION	0.2
548421 10	FOG LAMP RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548422 00	REAR FOG LAMP RELAY ··· REMOVAL AND INSTALLATION	0.2
548422 10	REAR FOG LAMP RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548461 00	HORN RELAY ··· REMOVAL AND INSTALLATION	0.2

CODE	DESCRIPTION	KG0W KH0W
548461 10	HORN RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548471 00	DEFOGGER RELAY ··· REMOVAL AND INSTALLATION	0.2
548471 10	DEFOGGER RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548481 00	ACCESSORY SOCKET RELAY ··· REMOVAL AND INSTALLATION	0.2
548481 10	ACCESSORY SOCKET RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548501 00	ETACS CONTROL UNIT ··· REMOVAL AND INSTALLATION	0.3
548501 10	ETACS CONTROL UNIT ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548515 00	HEAD LAMP AUTO LEVELING ECU ··· REMOVAL AND INSTALLATION	0.4
548515 10	HEAD LAMP AUTO LEVELING ECU ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548552 00	CORNER SENSOR CONTROL UNIT ··· REMOVAL AND INSTALLATION	0.5
548552 10	CORNER SENSOR CONTROL UNIT ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548571 00	IMMOBILIZER CONTROL UNIT ··· REMOVAL AND INSTALLATION	0.4
548571 10	IMMOBILIZER CONTROL UNIT ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548581 00	DISCHARGE HEADLAMP CONTROL UNIT ··· REMOVAL AND INSTALLATION (One p	1.2
548581 10	DISCHARGE HEADLAMP CONTROL UNIT ··· REPLACEMENT (One piece)	1.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
548921 00	CAN ADAPTOR ··· REMOVAL AND INSTALLATION	0.3
548921 10	CAN ADAPTOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
550000 90	REFRIGERANT CHARGE, AIR CONDITIONER	0.5
551110 00	FRONT HEATER ASSEMBLY ··· REMOVAL AND INSTALLATION	3.5
	[Additional operation]	
	A4 ··· Rear heater air duct - R&I	0.6
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
551110 10	FRONT HEATER ASSEMBLY ··· REPLACEMENT	3.5
	[Additional operation]	
	A4 ··· Rear heater air duct - R&I	0.6
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
551115 00	PTC HEATER ··· REMOVAL AND INSTALLATION	0.5
551115 10	PTC HEATER ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
551120 00	BLOWER ASSEMBLY ··· REMOVAL AND INSTALLATION	0.7
551120 10	BLOWER ASSEMBLY ··· REPLACEMENT	0.7
551510 00	AIR CONDITIONER UNIT ··· REMOVAL AND INSTALLATION	3.2
551510 10	AIR CONDITIONER UNIT ··· REPLACEMENT	3.2
551511 00	COOLER EVAPORATOR ASSEMBLY (FRONT) ··· REMOVAL AND INSTALLATION	2.8
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2

CODE	DESCRIPTION	KG0W KH0W
551511 10	COOLER EVAPORATOR ASSEMBLY (FRONT) ··· REPLACEMENT	2.8
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
551512 00	EXPANSION VALVE ··· REMOVAL AND INSTALLATION	2.5
	[Additional time allowance]	
	L1 ··· Left-hand drive	0.3
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
551512 10	EXPANSION VALVE ··· REPLACEMENT	2.5
	[Additional time allowance]	
	L1 ··· Left-hand drive	0.3
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
551610 00	AIR CONDITIONER UNIT (REAR) ··· REMOVAL AND INSTALLATION	1.3
	[Additional operation]	
	A2 ··· Third seat R&I	0.4
551610 10	AIR CONDITIONER UNIT (REAR) ··· REPLACEMENT	1.3
	[Additional operation]	
	A2 ··· Third seat R&I	0.4
551611 00	COOLER EVAPORATOR ASSEMBLY (REAR) ··· REMOVAL AND INSTALLATION	1.5
	[Additional operation]	
	A2 ··· Third seat R&I	0.4
551611 10	COOLER EVAPORATOR ASSEMBLY (REAR) ··· REPLACEMENT	1.5
	[Additional operation]	
	A2 ··· Third seat R&I	0.4
551612 00	EXPANSION VALVE (REAR) ··· REMOVAL AND INSTALLATION	1.5
	[Additional operation]	
	A2 ··· Third seat R&I	0.4
551612 10	EXPANSION VALVE (REAR) ··· REPLACEMENT	1.5
	[Additional operation]	
	A2 ··· Third seat R&I	0.4
552011 00	DEFROSTER DUCT ··· REMOVAL AND INSTALLATION	1.3
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
552011 10	DEFROSTER DUCT ··· REPLACEMENT	1.3
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
552016 00	SIDE DEFROSTER NOZZLE ··· REMOVAL AND INSTALLATION (One piece)	1.4
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
552016 10	SIDE DEFROSTER NOZZLE ··· REPLACEMENT (One piece)	1.4
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
552024 00	CENTER VENTILATOR AIR DUCT ··· REMOVAL AND INSTALLATION	1.3
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
552024 10	CENTER VENTILATOR AIR DUCT ··· REPLACEMENT	1.3
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
552026 00	REAR HEATER AIR DUCT ··· REMOVAL AND INSTALLATION	1.0
552026 10	REAR HEATER AIR DUCT ··· REPLACEMENT	1.0
552515 00	AIR PURIFIER FILTER ··· REMOVAL AND INSTALLATION	0.3
552515 10	AIR PURIFIER FILTER ··· REPLACEMENT	0.3
553110 00	COMPRESSOR ASSEMBLY ··· REMOVAL AND INSTALLATION	1.4
553110 10	COMPRESSOR ASSEMBLY ··· REPLACEMENT	1.4

CODE	DESCRIPTION	KG0W KH0W
553120 00	MAGNET CLUTCH ASSEMBLY ··· REMOVAL AND INSTALLATION	1.5
553120 10	MAGNET CLUTCH ASSEMBLY ··· REPLACEMENT	1.5
553143 00	TENSION PULLEY ··· REMOVAL AND INSTALLATION	0.3
553143 10	TENSION PULLEY ··· REPLACEMENT	0.3
553152 00	COMPRESSOR DRIVE BELT ··· REMOVAL AND INSTALLATION	0.3
553152 10	COMPRESSOR DRIVE BELT ··· REPLACEMENT	0.3
553152 40	COMPRESSOR DRIVE BELT ··· ADJUSTMENT	0.2
553210 00	FRONT CONDENSER ASSEMBLY ··· REMOVAL AND INSTALLATION	1.1
553210 10	FRONT CONDENSER ASSEMBLY ··· REPLACEMENT	1.1
554010 00	HEATER CONTROL ASSEMBLY ··· REMOVAL AND INSTALLATION	0.7
554010 10	HEATER CONTROL ASSEMBLY ··· REPLACEMENT	0.7
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
554011 00	HEATER CONTROL WIRE ··· REMOVAL AND INSTALLATION	0.8
554011 10	HEATER CONTROL WIRE ··· REPLACEMENT	0.8
555511 00	COOLER (DISCHARGE) HOSE ··· REMOVAL AND INSTALLATION (One piece)	1.1
555511 10	COOLER (DISCHARGE) HOSE ··· REPLACEMENT (One piece)	1.1
555512 00	COOLER (SUCTION) HOSE ··· REMOVAL AND INSTALLATION (One piece)	1.1
555512 10	COOLER (SUCTION) HOSE ··· REPLACEMENT (One piece)	1.1
555531 00	RECEIVER ··· REMOVAL AND INSTALLATION	0.9
555531 10	RECEIVER ··· REPLACEMENT	0.9
558101 00	FRONT BLOWER MOTOR ··· REMOVAL AND INSTALLATION	0.3
558101 10	FRONT BLOWER MOTOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558102 00	REAR BLOWER MOTOR ··· REMOVAL AND INSTALLATION	0.5
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
558102 10	REAR BLOWER MOTOR ··· REPLACEMENT	0.5
	[Additional operation]	
	A1 ··· Third seat R&I	0.4
	A9 ··· Inspection by multi-use tester	0.2
558111 00	CONDENSER FAN MOTOR ··· REMOVAL AND INSTALLATION	0.4
558111 10	CONDENSER FAN MOTOR ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558121 00	SUCTION PORT CHANGE OVER DAMPER MOTOR ··· REMOVAL AND INSTALLATIO	0.4
558121 10	SUCTION PORT CHANGE OVER DAMPER MOTOR ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558122 00	DISCHARGE PORT CHANGEOVER DAMPER MOTOR ··· REMOVAL AND INSTALLAT	0.5
558122 10	DISCHARGE PORT CHANGEOVER DAMPER MOTOR ··· REPLACEMENT	0.5
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558123 00	AIR MIX DAMPER CONTROL MOTOR ··· REMOVAL AND INSTALLATION	0.6
558123 10	AIR MIX DAMPER CONTROL MOTOR ··· REPLACEMENT	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558201 00	FRONT HEATER (BLOWER) SWITCH ··· REMOVAL AND INSTALLATION	0.8
558201 10	FRONT HEATER (BLOWER) SWITCH ··· REPLACEMENT	0.8
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558207 00	PTC HEATER SWITCH ··· REMOVAL AND INSTALLATION	0.2
558207 10	PTC HEATER SWITCH ··· REPLACEMENT	0.2
	[Additional operation]	

CODE	DESCRIPTION	KG0W KH0W
	A9 ··· Inspection by multi-use tester	0.2
558212 00	REAR COOLER SWITCH ··· REMOVAL AND INSTALLATION	0.3
558212 10	REAR COOLER SWITCH ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558217 00	REAR COOLER (BLOWER) SWITCH ··· REMOVAL AND INSTALLATION	0.3
558217 10	REAR COOLER (BLOWER) SWITCH ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558244 00	DUAL PRESSURE SWITCH ··· REMOVAL AND INSTALLATION	0.3
558244 10	DUAL PRESSURE SWITCH ··· REPLACEMENT	0.3
558312 00	ROOM TEMPERATURE SENSOR (FOOT) ··· REMOVAL AND INSTALLATION	0.4
558312 10	ROOM TEMPERATURE SENSOR (FOOT) ··· REPLACEMENT	0.4
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558313 00	PHOTO SENSOR ··· REMOVAL AND INSTALLATION	0.3
558313 10	PHOTO SENSOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558321 00	AIR-INLET SENSOR ··· REMOVAL AND INSTALLATION	0.3
558321 10	AIR-INLET SENSOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558331 00	FIN SENSOR ··· REMOVAL AND INSTALLATION	2.7
	[Additional time allowance]	
	L1 ··· Left-hand drive	0.3
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
558331 10	FIN SENSOR ··· REPLACEMENT	2.7
	[Additional time allowance]	
	L1 ··· Left-hand drive	0.3
	[Additional operation]	
	A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	A9 ··· Inspection by multi-use tester	0.2
558403 00	BLOWER MOTOR RELAY ··· REMOVAL AND INSTALLATION (One piece)	0.2
558403 10	BLOWER MOTOR RELAY ··· REPLACEMENT (One piece)	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558405 00	REAR BLOWER MOTOR RELAY ··· REMOVAL AND INSTALLATION (One piece)	0.2
558405 10	REAR BLOWER MOTOR RELAY ··· REPLACEMENT (One piece)	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558406 00	PTC HEATER RELAY ··· REMOVAL AND INSTALLATION	0.2
558406 10	PTC HEATER RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558411 00	CONDENSER FAN MOTOR RELAY ··· REMOVAL AND INSTALLATION (One piece)	0.2
558411 10	CONDENSER FAN MOTOR RELAY ··· REPLACEMENT (One piece)	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558423 00	AIR COMPRESSOR RELAY ··· REMOVAL AND INSTALLATION	0.2
558423 10	AIR COMPRESSOR RELAY ··· REPLACEMENT	0.2
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558511 00	AUTO AIR CONDITIONER CONTROL UNIT ··· REMOVAL AND INSTALLATION	0.6

CODE	DESCRIPTION	KG0W KH0W
558511 10	AUTO AIR CONDITIONER CONTROL UNIT ··· REPLACEMENT	0.6
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558901 00	HEATER BLOWER RESISTOR ··· REMOVAL AND INSTALLATION	0.3
558901 10	HEATER BLOWER RESISTOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558912 00	FULL AUTO AIR CONDITIONER POWER TRANSISTOR ··· REMOVAL AND INSTALLA	0.3
558912 10	FULL AUTO AIR CONDITIONER POWER TRANSISTOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558931 00	FRONT COOLER RESISTOR ··· REMOVAL AND INSTALLATION	0.3
558931 10	FRONT COOLER RESISTOR ··· REPLACEMENT	0.3
	[Additional operation]	
	A9 ··· Inspection by multi-use tester	0.2
558932 00	REAR AIR CONDITIONER RESISTOR ··· REMOVAL AND INSTALLATION	0.5
	[Additional operation]	
	A2 ··· Third seat R&I	0.4
558932 10	REAR AIR CONDITIONER RESISTOR ··· REPLACEMENT	0.5
	[Additional operation]	
	A2 ··· Third seat R&I	0.4
	A9 ··· Inspection by multi-use tester	0.2