SERVICE BULLETIN

MITSUBISHI MOTORS

AFTERSALES SERVICE OFFICE, MITSUBISHI MOTORS CORPORATION

PURPOSE: INFORMATION	ISSUE NO.: MSB-10E00-003	DATA: 2010-04-05
SUBJECT: FLAT RATE TIME FOR ASX		<MODEL> <M/Y> 11
GROUP: GENERAL		(EUR) See following 2. Applicable Vehicles table.

1. Description:

According to the establishment of the 2011 ASX, the flat rate times for the model are added to the following Flat Rate Manual. This Service Bulletin contains the added flat rate times.

2. Applicable Manual:

Manual	Pub. No.	Attached Sheet
2010 Flat Rate Manual (Revised version)	PFAM0801R-A	Attached sheet

OPERATION		GA0W
CODE	DESCRIPTION	
110010 10	ENGINE ASSEMBLY ･･･ REPLACEMENT	
	4B1	7.3
	[Additional time allowance]	
	B1 ･･･ With transfer	0.9
	C3 ･･･ Automatic transmission	0.6
	[Additional operation]	
	A4 ･･･ Initialization of headlamp automatic levelling-ECU	0.2
	4N1	8.4
	[Additional time allowance]	
	B1 ･･･ With transfer	0.6
	[Additional operation]	
	A2 ･･･ Theft prevention engine ECU cover - R&I	0.5
	A4 ･･･ Initialization of headlamp automatic levelling-ECU	0.3
	A8 ･･･ Steering wheel angular velocity sensor zero-calibration	0.2
110010 20	ENGINE ASSEMBLY ･･･ OVERHAUL	
	4B1	21.7
	[Additional time allowance]	
	B1 ･･･ With transfer	0.9
	B8 ･･･ Automatic transmission	0.6
	[Additional operation]	
	A4 ･･･ Initialization of headlamp automatic levelling-ECU	0.2
	4N1	25.5
	[Additional time allowance]	
	B1 ･･･ With transfer	0.6
	[Additional operation]	
	A2 ･･･ Theft prevention engine ECU cover - R&I	0.5
	A4 ･･･ Initialization of headlamp automatic levelling-ECU	0.3
	A8 ･･･ Steering wheel angular velocity sensor zero-calibration	0.2
110011 10	SHORT ENGINE ASSEMBLY ･･･ REPLACEMENT	
	4B1	12.2
	[Additional time allowance]	
	C8 ･･･ Automatic transmission	0.6
	D3 ･･･ With transfer	0.9
	[Additional operation]	
	A1 ･･･ Cylinder head assembly ･･･ overhaul	5.8
	B8 ･･･ Initialization of headlamp automatic levelling-ECU	0.2
	4N1	16.0
	[Additional time allowance]	
	D3 ･･･ With transfer	0.6
	[Additional operation]	
	A1 ･･･ Cylinder head assembly ･･･ overhaul	5.2
	A8 ･･･ Steering wheel angular velocity sensor zero-calibration	0.2
	B5 ･･･ Theft prevention engine ECU cover - R&I	0.5
	B8 ･･･ Initialization of headlamp automatic levelling-ECU	0.3
111110 10	CYLINDER BLOCK ASSEMBLY ･･･ REPLACEMENT	
	4B1	14.5
	[Additional time allowance]	
	C4 ･･･ With transfer	0.9
	D9 ･･･ Automatic transmission	0.6
	[Additional operation]	
	A1 ･･･ Cylinder head assembly ･･･ overhaul	5.8
	B8 ･･･ Initialization of headlamp automatic levelling-ECU	0.2
	4N1	19.9
	[Additional time allowance]	
	C4 ･･･ With transfer	0.6

OPERATION			GA0W
CODE		DESCRIPTION	
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B5 ··· Theft prevention engine ECU cover - R&I	0.5
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.3
111210	10	CYLINDER HEAD ASSEMBLY ··· REPLACEMENT	
		4B1	13.1
		4N1	16.4
		[Additional time allowance]	
		L8 ··· Without transfer	0.3
111210	20	CYLINDER HEAD ASSEMBLY ··· OVERHAUL	
		4B1	14.1
		4N1	17.4
		[Additional time allowance]	
		L8 ··· Without transfer	0.3
111221	10	CYLINDER HEAD GASKET ··· REPLACEMENT	
		4B1	7.7
		[Additional operation]	
		A8 ··· Cylinder head assembly ··· cleaning	0.2
		4N1	12.3
		[Additional time allowance]	
		L8 ··· Without transfer	0.3
		[Additional operation]	
		A8 ··· Cylinder head assembly ··· cleaning	0.2
111310	10	ROCKER COVER ASSEMBLY ··· REPLACEMENT	
		4B1	0.6
		4N1	2.0
111311	10	ROCKER COVER GASKET ··· REPLACEMENT	
		4B1	0.6
		4N1	2.0
111320	10	OIL PAN ASSEMBLY ··· REPLACEMENT	
		4B1	1.6
		4N1	2.0
111321	10	OIL PAN GASKET (LIQUID GASKET) ··· REPLACEMENT	
		4B1	1.6
		4N1	2.0
111336	10	TIMING CHAIN (GEAR) CASE ··· REPLACEMENT	
		4B1	3.8
		4N1	6.7
111337	10	TIMING CHAIN (GEAR) CASE GASKET ··· REPLACEMENT	
		4B1	3.8
		4N1	6.7
112110	10	PISTON ··· REPLACEMENT (All)	
		4B1	13.5
		[Additional time allowance]	
		C3 ··· Automatic transmission	0.6
		C8 ··· With transfer	0.9
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.8
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	17.5
		[Additional time allowance]	
		C8 ··· With transfer	0.6
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
		B5 ··· Theft prevention engine ECU cover – R&I	0.5
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.3
112120	10	PISTON RING ··· REPLACEMENT (All)	
		4B1	13.5
		[Additional time allowance]	
		C3 ··· Automatic transmission	0.6
		C8 ··· With transfer	0.9
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.8
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	17.5
		[Additional time allowance]	
		C8 ··· With transfer	0.6
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B5 ··· Theft prevention engine ECU cover – R&I	0.5
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.3
112210	10	CONNECTING ROD ASSEMBLY ··· REPLACEMENT (All)	
		4B1	13.5
		[Additional time allowance]	
		C3 ··· Automatic transmission	0.6
		C8 ··· With transfer	0.9
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.8
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	17.5
		[Additional time allowance]	
		C8 ··· With transfer	0.6
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B5 ··· Theft prevention engine ECU cover – R&I	0.5
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.3
112220	10	CONNECTING ROD BEARING (BIG END) ··· REPLACEMENT (All)	
		4B1	13.5
		[Additional time allowance]	
		B1 ··· With transfer	0.9
		C3 ··· Automatic transmission	0.6
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.8
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	17.5
		[Additional time allowance]	
		B1 ··· With transfer	0.6
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B5 ··· Theft prevention engine ECU cover – R&I	0.5
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.3
112310	10	CRANKSHAFT ASSEMBLY ··· REPLACEMENT	
		4B1	14.2
		[Additional time allowance]	
		C3 ··· Automatic transmission	0.6
		C8 ··· With transfer	0.9
		[Additional operation]	

OPERATION			GA0W
CODE		DESCRIPTION	
		A1 ··· Cylinder head assembly ··· overhaul	5.8
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	19.1
		[Additional time allowance]	
		C8 ··· With transfer	0.6
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B5 ··· Theft prevention engine ECU cover - R&I	0.5
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.3
112320	10	CRANKSHAFT MAIN BEARING ··· REPLACEMENT (All)	
		4B1	14.2
		[Additional time allowance]	
		C3 ··· Automatic transmission	0.6
		C8 ··· With transfer	0.9
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.8
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	19.1
		[Additional time allowance]	
		C8 ··· With transfer	0.6
		[Additional operation]	
		A1 ··· Cylinder head assembly ··· overhaul	5.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B5 ··· Theft prevention engine ECU cover - R&I	0.5
		B8 ··· Initialization of headlamp automatic levelling-ECU	0.3
112342	10	CRANKSHAFT OIL SEAL (FRONT) ··· REPLACEMENT	
		4B1	0.8
		4N1	2.2
112352	10	CRANKSHAFT OIL SEAL (REAR) ··· REPLACEMENT	
		4B1	4.6
		[Additional time allowance]	
		B1 ··· With transfer	1.0
		B2 ··· Automatic transmission	0.5
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	5.5
		[Additional time allowance]	
		B1 ··· With transfer	0.6
		[Additional operation]	
		A3 ··· Theft prevention engine ECU cover - R&I	0.5
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
112370	10	CRANKSHAFT PULLEY ··· REPLACEMENT	
		4B1	0.7
		4N1	2.1
112410	10	FLYWHEEL ··· REPLACEMENT	
		4B1	4.5
		[Additional time allowance]	
		B1 ··· With transfer	0.9
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	5.4
		[Additional time allowance]	
		B1 ··· With transfer	0.6
		[Additional operation]	

OPERATION			GA0W
CODE		DESCRIPTION	
		A3 ··· Theft prevention engine ECU cover – R&I	0.5
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
112411	10	FLYWHEEL RING GEAR ··· REPLACEMENT	
		4B1	4.6
		[Additional time allowance]	
		B1 ··· With transfer	0.9
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
112420	10	DRIVE PLATE ··· REPLACEMENT	4.9
		[Additional time allowance]	
		B2 ··· With transfer	1.1
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
113100	45	ENGINE VALVE GENERAL ··· CLEARANCE ADJUSTMENT	
		4B1	2.6
		4N1	2.9
113110	10	INLET VALVE ··· REPLACEMENT (All)	
		4B1	11.3
		[Additional operation]	
		A1 ··· Exhaust valve (all) ··· replacement	1.5
		4N1	14.6
		[Additional time allowance]	
		L8 ··· Without transfer	0.3
		[Additional operation]	
		A1 ··· Exhaust valve (all) ··· replacement	1.5
113113	10	INLET VALVE STEM SEAL ··· REPLACEMENT (All)	
		4B1	4.9
		[Additional operation]	
		A1 ··· Exhaust valve stem seal (all) ··· replacement	1.2
		4N1	5.7
		[Additional operation]	
		A1 ··· Exhaust valve stem seal (all) ··· replacement	2.9
113114	10	INLET VALVE SPRING ··· REPLACEMENT (All)	
		4B1	4.9
		[Additional operation]	
		A1 ··· Exhaust valve spring ··· replacement	1.2
		4N1	5.7
		[Additional operation]	
		A1 ··· Exhaust valve spring ··· replacement	2.9
113150	10	EXHAUST VALVE ··· REPLACEMENT (All)	
		4B1	11.3
		4N1	14.6
		[Additional time allowance]	
		L8 ··· Without transfer	0.3
113153	10	EXHAUST VALVE STEM SEAL ··· REPLACEMENT (All)	
		4B1	4.9
		4N1	5.3
113154	10	EXHAUST VALVE SPRING ··· REPLACEMENT (All)	
		4B1	4.9
		4N1	5.3
113213	10	ROCKER ARM ASSEMBLY (INLET) ··· REPLACEMENT	3.5
		[Additional operation]	
		A1 ··· Exhaust rocker arm assembly ··· replacement	0.7
113214	10	ROCKER ARM ASSEMBLY (EXHAUST) ··· REPLACEMENT	3.1
113220	10	ROCKER SHAFT ASSEMBLY ··· REPLACEMENT	3.5

OPERATION			GA0W
CODE		DESCRIPTION	
113310	10	CAMSHAFT ASSEMBLY ··· REPLACEMENT (One piece)	
		4B1	3.5
113312	10	CAMSHAFT (INTAKE) ··· REPLACEMENT	3.3
113313	10	CAMSHAFT (EXHAUST) ··· REPLACEMENT	8.3
113420	10	TIMING CHAIN ··· REPLACEMENT	
		4B1	4.0
		4N1	7.9
113520	10	TIMING CHAIN TENSIONER ASSEMBLY ··· REPLACEMENT	
		4B1	3.8
		4N1	7.7
113521	10	TIMING CHAIN GUIDE ··· REPLACEMENT	
		4B1	4.0
		4N1	7.9
113610	10	CRANKSHAFT SPROCKET ··· REPLACEMENT	
		4B1	4.1
		4N1	7.9
113620	10	CAMSHAFT SPROCKET ··· REPLACEMENT (One piece)	
		4B1	3.5
113640	10	OIL PUMP SPROCKET ··· REPLACEMENT	1.6
118601	10	OIL CONTROL VALVE ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
118602	10	OIL CONTROL VALVE (INTAKE SIDE) ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
118603	10	OIL CONTROL VALVE (EXHAUST SIDE) ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
121010	10	OIL PUMP ASSEMBLY ··· REPLACEMENT	1.7
121017	10	OIL PUMP DRIVE SHAFT ··· REPLACEMENT	2.1
121021	10	OIL PUMP CHAIN TENSIONER ··· REPLACEMENT	4.1
121022	10	OIL PUMP DRIVE CHAIN ··· REPLACEMENT	4.1
121061	10	OIL SCREEN (STRAINER) ··· REPLACEMENT	2.1
122020	10	OIL FILTER ASSEMBLY ··· REPLACEMENT	0.4
125012	10	OIL FILLER CAP ··· REPLACEMENT	0.2
128201	10	OIL PRESSURE SWITCH ··· REPLACEMENT	
		4B1	1.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
		4N1	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
133110	10	INJECTOR (ECI-MULTI) ··· REPLACEMENT (All)	1.4
		[Additional time allowance]	
		E8 ··· Automatic transmission	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
133121	10	THROTTLE BODY (ECI-MULTI) ··· REPLACEMENT	1.1
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
133132	10	DELIVERY PIPE (ECI-MULTI) ··· REPLACEMENT	1.3
		[Additional time allowance]	
		E8 ··· Automatic transmission	0.2
134210	10	THROTTLE BODY ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
134212	10	CAMSHAFT ANGLE SENSOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
134215	10	CRANKSHAFT POSITION SENSOR ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
134310	10	COMMON RAIL INJECTOR ··· REPLACEMENT (All)	1.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
134312	10	COMMON RAIL INJECTOR GASKET ··· REPLACEMENT (All)	1.4
134320	10	COMMON RAIL ··· REPLACEMENT	1.0
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
134321	10	COMMON RAIL INJECTION PIPE (PUMP SIDE) ··· REPLACEMENT	1.0
134322	10	COMMON RAIL INJECTOIN PIPE (INJECTOR SIDE) ··· REPLACEMENT (All)	1.0
134330	10	COMMON RAIL SUPPLY PUMP ··· REPLACEMENT	1.0
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
135020	10	FUEL PUMP ASSEMBLY (ELECTRICAL) ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
135031	10	FUEL PUMP MODULE ··· REPLACEMENT	0.5
136010	10	FUEL TANK ASSEMBLY ··· REPLACEMENT	1.7
		[Additional time allowance]	
		B2 ··· With transfer	0.6
136021	10	FUEL TANK FILLER NECK HOSE ··· REPLACEMENT	1.5
		[Additional time allowance]	
		B2 ··· With transfer	0.6
136022	10	FUEL TANK BREATHER HOSE ··· REPLACEMENT	1.5
		[Additional time allowance]	
		B4 ··· With transfer	0.6
136024	10	FUEL TANK CAP ··· REPLACEMENT	0.2
136032	10	FUEL TANK VAPOR HOSE ··· REPLACEMENT	1.5
		[Additional time allowance]	
		B2 ··· With transfer	0.6
136061	10	FUEL TANK BAND (STRAP) ··· REPLACEMENT	0.6
137010	10	FUEL FILTER (STRAINER) ASSEMBLY ··· REPLACEMENT	
		4B1	0.6
		4N1	0.7
137031	10	FUEL HOSE (ENGINE) ··· REPLACEMENT	
		4B1	0.3
		4N1	0.6
137042	10	FUEL HOSE (REAR FLOOR) ··· REPLACEMENT	0.5
137076	10	FUEL COOLER ··· REPLACEMENT	0.5
137083	10	FUEL PRESSURE REGULATOR ··· REPLACEMENT	0.6
138221	10	WATER LEVEL SWITCH (SENSOR) (FUEL FILTER) ··· REPLACEMENT	0.6
138301	10	FUEL TANK GAUGE UNIT ··· REPLACEMENT (One piece)	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138301	80	FUEL TANK GAUGE UNIT (LEFT SIDE) ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138301	82	FUEL TANK GAUGE UNIT (RIGHT SIDE) ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138311	10	WATER TEMPERATURE SENSOR ··· REPLACEMENT	0.9

OPERATION			GA0W
CODE		DESCRIPTION	
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138314	10	AIR FLOW SENSOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138315	10	INTAKE AIR TEMPERATURE SENSOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138322	10	MANIFOLD ABSOLUTE PRESSURE SENSOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138354	10	OXYGEN SENSOR (BEFORE UCC) ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138355	10	OXYGEN SENSOR (AFTER UCC) ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138401	10	ECI CONTROL RELAY ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138452	10	INJECTOR RELAY ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138501	10	ECI CONTROL UNIT ··· REPLACEMENT	0.8
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
138501	13	ECI CONTROL UNIT ··· REPROGRAMMING	0.3
		[Additional operation]	
		A2 ··· learning drive	0.2
138502	10	ENGINE CONTROL UNIT (DIESEL) ··· REPLACEMENT	0.8
		[Additional operation]	
		A1 ··· Theft prevention engine ECU cover – R&I	0.6
		A9 ··· Inspection by multi-use tester	0.2
138502	13	ENGINE CONTROL UNIT (DIESEL) ··· REPROGRAMMING	0.3
		[Additional operation]	
		A2 ··· learning drive	0.2
141010	10	WATER PUMP ASSEMBLY ··· REPLACEMENT	
		4B1	1.2
		4N1	1.7
141016	10	WATER PUMP GASKET ··· REPLACEMENT	
		4B1	1.2
		4N1	1.7
141021	10	WATER PUMP DRIVE BELT ··· REPLACEMENT	
		4B1	0.7
		4N1	0.6
141023	10	WATER PUMP DRIVE BELT AUTO TENSIONER ··· REPLACEMENT	0.8
141024	10	WATER PUMP DRIVE BELT IDLER PULLEY ··· REPLACEMENT	0.7
142110	10	THERMOSTAT ··· REPLACEMENT	
		4B1	0.9
		4N1	2.2
142111	10	WATER OUTLET FITTING ··· REPLACEMENT	
		4B1	1.0
		4N1	2.5
142112	10	WATER OUTLET GASKET ··· REPLACEMENT	
		4B1	1.0
		4N1	2.5

OPERATION			GA0W
CODE		DESCRIPTION	
142113	10	THERMOSTAT CASE (HOUSING) ··· REPLACEMENT	
		4B1	1.7
		4N1	2.2
142114	10	THERMOSTAT CASE GASKET ··· REPLACEMENT	1.7
142120	10	WATER BY-PASS FITTING ··· REPLACEMENT	1.4
142211	10	WATER BY-PASS PIPE ··· REPLACEMENT	2.2
142212	10	WATER SUCTION (INLET) PIPE ··· REPLACEMENT	
		4B1	1.7
		4N1	1.8
144031	10	COOLING FAN (ELECTRIC) ··· REPLACEMENT	1.3
145010	10	RADIATOR ASSEMBLY ··· REPLACEMENT	
		4B1	1.2
		4N1	1.4
145034	10	RADIATOR SHROUD ··· REPLACEMENT	1.4
145050	10	RESERVOIR (CONDENSE) TANK ASSEMBLY ··· REPLACEMENT	
		4B1	0.3
		4N1	0.8
146012	10	RADIATOR LOWER PIPE ··· REPLACEMENT	1.0
146021	10	RADIATOR HOSE (UPPER) ··· REPLACEMENT (All)	0.8
146022	10	RADIATOR HOSE (LOWER) ··· REPLACEMENT (All)	
		4B1	1.0
		4N1	1.2
146023	10	RUBBER HOSE (RADIATOR TO TANK) ··· REPLACEMENT (All)	
		4B1	0.3
		4N1	0.4
148101	10	RADIATOR FAN MOTOR ··· REPLACEMENT	1.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
148401	10	RADIATOR FAN MOTOR RELAY ··· REPLACEMENT (One piece)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
148411	10	RADIATOR FAN CONTROL RELAY ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
151110	10	INTAKE MANIFOLD ASSEMBLY ··· REPLACEMENT	
		4B1	2.3
		[Additional time allowance]	
		E8 ··· Automatic transmission	0.2
		4N1	1.3
151120	10	INTAKE MANIFOLD GASKET ··· REPLACEMENT	
		4B1	2.3
		[Additional time allowance]	
		E8 ··· Automatic transmission	0.2
		4N1	1.3
151210	10	AIR CLEANER ASSEMBLY ··· REPLACEMENT	0.4
151211	10	AIR CLEANER ELEMENT ··· REPLACEMENT	0.2
151410	10	INTERCOOLER ASSEMBLY ··· REPLACEMENT	0.8
151523	10	INTAKE HOSE (TURBO TO INTER COOLER) ··· REPLACEMENT	0.7
		[Additional operation]	
		A1 ··· Front bumper assy - R&I	0.4
		A3 ··· Air intake pipe - R&I	0.3
151526	10	INTAKE HOSE (INTER COOLER TO THROTTLE BODY) ··· REPLACEMENT	0.6
		[Additional operation]	
		A2 ··· Intercooler assy - R&I	0.6
153110	10	EXHAUST MANIFOLD ASSEMBLY ··· REPLACEMENT	
		4B1	1.2

OPERATION			GA0W
CODE		DESCRIPTION	
		4N1	2.9
		[Additional time allowance]	
		L8 ··· Without transfer	0.2
153120	10	EXHAUST MANIFOLD GASKET ··· REPLACEMENT	
		4B1	1.2
		4N1	2.9
		[Additional time allowance]	
		L8 ··· Without transfer	0.2
153210	10	FRONT EXHAUST PIPE ASSEMBLY ··· REPLACEMENT	0.6
153211	10	FRONT EXHAUST PIPE GASKET ··· REPLACEMENT	0.6
153310	10	CENTER EXHAUST PIPE ASSEMBLY ··· REPLACEMENT	0.9
153311	10	CENTER EXHAUST PIPE GASKET ··· REPLACEMENT	0.6
153510	10	MAIN MUFFLER ASSEMBLY ··· REPLACEMENT	0.6
153710	10	CATALYTIC CONVERTER ASSEMBLY (FRONT) ··· REPLACEMENT	1.4
		[Additional time allowance]	
		C2 ··· With transfer	0.5
153901	10	DIESEL PARTICULATE FILTER(DPF) ··· REPLACEMENT	0.8
153901	5F	DIESEL PARTICULATE FILTER(DPF) ··· CLEANING WITH RACING	0.4
155010	10	TURBOCHARGER ASSEMBLY ··· REPLACEMENT	2.5
		[Additional time allowance]	
		L8 ··· Without transfer	0.2
155051	10	TURBO OIL FEED PIPE ··· REPLACEMENT	0.8
155052	10	TURBO OIL RETURN PIPE ··· REPLACEMENT	1.6
		[Additional time allowance]	
		L8 ··· Without transfer	0.2
155053	10	TURBO OIL RETURN HOSE ··· REPLACEMENT	1.0
158604	10	VGT SOLENOID VALVE ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
161110	10	ALTERNATOR ASSEMBLY ··· REPLACEMENT	1.0
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
161110	20	ALTERNATOR ASSEMBLY ··· OVERHAUL	2.0
161121	10	ALTERNATOR IC REGULATOR ··· REPLACEMENT	1.6
161122	10	ALTERNATOR BRUSH HOLDER ASSEMBLY ··· REPLACEMENT	1.4
161125	10	ALTERNATOR RECTIFIER ··· REPLACEMENT	1.4
161161	10	ALTERNATOR DRIVE BELT ··· REPLACEMENT	0.6
161172	10	ALTERNATOR DRIVE BELT IDLER PULLEY ··· REPLACEMENT	0.6
161175	10	ALTERNATOR DRIVE BELT AUTO TENSIONER ··· REPLACEMENT	0.9
162110	10	STARTER ASSEMBLY ··· REPLACEMENT	
		4B1	1.2
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
		4N1	1.0
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
162110	20	STARTER ASSEMBLY ··· OVERHAUL	
		4B1	2.2
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.2
		4N1	2.0
162112	10	STARTER SWITCH ASSEMBLY ··· REPLACEMENT	
		4B1	1.5
		[Additional time allowance]	

OPERATION			GA0W
CODE		DESCRIPTION	
		B1 ··· Automatic transmission	0.2
		4N1	1.3
162121	10	STARTER BRUSH HOLDER ASSEMBLY ··· REPLACEMENT	
		4B1	1.7
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.2
		4N1	1.5
162124	10	STARTER OVERRUNNING CLUTCH ··· REPLACEMENT	
		4B1	1.7
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.2
		4N1	1.5
162210	10	GLOW PLUG ··· REPLACEMENT (One piece)	0.4
		[Additional operation]	
		01 ··· Per 1 pc.	0.1
163110	10	IGNITION COIL ASSEMBLY ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
163510	10	SPARK PLUG ASSEMBLY ··· REPLACEMENT (All)	0.4
163510	55	SPARK PLUG ASSEMBLY ··· CLEANING (All)	0.5
163510	57	SPARK PLUG ASSEMBLY ··· CLEANING WITH RACING	0.3
168204	10	INTERLOCK SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
168301	10	KNOCK SENSOR ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
168321	10	CRANKSHAFT ANGLE SENSOR ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
168324	10	CAMSHAFT ANGLE SENSOR (INTAKE) ··· REPLACEMENT	1.0
		[Additional time allowance]	
		E8 ··· Automatic transmission	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
168325	10	CAMSHAFT ANGLE SENSOR (EXHAUST) ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
168401	10	STARTER RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
168431	10	GLOW PLUG RELAY ··· REPLACEMENT (One piece)	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
171111	10	ACCELERATOR PEDAL ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
173110	10	CANISTER ASSEMBLY ··· REPLACEMENT	0.3
173171	10	VAPOR HOSE ··· REPLACEMENT	0.3
173310	10	EGR VALVE ··· REPLACEMENT	
		4B1	0.4
		[Additional time allowance]	
		E8 ··· Automatic transmission	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
		4N1	1.5

OPERATION			GA0W
CODE		DESCRIPTION	
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
173311	10	EGR VALVE GASKET ··· REPLACEMENT	
		4B1	0.4
		[Additional time allowance]	
		E8 ··· Automatic transmission	0.4
		4N1	1.5
173312	10	EGR PIPE ··· REPLACEMENT	
		4B1	1.1
		4N1	0.8
173313	10	EGR COOLER ··· REPLACEMENT	2.6
173610	10	POSITIVE CRANKCASE VENTILATION VALVE ··· REPLACEMENT	0.3
173620	10	PCV HOSE ··· REPLACEMENT	0.3
173630	10	BREATHER HOSE ··· REPLACEMENT	0.3
178202	10	CLUTCH PEDAL SWITCH (AUTO CRUISE) ··· REPLACEMENT	0.3
		[Additional time allowance]	
		L9 ··· Left-hand drive	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178203	10	AUTO CRUISE SWITCH ··· REPLACEMENT	0.4
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
178205	10	AS & G MAIN SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178206	10	NEUTRAL SWITCH1(ASG) ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178331	10	No.1 EXHAUST GAS TEMPERATURE SENSOR ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178332	10	No.2 EXHAUST GAS TEMPERATURE SENSOR ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178333	10	No.3 EXHAUST GAS TEMPERATURE SENSOR ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178334	10	EXHAUST DIFFERENTIAL PRESSURE SENSOR ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178451	10	THROTTLE CONTROL SERVO RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178502	10	ASG CONTROL UNIT ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178608	10	EGR COOLER SOLENOID VALVE ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
178635	10	PURGE CONTROL VALVE ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
211110	10	CLUTCH DISC ··· REPLACEMENT	
		4B1	4.3
		[Additional time allowance]	

OPERATION			GA0W
CODE		DESCRIPTION	
		C3 ··· With transfer	1.0
		[Additional operation]	
		A1 ··· Release bearing ··· replacement	0.1
		A2 ··· Flywheel ··· replacement	0.3
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	5.2
		[Additional time allowance]	
		C3 ··· With transfer	0.7
		[Additional operation]	
		A1 ··· Release bearing ··· replacement	0.1
		A2 ··· Flywheel ··· replacement	0.3
		A7 ··· Theft prevention engine ECU cover - R&I	0.5
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
211120	10	CLUTCH COVER ASSEMBLY ··· REPLACEMENT	
		4B1	4.3
		[Additional time allowance]	
		C3 ··· With transfer	1.0
		[Additional operation]	
		A1 ··· Release bearing ··· replacement	0.1
		A2 ··· Flywheel ··· replacement	0.3
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	5.2
		[Additional time allowance]	
		C3 ··· With transfer	0.7
		[Additional operation]	
		A1 ··· Release bearing ··· replacement	0.1
		A2 ··· Flywheel ··· replacement	0.3
		A7 ··· Theft prevention engine ECU cover - R&I	0.5
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
212011	10	CLUTCH PEDAL ··· REPLACEMENT	
		4B1	0.9
		[Additional time allowance]	
		L9 ··· Left-hand drive	0.5
		4N1	1.1
		[Additional time allowance]	
		L9 ··· Left-hand drive	0.3
212030	10	CLUTCH MASTER CYLINDER ASSEMBLY ··· REPLACEMENT	
		4B1	0.6
		[Additional time allowance]	
		L9 ··· Left-hand drive	0.8
		4N1	0.8
		[Additional time allowance]	
		L9 ··· Left-hand drive	0.6
212071	10	CLUTCH RELEASE BEARING ··· REPLACEMENT	
		4B1	4.2
		[Additional time allowance]	
		C3 ··· With transfer	1.0
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
		4N1	5.1
		[Additional time allowance]	
		C3 ··· With transfer	0.7
		[Additional operation]	
		A1 ··· Theft prevention engine ECU cover - R&I	0.5

OPERATION			GA0W
CODE		DESCRIPTION	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
212081	10	CLUTCH HOSE ··· REPLACEMENT	
		4B1	0.7
		[Additional time allowance]	
		H6 ··· Right-hand drive	2.3
		4N1	0.7
		[Additional time allowance]	
		H6 ··· Right-hand drive	2.6
		[Additional operation]	
		A2 ··· Theft prevention engine ECU cover - R&I	0.5
221110	10	T/M SHIFT LEVER ASSEMBLY ··· REPLACEMENT	0.7
221112	10	T/M SHIFT LEVER KNOB ··· REPLACEMENT	0.2
221115	10	T/M SHIFT LEVER BOOT (COVER) ··· REPLACEMENT	0.3
221171	10	T/M CONTROL CABLE ··· REPLACEMENT	1.5
222010	10	T/M ASSEMBLY ··· REPLACEMENT	
		F6MB	5.0
		[Additional operation]	
		A1 ··· Clutch disk or clutch cover ··· replacement	0.2
		A2 ··· Flywheel ··· replacement	0.3
		A7 ··· Theft prevention engine ECU cover - R&I	0.5
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		W6MB	5.7
		[Additional operation]	
		A1 ··· Clutch disk or clutch cover ··· replacement	0.2
		A2 ··· Flywheel ··· replacement	0.3
		A7 ··· Theft prevention engine ECU cover - R&I	0.5
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		OTHERS	4.1
		[Additional time allowance]	
		C3 ··· With transfer	1.0
		[Additional operation]	
		A1 ··· Clutch disk or clutch cover ··· replacement	0.2
		A2 ··· Flywheel ··· replacement	0.3
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010	20	T/M ASSEMBLY ··· OVERHAUL	
		F6MB	12.1
		[Additional operation]	
		A1 ··· Clutch disk or clutch cover ··· replacement	0.2
		A2 ··· Flywheel ··· replacement	0.3
		A7 ··· Theft prevention engine ECU cover - R&I	0.5
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		W6MB	12.8
		[Additional operation]	
		A1 ··· Clutch disk or clutch cover ··· replacement	0.2
		A2 ··· Flywheel ··· replacement	0.3
		A7 ··· Theft prevention engine ECU cover - R&I	0.5
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		OTHERS	11.3
		[Additional time allowance]	
		C3 ··· With transfer	1.0
		[Additional operation]	

OPERATION		GA0W
CODE	DESCRIPTION	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010 9A	T/M ASSEMBLY ··· GROUP WORK (A)	
	F6MB	5.5
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	W6MB	6.2
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	OTHERS	4.9
	[Additional time allowance]	
	C3 ··· With transfer	1.0
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010 9B	T/M ASSEMBLY ··· GROUP WORK (B)	
	F6MB	8.3
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	W6MB	9.0
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	OTHERS	8.5
	[Additional time allowance]	
	C3 ··· With transfer	1.0
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010 9C	T/M ASSEMBLY ··· GROUP WORK (C)	
	F6MB	8.6
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	W6MB	9.3

OPERATION		GA0W
CODE	DESCRIPTION	
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	OTHERS	8.5
	[Additional time allowance]	
	C3 ··· With transfer	1.0
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010 9D	T/M ASSEMBLY ··· GROUP WORK (D)	
	F6MB	6.6
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	W6MB	7.3
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	OTHERS	5.9
	[Additional time allowance]	
	C3 ··· With transfer	1.0
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010 9E	T/M ASSEMBLY ··· GROUP WORK (E)	
	F6MB	6.4
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	W6MB	7.1
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	OTHERS	5.8
	[Additional time allowance]	
	C3 ··· With transfer	1.0
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3

OPERATION		GA0W
CODE	DESCRIPTION	
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010 9F	T/M ASSEMBLY ··· GROUP WORK (F)	
	F6MB	7.1
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	W6MB	7.8
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	OTHERS	7.5
	[Additional time allowance]	
	C3 ··· With transfer	1.0
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010 9G	T/M ASSEMBLY ··· GROUP WORK (G)	
	F6MB	7.7
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	W6MB	8.4
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	OTHERS	7.6
	[Additional time allowance]	
	C3 ··· With transfer	1.0
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010 9H	T/M ASSEMBLY ··· GROUP WORK (H)	
	F6MB	8.1
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2
	A2 ··· Flywheel ··· replacement	0.3
	A7 ··· Theft prevention engine ECU cover - R&I	0.5
	A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
	B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
	W6MB	8.8
	[Additional operation]	
	A1 ··· Clutch disk or clutch cover ··· replacement	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
		A2 ··· Flywheel ··· replacement	0.3
		A7 ··· Theft prevention engine ECU cover – R&I	0.5
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		OTHERS	6.3
		[Additional time allowance]	
		C3 ··· With transfer	1.0
		[Additional operation]	
		A1 ··· Clutch disk or clutch cover ··· replacement	0.2
		A2 ··· Flywheel ··· replacement	0.3
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222010	9J	T/M ASSEMBLY ··· GROUP WORK (J)	
		F6MB	8.5
		[Additional operation]	
		A1 ··· Clutch disk or clutch cover ··· replacement	0.2
		A2 ··· Flywheel ··· replacement	0.3
		A7 ··· Theft prevention engine ECU cover – R&I	0.5
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		W6MB	9.2
		[Additional operation]	
		A1 ··· Clutch disk or clutch cover ··· replacement	0.2
		A2 ··· Flywheel ··· replacement	0.3
		A7 ··· Theft prevention engine ECU cover – R&I	0.5
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		B2 ··· Initialization of headlamp automatic levelling-ECU	0.3
222113	80	T/M DRIVE SHAFT OIL SEAL ··· REPLACEMENT (LEFT)	0.9
222113	82	T/M DRIVE SHAFT OIL SEAL ··· REPLACEMENT (RIGHT)	0.9
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
222260	90	POPPET BALL, SPRING AND PLUG ··· REPLACEMENT (All)	1.0
225020	10	T/F SUB ASSEMBLY ··· REPLACEMENT	
		W6MB	3.3
		[Additional operation]	
		A1 ··· Initialization of headlamp automatic levelling-ECU	0.2
		OTHERS	2.5
		[Additional operation]	
		A1 ··· Initialization of headlamp automatic levelling-ECU	0.2
225112	10	T/F CASE INPUT SHAFT OIL SEAL ··· REPLACEMENT	
		W6MB	3.3
		[Additional operation]	
		A1 ··· Initialization of headlamp automatic levelling-ECU	0.2
		OTHERS	2.5
		[Additional operation]	
		A1 ··· Initialization of headlamp automatic levelling-ECU	0.2
225145	10	T/F EXTENSION HOUSING OIL SEAL ··· REPLACEMENT	0.9
228201	10	BACK-UP LAMP SWITCH ··· REPLACEMENT	
		F6MB	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
		W6MB	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
		OTHERS	1.1
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
231110	10	T/M SELECTOR LEVER ASSEMBLY ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
231112	10	T/M SELECTOR HANDLE ··· REPLACEMENT	0.2
231118	10	T/M INDICATOR PANEL ··· REPLACEMENT	0.6
231131	10	T/M CONTROL (SELECT) CABLE ··· REPLACEMENT	1.4
233010	10	T/M ASSEMBLY ··· REPLACEMENT	4.8
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A1 ··· Oil line flush	0.4
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
233010	20	T/M ASSEMBLY ··· OVERHAUL	8.4
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
233010	9A	T/M ASSEMBLY ··· GROUP WORK (A)	6.4
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
233010	9B	T/M ASSEMBLY ··· GROUP WORK (B)	5.9
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
233010	9C	T/M ASSEMBLY ··· GROUP WORK (C)	6.8
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
233010	9D	T/M ASSEMBLY ··· GROUP WORK (D)	6.0
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
233010	9E	T/M ASSEMBLY ··· GROUP WORK (E)	5.6
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
233113	80	T/M DRIVE SHAFT OIL SEAL (LEFT SIDE) ··· REPLACEMENT	1.1
233113	82	T/M DRIVE SHAFT OIL SEAL (RIGHT SIDE) ··· REPLACEMENT	1.1
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
233130	10	T/M CONVERTER HOUSING ASSEMBLY ··· REPLACEMENT	6.0
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
233132	10	T/M CONVERTER HOUSING GASKET ··· REPLACEMENT	6.0
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
233141	10	T/M OIL PAN ··· REPLACEMENT	1.1
233142	10	T/M OIL PAN GASKET ··· REPLACEMENT	1.1
233731	10	T/M OIL FILTER ··· REPLACEMENT	1.3
233810	10	T/M VALVE BODY ASSEMBLY ··· REPLACEMENT	1.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
234510	10	TORQUE CONVERTER ··· REPLACEMENT	4.9
		[Additional time allowance]	
		C3 ··· With transfer	1.1
		[Additional operation]	
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
235020	10	T/F SUB ASSEMBLY ··· REPLACEMENT	2.7
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
235112	10	T/F CASE INPUT SHAFT OIL SEAL ··· REPLACEMENT	2.7
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
235145	10	T/F EXTENSION HOUSING OIL SEAL ··· REPLACEMENT	0.9
237500	55	T/M & OIL LINE FLUSHING	0.7
237510	10	T/M OIL HOSE ··· REPLACEMENT (All)	1.0
237530	10	T/M OIL COOLER ··· REPLACEMENT	1.0
237531	10	ATF WARMER ASSEMBLY ··· REPLACEMENT	1.3
237532	10	THERMO VALVE (ATF WARMER) ··· REPLACEMENT	0.9
238201	10	SWITCH, PARK/NEUTRAL POSITION ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
238205	10	PADDLE SHIFT ASSY ··· REPLACEMENT	0.5
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
238311	10	INPUT SPEED SENSOR ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
238312	10	OUTPUT SPEED SENSOR ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
238413	10	A/T RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
238501	10	T/M ELC CONTROL UNIT ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
251010	10	PROPELLER SHAFT ASSEMBLY ··· REPLACEMENT (One piece)	0.8
266121	10	FRONT DRIVE KNUCKLE ··· REPLACEMENT (One side)	1.1
		[Additional operation]	
		01 ··· Per 1 pc.	0.6
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
266141	10	FRONT WHEEL HUB ··· REPLACEMENT (One side)	1.1
		[Additional operation]	
		01 ··· Per 1 pc.	0.6
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
266142	10	FRONT WHEEL HUB BOLT ··· REPLACEMENT (One side)	0.8
		[Additional operation]	
		01 ··· Per 1 pc.	0.4
266148	10	WHEEL HUB BEARING (DOUBLE ROW ANGULAR CONTACT TYPE)	
		··· REPLACEMENT (One side)	1.1

OPERATION			GA0W
CODE		DESCRIPTION	
		[Additional operation]	
		01 ··· Per 1 pc.	0.6
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
266180	80	FRONT DRIVE SHAFT ASSEMBLY (LEFT SIDE) ··· REPLACEMENT	0.8
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.3
		[Additional operation]	
		A1 ··· Both side replace	0.3
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
266180	81	FRONT DRIVE SHAFT ASSEMBLY (LEFT SIDE) ··· OVERHAUL	1.2
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.3
		[Additional operation]	
		A1 ··· Both side overhaul	0.7
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
266180	82	FRONT DRIVE SHAFT ASSEMBLY (RIGHT SIDE) ··· REPLACEMENT	0.8
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.3
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
266180	83	FRONT DRIVE SHAFT ASSEMBLY (RIGHT SIDE) ··· OVERHAUL	1.2
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.3
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
266183	80	DRIVE SHAFT BOOT (LEFT SIDE) ··· REPLACEMENT	1.1
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.3
		[Additional operation]	
		A1 ··· Both side replace	0.6
		A5 ··· Initialization of headlamp automatic levelling-ECU	0.2
266183	82	DRIVE SHAFT BOOT (RIGHT SIDE) ··· REPLACEMENT	1.1
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.3
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
271141	10	REAR WHEEL HUB ··· REPLACEMENT (One side)	0.7
271142	10	REAR WHEEL HUB BOLT ··· REPLACEMENT (One side)	0.7
276021	10	REAR DIFFERENTIAL ELECTRONIC CONTROL COUPLING ··· REPLACEMENT	1.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
276141	10	REAR WHEEL HUB ··· REPLACEMENT (One side)	0.8
276142	10	REAR WHEEL HUB BOLT ··· REPLACEMENT (One side)	0.7
276180	10	REAR DRIVE SHAFT ASSEMBLY ··· REPLACEMENT (One side)	0.8
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276180	20	REAR DRIVE SHAFT ASSEMBLY ··· OVERHAUL (One side)	1.2
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276183	10	REAR DRIVE SHAFT BOOT ··· REPLACEMENT (Both side)	1.2
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276220	10	DIFFERENTIAL CASE ASSEMBLY ··· REPLACEMENT	6.0
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276222	10	DIFFERENTIAL SIDE & PINION GEAR SET ··· REPLACEMENT	3.5

OPERATION			GA0W
CODE		DESCRIPTION	
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276224	10	DIFFERENTIAL SIDE BEARING ··· REPLACEMENT	5.0
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276225	10	DIFFERENTIAL SIDE GEAR OIL SEAL ··· REPLACEMENT (One side)	0.9
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276230	10	FINAL DRIVE GEAR SET ··· REPLACEMENT	5.9
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276231	10	DRIVE PINION BEARING ··· REPLACEMENT	5.4
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276232	10	DRIVE PINION OIL SEAL ··· REPLACEMENT	1.2
276240	10	DIFFERENTIAL CARRIER ASSEMBLY ··· REPLACEMENT	2.1
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276240	20	DIFFERENTIAL CARRIER ASSEMBLY ··· OVERHAUL	6.8
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
276242	10	DIFFERENTIAL CARRIER GASKET ··· REPLACEMENT	2.6
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.2
278211	10	REAR DIFFERENTIAL COUPLING SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
278521	10	REAR DIFFERENTIAL COUPLING CONTROL UNIT ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
311010	05	WHEEL ASSEMBLY ··· ROTATION (One side)	0.3
311010	10	WHEEL ASSEMBLY ··· REPLACEMENT (One piece)	0.3
311010	67	WHEEL ASSEMBLY ··· BALANCE (One piece)	0.5
		[Additional operation]	
		01 ··· Per 1 pc.	0.2
311015	10	DISC WHEEL ··· REPLACEMENT (One piece)	0.8
		[Additional operation]	
		01 ··· Per 1 pc.	0.4
312011	10	WHEEL CAP ··· REPLACEMENT (One piece)	0.2
312012	10	CENTER CAP ··· REPLACEMENT (One piece)	0.2
321110	10	CROSSMEMBER (SUB FRAME) ASSEMBLY ··· REPLACEMENT	2.3
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
321150	10	CENTER MEMBER ASSEMBLY ··· REPLACEMENT	0.6
321221	10	ENGINE FRONT ROLL STOPPER ··· REPLACEMENT	0.6
321222	10	ENGINE MOUNTING ··· REPLACEMENT	
		4B1	0.7
		4N1	0.9
321223	10	T/M MOUNTING ··· REPLACEMENT	1.4
		[Additional operation]	
		A1 ··· Theft prevention engine ECU cover - R&I	0.5
321224	10	REAR ROLL STOPPER (INSULATOR) ··· REPLACEMENT	
		4B1	0.7
		[Additional time allowance]	
		B2 ··· With transfer	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
		4N1	0.9
		[Additional time allowance]	
		B2 ··· With transfer	1.3
		[Additional operation]	
		A3 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
323110	10	REAR SUSPENSION MEMBER ASSEMBLY ··· REPLACEMENT	2.2
		[Additional time allowance]	
		B3 ··· With transfer	0.8
		[Additional operation]	
		A7 ··· Initialization of headlamp automatic levelling-ECU	0.3
323220	10	DIFFERENTIAL SUPPORT ASSEMBLY (FRONT) ··· REPLACEMENT (One piece)	0.5
333110	10	LOWER ARM ASSEMBLY ··· REPLACEMENT (One side)	1.0
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
333112	10	LOWER ARM BUSHING ··· REPLACEMENT (One side)	1.1
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
333211	10	FRONT COIL SPRING ··· REPLACEMENT (One side)	1.2
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
333213	10	FRONT STRUT INSULATOR ··· REPLACEMENT (One side)	1.2
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
333310	10	FRONT STRUT ASSEMBLY ··· REPLACEMENT (One side)	1.0
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
333311	10	FRONT STRUT SHOCK ABSORBER ··· REPLACEMENT (One side)	1.2
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
333411	10	FRONT STABILIZER BAR ··· REPLACEMENT	
		4B1	1.4
		[Additional time allowance]	
		B2 ··· With transfer	0.8
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		4N1	2.0
		[Additional time allowance]	
		B2 ··· With transfer	0.3
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
333412	10	FRONT STABILIZER BUSHING ··· REPLACEMENT (All)	0.7
333414	10	FRONT STABILIZER LINK KIT ··· REPLACEMENT (One side)	0.5
340000	91	WHEEL ALIGNMENT	0.8
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.2
346110	10	LOWER ARM ASSEMBLY ··· REPLACEMENT (One side)	0.9
		[Additional operation]	

OPERATION			GA0W
CODE		DESCRIPTION	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
346112	10	LOWER ARM BUSHING ··· REPLACEMENT (One side)	1.0
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
346120	10	UPPER ARM ASSEMBLY ··· REPLACEMENT (One side)	0.9
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
346130	10	TRAILING ARM ASSEMBLY ··· REPLACEMENT (One side)	1.8
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
346132	10	TRAILING ARM BUSHING ··· REPLACEMENT (One side)	1.9
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
346211	10	REAR COIL SPRING ··· REPLACEMENT (One side)	1.0
		[Additional operation]	
		A5 ··· Rear speaker woofer - R&I	0.3
346213	10	REAR STRUT INSULATOR ASSEMBLY ··· REPLACEMENT (One side)	1.0
		[Additional operation]	
		A5 ··· Rear speaker woofer - R&I	0.3
346310	10	REAR SHOCK ABSORBER ASSEMBLY ··· REPLACEMENT (One side)	0.7
		[Additional operation]	
		A5 ··· Rear speaker woofer - R&I	0.3
346311	10	REAR SHOCK ABSORBER ··· REPLACEMENT (One side)	1.0
		[Additional operation]	
		A5 ··· Rear speaker woofer - R&I	0.3
346411	10	REAR STABILIZER BAR ··· REPLACEMENT	0.7
		[Additional time allowance]	
		B2 ··· With transfer	1.1
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
346412	10	REAR STABILIZER BUSHING ··· REPLACEMENT (All)	0.5
346414	10	REAR STABILIZER LINK KIT ··· REPLACEMENT (One side)	0.5
346520	10	REAR ASSIST LINK ASSEMBLY ··· REPLACEMENT (One side)	0.9
		[Additional operation]	
		A4 ··· Initialization of headlamp automatic levelling-ECU	0.2
350000	94	BRAKE SYSTEM ··· BLEED	0.4
351110	10	BRAKE MASTER CYLINDER ASSEMBLY ··· REPLACEMENT	1.4
351210	10	BRAKE BOOSTER ASSEMBLY ··· REPLACEMENT	
		4B1	1.7
		[Additional time allowance]	
		B5 ··· Left-hand drive	0.4
		D7 ··· Right-hand drive, Manual transmission	0.3
		4N1	2.5
		[Additional time allowance]	
		H6 ··· Right-hand drive	0.2
351212	10	BRAKE BOOSTER CHECK VALVE ··· REPLACEMENT	0.3
352211	10	FRONT BRAKE DISC (ROTOR) ··· REPLACEMENT (One side)	0.6
		[Additional operation]	
		A1 ··· Disc brake pad assembly ··· replacement	0.1
352211	89	FRONT BRAKE DISC (ROTOR) ··· ON-VEHICLE GRINDING (Both side)	1.4
		[Additional operation]	
		A1 ··· Disc brake pad assembly ··· replacement	0.1
352220	10	DISC BRAKE CALIPER ASSEMBLY ··· REPLACEMENT (One side)	0.8
352220	20	DISC BRAKE CALIPER ASSEMBLY ··· OVERHAUL (One side)	1.1
352226	10	DISC BRAKE PAD ASSEMBLY ··· REPLACEMENT (One side)	0.5
352611	10	REAR BRAKE DISC ··· REPLACEMENT (One side)	0.7

OPERATION			GA0W
CODE		DESCRIPTION	
		[Additional operation]	
		A1 ··· Disc brake pad assembly ··· replacement	0.1
352611	89	REAR BRAKE DISC (ROTOR) ··· ON-VEHICLE GRINDING (Both side)	1.4
		[Additional operation]	
		A1 ··· Disc brake pad assembly ··· replacement	0.1
352620	10	DISC BRAKE CALIPER ASSEMBLY ··· REPLACEMENT (One side)	0.8
352620	20	DISC BRAKE CALIPER ASSEMBLY ··· OVERHAUL (One side)	1.1
352626	10	DISC BRAKE PAD ASSEMBLY ··· REPLACEMENT (One side)	0.5
353121	10	BRAKE HOSE (FRONT) ··· REPLACEMENT (One side)	0.7
353123	10	BRAKE HOSE (REAR) ··· REPLACEMENT (One side)	0.8
353140	10	OIL RESERVOIR TANK ASSEMBLY ··· REPLACEMENT	1.4
353221	10	VACUUM HOSE ··· REPLACEMENT	
		4B1	0.4
		4N1	0.3
		[Additional time allowance]	
		H6 ··· Right-hand drive	0.3
353260	10	BRAKE VACUUM PUMP ASSEMBLY ··· REPLACEMENT	0.5
354011	10	BRAKE PEDAL ··· REPLACEMENT	0.6
354520	10	HYDRAULIC UNIT ASSEMBLY ··· REPLACEMENT	
		4B1	1.8
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
		4N1	2.0
		[Additional time allowance]	
		H6 ··· Right-hand drive	0.2
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
358201	10	STOP LAMP SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
358206	10	ASC SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
358308	10	STEERING WHEEL ANGULAR VELOCITY SENSOR ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
358311	10	FRONT SPEED SENSOR (ABS,AYC,ACD) ··· REPLACEMENT (One piece)	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
358312	10	REAR SPEED SENSOR (ABS,AYC,ACD) ··· REPLACEMENT (One piece)	0.9
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
358331	10	YAW RATE SENSOR ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
358341	10	BRAKE VACUUM SENSOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
361010	10	PARKING BRAKE LEVER ASSEMBLY ··· REPLACEMENT	0.4
361010	40	PARKING BRAKE LEVER ASSEMBLY ··· ADJUSTMENT	0.2
361050	10	REAR PARKING BRAKE CABLE ASSEMBLY ··· REPLACEMENT (One piece)	1.2
362110	10	SHOE AND LINING ASSEMBLY ··· REPLACEMENT (One side)	1.0
362120	10	PARKING BRAKE SHOE ADJUSTER ASSEMBLY ··· REPLACEMENT (One side)	0.8
362140	10	BACKING PLATE ASSEMBLY ··· REPLACEMENT (One side)	1.0

OPERATION			GA0W
CODE		DESCRIPTION	
368201	10	PARKING BRAKE SWITCH ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
371010	10	STEERING WHEEL ASSEMBLY ··· REPLACEMENT	0.4
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
371010	40	STEERING WHEEL ASSEMBLY ··· ADJUSTMENT AT TIE ROD ENDS	0.4
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
372010	10	STEERING SHAFT ASSEMBLY ··· REPLACEMENT	1.4
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
372050	10	STEERING SHAFT JOINT ASSEMBLY ··· REPLACEMENT	0.6
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
372070	10	STEERING COLUMN COVER ASSEMBLY ··· REPLACEMENT	0.3
372090	10	STEERING LOCK ··· REPLACEMENT	1.4
		[Additional operation]	
		A1 ··· OSS Platform number registration	0.2
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
373050	10	STEERING GEAR ASSEMBLY (RACK & PINION) ··· REPLACEMENT	2.3
		[Additional operation]	
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
373058	10	STEERING GEAR BELLOWS ··· REPLACEMENT (One side)	2.3
		[Additional operation]	
		01 ··· Per 1 pc.	0.1
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
376040	40	TOE-IN ··· ADJUSTMENT	0.4
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
376041	10	TIE ROD ··· REPLACEMENT (One side)	2.4
		[Additional operation]	
		01 ··· Per 1 pc.	0.2
		A2 ··· Initialization of headlamp automatic levelling-ECU	0.3
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
376042	10	TIE ROD END ··· REPLACEMENT (One side)	0.8
		[Additional operation]	
		01 ··· Per 1 pc.	0.1
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
378502	10	CONTROL UNIT (ECPS) ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
422022	10	FRONT FENDER PANEL ··· REPLACEMENT (One side)	1.4
422022	40	FRONT FENDER PANEL ··· ADJUSTMENT (One side)	0.4
422025	10	FRONT FENDER SPLASH SHIELD PANEL ··· REPLACEMENT (One side)	0.4
422031	10	REAR SPLASH SHIELD ··· REPLACEMENT (One side)	0.4
422062	10	UNDER COVER ··· REPLACEMENT	0.5
423121	10	FRONT WINDOW GLASS ··· REPLACEMENT	3.1
		[Additional operation]	
		A3 ··· Auto lighting control sensor R&I	0.2
423421	10	QUARTER WINDOW GLASS ··· REPLACEMENT (One side)	1.3
423915	10	ROOF GLASS ··· REPLACEMENT	6.3

OPERATION			GA0W
CODE		DESCRIPTION	
		[Additional operation]	
		A1 ··· Curtain air bag module – R&I	0.4
424110	00	FRONT DOOR ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.7
424110	40	FRONT DOOR ASSEMBLY ··· ADJUSTMENT (One side)	0.5
424111	10	FRONT DOOR PANEL ··· REPLACEMENT (One side)	2.1
424112	10	FRONT DOOR SASH ··· REPLACEMENT (One side)	0.5
424113	10	FRONT DOOR HINGE ··· REPLACEMENT (One side)	0.9
424114	10	FRONT DOOR CHECK ··· REPLACEMENT (One side)	0.4
424121	10	FRONT DOOR GLASS ··· REPLACEMENT (One side)	0.6
424121	40	FRONT DOOR GLASS ··· ADJUSTMENT (One side)	0.5
424125	10	FRONT DOOR RUNCHANNEL ··· REPLACEMENT (One side)	0.3
424131	10	FRONT DOOR WEATHERSTRIP (BODY SIDE) ··· REPLACEMENT (One side)	0.3
424132	10	FRONT DOOR WEATHERSTRIP (DOOR SIDE) ··· REPLACEMENT (One side)	0.4
424133	10	FRONT DOOR WEATHERSTRIP (BELT INNER) ··· REPLACEMENT (One side)	0.4
424138	10	FRONT DOOR WEATHERSTRIP LOWER (DOOR SIDE) ··· REPLACEMENT (One side)	0.3
424140	40	FRONT DOOR MECHANISM ··· ADJUSTMENT (One side)	0.5
424141	10	FRONT DOOR LATCH (LOCK) ··· REPLACEMENT (One side)	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
424141	40	FRONT DOOR LATCH (LOCK) ··· ADJUSTMENT (One side)	0.5
424142	10	FRONT DOOR STRIKER ··· REPLACEMENT (One side)	0.2
424142	40	FRONT DOOR STRIKER ··· ADJUSTMENT (One side)	0.2
424143	10	FRONT DOOR LOCK CYLINDER ··· REPLACEMENT (One side)	0.3
424144	10	FRONT DOOR OUTSIDE HANDLE ··· REPLACEMENT (One side)	0.3
424145	10	FRONT DOOR INSIDE HANDLE ··· REPLACEMENT (One side)	0.4
424148	10	FRONT DOOR INSIDE LOCK ROD ··· REPLACEMENT (One side)	0.6
424161	10	FRONT DOOR REGULATOR ··· REPLACEMENT (One side)	0.7
424210	00	REAR (SLIDE) DOOR ASSEMBLY ··· REMOVAL AND INSTALLATION (One side)	0.5
424210	40	REAR (SLIDE) DOOR ASSEMBLY ··· ADJUSTMENT (One side)	0.3
424211	10	REAR (SLIDE) DOOR PANEL ··· REPLACEMENT (One side)	1.9
424212	10	REAR (SLIDE) DOOR SASH ··· REPLACEMENT (One side)	0.5
424213	10	REAR (SLIDE) DOOR HINGE ··· REPLACEMENT (One side)	0.6
424214	10	REAR (SLIDE) DOOR CHECK ··· REPLACEMENT (One side)	0.4
424221	10	REAR (SLIDE) DOOR GLASS ··· REPLACEMENT (One side)	0.6
424221	40	REAR (SLIDE) DOOR GLASS ··· ADJUSTMENT (One side)	0.5
424225	10	REAR (SLIDE) DOOR RUNCHANNEL ··· REPLACEMENT (One side)	0.3
424231	10	REAR (SLIDE) DOOR WEATHERSTRIP (BODY) ··· REPLACEMENT (One side)	0.3
424232	10	REAR (SLIDE) DOOR WEATHERSTRIP (DOOR) ··· REPLACEMENT (One side)	0.4
424233	10	REAR (SLIDE) DOOR WEATHERSTRIP (BELT INNER) ··· REPLACEMENT (One side)	0.4
424238	10	REAR (SLIDE) DOOR WEATHERSTRIP LOWER (DOOR) ··· REPLACEMENT (One side)	0.2
424240	40	REAR (SLIDE) DOOR MECHANISM ··· ADJUSTMENT (One side)	0.5
424241	10	REAR (SLIDE) DOOR LATCH ··· REPLACEMENT (One side)	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
424241	40	REAR (SLIDE) DOOR LATCH ··· ADJUSTMENT (One side)	0.5
424242	10	REAR (SLIDE) DOOR STRIKER ··· REPLACEMENT (One side)	0.2
424242	40	REAR (SLIDE) DOOR STRIKER ··· ADJUSTMENT (One side)	0.2
424244	10	REAR (SLIDE) DOOR OUTSIDE HANDLE ··· REPLACEMENT (One side)	0.3
424245	10	REAR (SLIDE) DOOR INSIDE HANDLE ··· REPLACEMENT (One side)	0.3
424248	10	REAR (SLIDE) DOOR INSIDE LOCK ROD ··· REPLACEMENT (One side)	0.6
424261	10	REAR (SLIDE) DOOR REGULATOR ··· REPLACEMENT (One side)	0.8
424310	00	BACK DOOR (TAILGATE) ASSEMBLY ··· REMOVAL AND INSTALLATION	0.7
424310	40	BACK DOOR (TAILGATE) ASSEMBLY ··· ADJUSTMENT	0.3
424311	10	BACK DOOR (TAILGATE) PANEL ··· REPLACEMENT (One piece)	2.9
424313	10	BACK DOOR (TAILGATE) HINGE ··· REPLACEMENT	2.2
424321	10	BACK DOOR (TAILGATE) GLASS ··· REPLACEMENT	2.3

OPERATION			GA0W
CODE		DESCRIPTION	
424331	10	BACK DOOR WEATHERSTRIP (BODY SIDE) ··· REPLACEMENT	0.2
424341	10	BACK DOOR (TAILGATE) LATCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
424341	40	BACK DOOR (TAILGATE) LATCH ··· ADJUSTMENT	0.3
424342	10	BACK DOOR (TAILGATE) STRIKER ··· REPLACEMENT	0.3
424342	40	BACK DOOR (TAILGATE) STRIKER ··· ADJUSTMENT	0.2
424344	10	BACK DOOR (TAILGATE) OUTER HANDLE ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
424353	10	BACK DOOR (TAILGATE) STOPPER ··· REPLACEMENT (One piece)	0.3
425110	00	HOOD ASSEMBLY ··· REMOVAL AND INSTALLATION	0.4
425110	40	HOOD ASSEMBLY ··· ADJUSTMENT	0.3
425111	10	HOOD PANEL ··· REPLACEMENT	0.6
425113	10	HOOD HINGE ··· REPLACEMENT	0.8
425141	10	HOOD CATCH ··· REPLACEMENT	0.4
425151	10	HOOD OPENER CABLE ··· REPLACEMENT	0.7
425311	10	FUEL FILLER LID ··· REPLACEMENT	0.3
425341	10	FUEL FILLER LID LATCH ··· REPLACEMENT	0.6
425351	10	FUEL FILLER LID OPENER CABLE ··· REPLACEMENT	0.8
425352	10	FUEL FILLER LID OPENER LEVER ··· REPLACEMENT	0.3
428101	10	POWER WINDOW MOTOR (FRONT DOOR) ··· REPLACEMENT (One side)	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428102	10	POWER WINDOW MOTOR (REAR DOOR) ··· REPLACEMENT (One side)	0.8
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428201	10	POWER WINDOW SWITCH (MAIN) ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428202	10	POWER WINDOW SWITCH (SUB) ··· REPLACEMENT (One piece)	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428205	10	REAR POWER WINDOW SWITCH (SUB) ··· REPLACEMENT (One side)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428225	10	KEYLESS OPERATION SWITCH (FRONT DOOR) ··· REPLACEMENT (One side)	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428426	10	DEAD LOCK RELAY ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428505	10	KEYLESS OPERATION CONTROL UNIT ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428702	10	KEYLESS ENTRY TRANSMITTER ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428711	10	KEYLESS OPERATION ANTENNA (FRONT INNER) ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428712	10	KEYLESS OPERATION ANTENNA (FRONT OUTER) ··· REPLACEMENT (One piece)	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428713	10	KEYLESS OPERATION ANTENNA (REAR INNER) ··· REPLACEMENT (One piece)	0.6
		[Additional operation]	

OPERATION			GA0W
CODE		DESCRIPTION	
		A9 ··· Inspection by multi-use tester	0.2
428714	10	KEYLESS OPERATION ANTENNA (REAR OUTER) ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428716	10	KEYLESS OPERATION BUZZER ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
428717	10	KEYLESS OPERATION KEY ··· REPLACEMENT	0.4
428718	10	KEYLESS OPERATION KEYBOX ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
511120	10	FRONT WINDOW WIPER ARM ASSEMBLY ··· REPLACEMENT (One side)	0.2
511130	10	FRONT WINDOW WIPER BLADE ASSEMBLY ··· REPLACEMENT (One side)	0.2
511132	10	FRONT WINDOW WIPER BLADE RUBBER ··· REPLACEMENT (One piece)	0.2
511140	10	FRONT WINDOW WIPER LINK ASSEMBLY ··· REPLACEMENT	0.6
511220	10	REAR WINDOW WIPER ARM ASSEMBLY ··· REPLACEMENT	0.2
511230	10	REAR WINDOW WIPER BLADE ASSEMBLY ··· REPLACEMENT	0.2
511232	10	REAR WINDOW WIPER BLADE RUBBER ··· REPLACEMENT	0.2
512121	10	FRONT WINDOW WASHER TANK ··· REPLACEMENT	0.9
512131	10	FRONT WINDOW WASHER NOZZLE ··· REPLACEMENT (One piece)	0.3
512231	10	REAR WINDOW WASHER NOZZLE ··· REPLACEMENT (One piece)	0.4
512332	10	HEADLAMP WASHER TUBE ··· REPLACEMENT (All)	0.8
512335	10	HEADLAMP WASHER ACTUATOR ··· REPLACEMENT (One piece)	0.8
513010	10	REAR VIEW MIRROR ASSEMBLY ··· REPLACEMENT (One side)	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
513060	10	SIDE UNDER MIRROR ··· REPLACEMENT	0.3
514110	10	FRONT BUMPER ASSEMBLY ··· REPLACEMENT	0.7
514121	10	FRONT BUMPER FACE ··· REPLACEMENT	1.3
514155	10	FRONT BUMPER GARNISH ··· REPLACEMENT	0.9
514210	10	REAR BUMPER ASSEMBLY ··· REPLACEMENT	0.7
514221	10	REAR BUMPER FACE ··· REPLACEMENT	0.7
515025	10	REAR AIR SPOILER ··· REPLACEMENT	0.4
515062	10	SIDE AIR SPOILER (CENTER) ··· REPLACEMENT (One side)	0.4
516111	10	FRONT GRILLE ··· REPLACEMENT (One piece)	1.0
516112	10	FRONT LOWER (UNDER) GRILLE ··· REPLACEMENT (One piece)	0.9
516116	10	FRONT DECK GARNISH ··· REPLACEMENT	0.5
516155	10	FENDER GARNISH ··· REPLACEMENT (One piece)	0.3
516211	10	FRONT WINDOW MOULDING ··· REPLACEMENT (All)	3.1
516233	10	DRIP RAIL MOULDING ··· REPLACEMENT (One piece)	0.3
516246	10	ROOF WINDOW FRONT MOULDING ··· REPLACEMENT	1.5
516247	10	ROOF WINDOW REAR MOULDING ··· REPLACEMENT	0.7
516252	10	FRONT DOOR BELT LINE MOULDING ··· REPLACEMENT (One side)	0.7
516262	10	REAR DOOR BELT LINE MOULDING ··· REPLACEMENT (One side)	0.7
516411	10	FRONT MARK ··· REPLACEMENT (One piece)	0.3
516421	10	REAR MARK ··· REPLACEMENT (One piece)	0.3
516461	10	FRONT DOOR SASH BLACK OUT TAPE (OUTSIDE) ··· REPLACEMENT (One side)	1.0
516463	10	REAR DOOR SASH BLACK OUT TAPE (OUTSIDE) ··· REPLACEMENT (One side)	1.3
517015	10	REAR MUDGUARD ··· REPLACEMENT (One side)	0.4
517043	10	ROOF RAIL ASSEMBLY ··· REPLACEMENT	0.3
518101	10	WIPER MOTOR (FRONT WINDOW) ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
518102	10	WIPER MOTOR (REAR WINDOW) ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
518111	10	WASHER MOTOR (FRONT WINDOW) ··· REPLACEMENT	0.8
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
518113	10	WASHER MOTOR (HEADLAMP) ··· REPLACEMENT	0.8
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
518201	10	WIPER SWITCH (FRONT WINDOW) ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
518241	10	REMOTE CONTROL MIRROR SWITCH ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
518421	10	HEADLAMP WASHER CONTROL RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
521120	10	FRONT SEAT CUSHION ASSEMBLY (DRIVER) ··· REPLACEMENT	0.7
521121	10	FRONT SEAT CUSHION COVER (DRIVER) ··· REPLACEMENT	1.3
521130	10	FRONT SEAT BACK ASSEMBLY (DRIVER) ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Side SRS module ··· inspection by multi-use tester	0.2
521131	10	FRONT SEAT BACK COVER (DRIVER) ··· REPLACEMENT	1.0
521141	10	FRONT SEAT HEAD RESTRAINT (DRIVER) ··· REPLACEMENT	0.2
521152	10	FRONT SEAT SLIDE ADJUSTER (DRIVER) ··· REPLACEMENT	1.0
		[Additional time allowance]	
		B1 ··· With front power seat	0.3
521158	10	FRONT SEAT SLIDE ANCHOR COVER (DRIVER) ··· REPLACEMENT	0.3
521220	10	FRONT SEAT CUSHION ASSEMBLY (PASSENGER) ··· REPLACEMENT	0.7
521221	10	FRONT SEAT CUSHION COVER (PASSENGER) ··· REPLACEMENT	1.2
521230	10	FRONT SEAT BACK ASSEMBLY (PASSENGER) ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Side SRS module ··· inspection by multi-use tester	0.2
521231	10	FRONT SEAT BACK COVER (PASSENGER) ··· REPLACEMENT	1.0
521241	10	FRONT SEAT HEAD RESTRAINT (PASSENGER) ··· REPLACEMENT	0.2
521252	10	FRONT SEAT SLIDE ADJUSTER (PASSENGER) ··· REPLACEMENT	1.0
521258	10	FRONT SEAT SLIDE ANCHOR COVER (PASSENGER) ··· REPLACEMENT	0.3
521520	10	REAR SEAT CUSHION ASSEMBLY ··· REPLACEMENT (One piece)	0.3
521521	10	REAR SEAT CUSHION COVER ··· REPLACEMENT (One piece)	0.9
521530	10	REAR SEAT BACK ASSEMBLY ··· REPLACEMENT (One piece)	0.3
521531	80	REAR SEAT BACK COVER (LEFT SIDE) ··· REPLACEMENT	0.8
521531	82	REAR SEAT BACK COVER (RIGHT SIDE) ··· REPLACEMENT	0.6
521532	10	REAR SEAT BACK ARMREST ··· REPLACEMENT (One piece)	0.3
521541	10	REAR SEAT HEAD RESTRAINT ··· REPLACEMENT (One piece)	0.2
521593	80	REAR SEAT BACK LOCK ASSY (LEFT SIDE) ··· REPLACEMENT	0.6
521593	82	REAR SEAT BACK LOCK ASSY (RIGHT SIDE) ··· REPLACEMENT	0.5
522011	10	FRONT SEAT BELT RETRACTOR (DRIVER) ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Pre-tensioner (squib) ··· inspection by multi-use tester	0.2
522012	10	FRONT SEAT BELT BUCKLE STALK (DRIVER) ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
522013	10	FRONT SEAT BELT ANCHOR PLATE ··· REPLACEMENT	0.5
522021	10	FRONT SEAT BELT RETRACTOR (PASSENGER) ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Pre-tensioner (squib) ··· inspection by multi-use tester	0.2
522022	10	FRONT SEAT BELT BUCKLE STALK (PASSENGER) ··· REPLACEMENT	0.5
		[Additional operation]	

OPERATION			GA0W
CODE		DESCRIPTION	
		A9 ··· Inspection by multi-use tester	0.2
522023	10	FRONT SEAT BELT ANCHOR PLATE (PASSENGER) ··· REPLACEMENT	0.6
522052	10	REAR (SECOND) SEAT BELT RETRACTOR ··· REPLACEMENT (One piece)	0.7
522053	10	REAR (SECOND) SEAT BELT BUCKLE STALK ··· REPLACEMENT (One piece)	0.3
522081	10	REAR (SECOND) SEAT BELT RETRACTOR (CENTER) ··· REPLACEMENT	0.7
523110	10	INSTRUMENT PANEL ASSEMBLY ··· REPLACEMENT	1.4
523111	10	INSTRUMENT PANEL ··· REPLACEMENT	1.8
523114	10	INSTRUMENT PANEL METER HOOD (COVER) ··· REPLACEMENT	0.3
523116	10	INSTRUMENT PANEL LOWER COVER ··· REPLACEMENT	0.4
523117	10	INSTRUMENT CENTER PANEL ASSEMBLY ··· REPLACEMENT	0.4
523130	10	INSTRUMENT PANEL GLOVEBOX ASSEMBLY ··· REPLACEMENT	0.3
523138	10	INSTRUMENT PANEL GLOVEBOX DUMPER ··· REPLACEMENT	0.3
523161	10	INSTRUMENT PANEL OUTLET (GARNISH) (CENTER) ··· REPLACEMENT (One piece)	0.4
523162	10	INSTRUMENT PANEL OUTLET (GARNISH) (SIDE) ··· REPLACEMENT (One piece)	0.2
523311	10	FLOOR CONSOLE (FRONT) ··· REPLACEMENT	0.5
523312	10	FLOOR CONSOLE (REAR) ··· REPLACEMENT	0.3
523313	10	FLOOR CONSOLE PANEL ··· REPLACEMENT	0.3
523345	10	FLOOR CONSOLE PARCEL (ACCESSORY) BOX ··· REPLACEMENT	0.5
523346	10	FLOOR CONSOLE PARCEL (ACCESSORY) BOX LID ··· REPLACEMENT	0.3
524101	10	HEADLINING ··· REPLACEMENT	1.9
		[Additional operation]	
		A3 ··· Headlining garnish - R&I	0.3
524109	10	HEADLINING GARNISH ··· REPLACEMENT (One piece)	2.2
524110	10	FLOOR CARPET (MAT) ASSEMBLY ··· REPLACEMENT (All)	1.4
524113	10	TRUNK (CARGO) FLOOR CARPET (MAT) ··· REPLACEMENT	0.2
524120	10	ELECTRIC SUNSHADE ASSY ··· REPLACEMENT	2.4
		[Additional operation]	
		A1 ··· Curtain air bag module - R&I	0.4
524121	10	ELECTRIC SUNSHADE DRIVE CABLE ··· REPLACEMENT	2.6
		[Additional operation]	
		A1 ··· Curtain air bag module - R&I	0.4
524122	10	ELECTRIC SUNSHADE SUNSHADE (FRONT) ··· REPLACEMENT	2.5
		[Additional operation]	
		A1 ··· Curtain air bag module - R&I	0.4
524123	10	ELECTRIC SUNSHADE SUNSHADE (CENTER) ··· REPLACEMENT	2.5
		[Additional operation]	
		A1 ··· Curtain air bag module - R&I	0.4
524124	10	ELECTRIC SUNSHADE SUNSHADE (REAR) ··· REPLACEMENT	2.5
		[Additional operation]	
		A1 ··· Curtain air bag module - R&I	0.4
524125	10	ELECTRIC SUNSHADE HOUSING ··· REPLACEMENT	2.6
		[Additional operation]	
		A1 ··· Curtain air bag module - R&I	0.4
524221	10	REAR SHELF TRIM (CENTER) ··· REPLACEMENT	0.2
524224	10	REAR END TRIM ··· REPLACEMENT	0.3
524231	10	FRONT PILLAR TRIM ··· REPLACEMENT (One piece)	0.3
524236	10	SCUFF PLATE (FRONT) ··· REPLACEMENT (One piece)	0.2
524237	10	SCUFF PLATE (REAR) ··· REPLACEMENT (One piece)	0.3
524249	80	QUARTER TRIM (UPPER) (PASSENGER) ··· REPLACEMENT	0.7
524249	82	QUARTER TRIM (UPPER) (DRIVER) ··· REPLACEMENT	0.6
524250	10	QUARTER TRIM (LOWER) ··· REPLACEMENT (One piece)	0.6
524260	10	FRONT DOOR TRIM ASSEMBLY ··· REPLACEMENT (One piece)	0.4
524270	10	REAR (SLIDE) DOOR TRIM ASSEMBLY ··· REPLACEMENT (One piece)	0.4
524281	10	TAILGATE (BACK DOOR) TRIM (UPPER) ··· REPLACEMENT (One piece)	0.2
524282	10	TAILGATE (BACK DOOR) TRIM (LOWER) ··· REPLACEMENT	0.3
524283	10	TAILGATE (BACK DOOR) TRIM (SIDE) ··· REPLACEMENT (One piece)	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
524311	10	CENTER PILLAR TRIM (UPPER) ･･･ REPLACEMENT (One side)	0.5
524312	10	CENTER PILLAR TRIM (LOWER) ･･･ REPLACEMENT (One side)	0.3
525010	10	SRS MODULE ･･･ REPLACEMENT	0.3
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
525020	10	SRS MODULE (PASSENGER SIDE) ･･･ REPLACEMENT	1.5
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
525030	10	CURTAIN AIR BAG MODULE ･･･ REPLACEMENT (One piece)	2.2
		[Additional operation]	
		01 ･･･ Per 1 pc.	0.2
		A9 ･･･ Inspection by multi-use tester	0.2
525040	10	KNEE AIR BAG MODULE ･･･ REPLACEMENT	0.4
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
527071	10	ARM REST ･･･ REPLACEMENT (One piece)	0.4
527072	10	PULL HANDLE ･･･ REPLACEMENT (One piece)	0.3
527074	10	ASSIST GRIP ･･･ REPLACEMENT (One piece)	0.3
527077	10	ROOM MIRROR ･･･ REPLACEMENT	0.3
527078	10	SUN VISOR & SUNSHADE ･･･ REPLACEMENT (One piece)	0.3
527081	10	FOOT REST ･･･ REPLACEMENT	0.3
528130	10	ELECTRIC SUNSHADE MOTOR ･･･ REPLACEMENT	2.1
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
528201	10	FRONT SEAT HEATER SWITCH ･･･ REPLACEMENT (One piece)	0.3
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
528211	10	POWER SEAT SWITCH ･･･ REPLACEMENT (One piece)	0.5
528265	10	ELECTRIC SUNSHADE SWITCH ･･･ REPLACEMENT	0.3
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
528271	10	PASSENGER SIDE AIR BAG CUT OFF SWITCH ･･･ REPLACEMENT	0.3
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
528311	84	FRONT IMPACT SENSOR (RIGHT SIDE) ･･･ REPLACEMENT	0.3
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
528311	86	FRONT IMPACT SENSOR (LEFT SIDE) ･･･ REPLACEMENT	0.4
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
528322	10	SIDE IMPACT SENSOR (FRONT) ･･･ REPLACEMENT (One side)	0.4
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
528323	10	SIDE IMPACT SENSOR (REAR) ･･･ REPLACEMENT (One side)	0.6
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
528421	10	HEATED SEAT RELAY ･･･ REPLACEMENT	0.3
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
528511	10	SRS DIAGNOSIS UNIT ･･･ REPLACEMENT	0.8
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2
541001	10	FRONT EXTERIOR LAMP BULB ･･･ REPLACEMENT (One piece)	0.2
541010	10	HEADLAMP ASSEMBLY ･･･ REPLACEMENT (One piece)	0.8
		[Additional operation]	
		A9 ･･･ Inspection by multi-use tester	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
541010	93	HEADLAMP ··· AIMING	0.3
541011	10	HEADLAMP UNIT ··· REPLACEMENT (One piece)	1.0
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
541013	10	HEADLAMP BULB ··· REPLACEMENT (One piece)	0.3
		[Additional operation]	
		A1 ··· Headlamp unit R&I (for discharge headlamp)	0.6
		A9 ··· Inspection by multi-use tester	0.2
541032	10	FRONT TURN SIGNAL LAMP BULB ··· REPLACEMENT (One side)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
541040	10	FRONT SIDE TURN SIGNAL LAMP ASSEMBLY ··· REPLACEMENT (One side)	0.2
		[Additional operation]	
		A1 ··· Rear view mirror assy – R&I	0.4
		A9 ··· Inspection by multi-use tester	0.2
541060	10	FRONT PARKING (CLEARANCE) LAMP ASSEMBLY ··· REPLACEMENT (One side)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
541070	10	FRONT FOG LAMP ASSEMBLY ··· REPLACEMENT (One side)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
541070	93	FOG LAMP ··· AIMING	0.2
541305	10	TAILGATE COMBINATION LAMP ASSEMBLY ··· REPLACEMENT (One side)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
541310	10	REAR COMBINATION LAMP ASSEMBLY ··· REPLACEMENT (One side)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
541311	10	REAR COMBINATION LAMP UNIT ··· REPLACEMENT (One side)	0.3
541315	10	REAR COMBINATION LAMP SOCKET ASSEMBLY ··· REPLACEMENT (One side)	0.3
541350	10	LICENCE PLATE LAMP ASSEMBLY ··· REPLACEMENT (One piece)	0.2
541370	10	REFLEX REFLECTOR ASSEMBLY ··· REPLACEMENT (One side)	0.7
541380	10	REAR FOG LAMP ASSEMBLY ··· REPLACEMENT (One piece)	0.2
541390	10	HIGH MOUNT STOP LAMP ··· REPLACEMENT	0.4
541801	10	INTERIOR LAMP BULB ··· REPLACEMENT (One piece)	0.2
541810	84	ROOM LAMP ASSEMBLY (FRONT) ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
541810	86	ROOM LAMP ASSEMBLY (REAR) ··· REPLACEMENT	1.9
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
541830	10	CARGO ROOM (LUGGAGE COMPARTMENT) LAMP ASSEMBLY	
		··· REPLACEMENT (One piece)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
541891	10	ILLUMINATION LAMP ··· REPLACEMENT (One piece)	2.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
542010	10	COMBINATION METER ASSEMBLY ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
543010	10	BATTERY ··· REPLACEMENT (One piece)	0.4
		[Additional operation]	
		A9 ··· Test & inspection	0.2
543010	52	BATTERY ··· ELECTRICAL CHARGE (One piece)	0.2
543501	10	FUSE ··· REPLACEMENT	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
543511	10	BATTERY CABLE (+) ··· REPLACEMENT (One piece)	
		4B1	1.5
		[Additional time allowance]	
		B1 ··· Automatic transmission	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
		4N1	1.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
543512	10	BATTERY CABLE (−) ··· REPLACEMENT (One piece)	0.5
		[Additional time allowance]	
		J1 ··· Manual transmission	0.7
		[Additional operation]	
		A1 ··· Theft prevention engine ECU cover − R&I	0.5
		A9 ··· Inspection by multi-use tester	0.2
543530	10	FUSIBLE LINK ASSEMBLY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
543541	10	INSTRUMENT PANEL HARNESS (WIRING HARNESS A) ··· REPLACEMENT	3.5
		[Additional operation]	
		A7 ··· Steering wheel angular velocity sensor zero−calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
543542	10	BODY (FRONT) HARNESS (WIRING HARNESS B) ··· REPLACEMENT	6.6
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero−calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
543543	10	BODY (REAR) HARNESS (WIRING HARNESS C) ··· REPLACEMENT	3.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
543544	10	ROOF HARNESS ··· REPLACEMENT	3.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
543555	10	REAR GATE HARNESS ··· REPLACEMENT	2.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
543563	10	ENGINE CONTROL HARNESS ··· REPLACEMENT	1.5
		[Additional operation]	
		A1 ··· Theft prevention engine ECU cover − R&I	0.5
		A9 ··· Inspection by multi-use tester	0.2
543566	10	FRONT DOOR HARNESS ··· REPLACEMENT (One side)	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
543567	10	REAR DOOR HARNESS ··· REPLACEMENT (One side)	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
544011	10	HORN ··· REPLACEMENT (One piece)	0.3
		[Additional operation]	
		A1 ··· Front bumper assy − R&I	0.4
		A9 ··· Inspection by multi-use tester	0.2
544012	10	THEFT−ALARM HORN ··· REPLACEMENT	0.3
		[Additional time allowance]	
		H6 ··· Right−hand drive	1.1
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
544013	10	SECURITY ALARM SIREN ··· REPLACEMENT	0.4
		[Additional time allowance]	

OPERATION			GA0W
CODE		DESCRIPTION	
		H6 ··· Right-hand drive	1.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
545013	10	AUDIO (CASSETTE STEREO ASSEMBLY) ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
545014	10	AUDIO POWER AMPLIFIER ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
545033	10	DOOR SPEAKER ··· REPLACEMENT (One piece)	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
545035	10	REAR SPEAKER WOOFER ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
545041	10	FRONT DOOR TWEETER SPEAKER ··· REPLACEMENT (One piece)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
545043	10	REAR DOOR SPEAKER ··· REPLACEMENT (One piece)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
545051	10	ANTENNA ASSEMBLY ··· REPLACEMENT	2.0
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
545052	10	ANTENNA POLE ··· REPLACEMENT	0.2
545055	10	ANTENNA FEEDER ··· REPLACEMENT	2.3
		[Additional time allowance]	
		H6 ··· Right-hand drive	1.0
		[Additional operation]	
		A1 ··· Curtain air bag module - R&I	0.2
		A3 ··· DC/DC converter - R&I	0.2
		A9 ··· Inspection by multi-use tester	0.2
545093	10	USB ADAPTOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
545094	10	USB BOX ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
547015	10	CLOCK SPRING (SRS) ··· REPLACEMENT	0.5
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
547020	10	CIGARETTE LIGHTER ASSEMBLY ··· REPLACEMENT (One piece)	0.5
547025	25	REAR WINDOW DEFOGGER ··· REPAIR	0.6
547042	10	MICROPHONE ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
547046	10	HAND FREE REMOTE CONTROL SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
547047	10	HAND FREE MODULE ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
547053	10	NAVIGATION UNIT ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
547054	10	GPS ANTENNA ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
547067	10	AUDIO AND VIDEO ADAPTOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
547070	10	REAR VIEW MONITOR CAMERA ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
547091	10	IMMOBILIZER KEY RING ANTENNA ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
547092	10	IMMOBILIZER TRANSPONDER ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548201	84	DOOR SWITCH (FRONT) ··· REPLACEMENT (One piece)	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548201	86	DOOR SWITCH (REAR) ··· REPLACEMENT (One piece)	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548211	10	COLUMN (COMBINATION, LEVER) SWITCH ··· REPLACEMENT	0.5
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
548212	10	TURN SIGNAL & LIGHTING SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548215	10	HAZARD WARNING LAMP SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548243	10	SUNSHADE ILLUMINATION SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548255	10	COMBINATION METER INFORMATION SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548261	10	IGNITION SWITCH / ELECTRIC MOTOR SWITCH ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548263	10	KEY REMINDER SWITCH ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548264	10	ENGINE SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548266	10	HEADLAMP LEVELING SWITCH ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548271	10	RADIO REMOTE CONTROL SWITCH ··· REPLACEMENT	0.4
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
548305	10	BATTERY CURRENT SENSOR ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2

OPERATION			GA0W
CODE		DESCRIPTION	
548311	10	AUTO LIGHTING CONTROL SENSOR ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548312	10	FRONT HEIGHT SENSOR (HEAD LAMP AUTO LEVELING) ··· REPLACEMENT	0.8
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548313	10	REAR HEIGHT SENSOR (HEAD LAMP AUTO LEVELING) ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548331	10	VEHICLE SPEED SENSOR ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548353	10	BACK SONAR SENSOR ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548356	10	CORNER SENSOR (REAR SIDE) ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548361	10	SECURITY ALARM SENSOR ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548412	10	HEADLAMP LIGHTING RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548415	10	DAYTIME RUNNING LIGHT RELAY ··· REPLACEMENT (One piece)	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548420	10	STOP LAMP RELAY ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548421	10	FOG LAMP RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548461	10	HORN RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548462	10	THEFT-ALARM HORN RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548471	10	DEFOGGER RELAY ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548501	10	ETACS CONTROL UNIT ··· REPLACEMENT	1.0
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548509	10	ONE-TOUCH START SYSTEM CONTROL UNIT ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548515	10	HEAD LAMP AUTO LEVELING ECU ··· REPLACEMENT	0.6
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548525	10	DC/DC CONVERTER CONTROL UNIT ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548552	10	CORNER SENSOR CONTROL UNIT ··· REPLACEMENT	0.4
		[Additional operation]	

OPERATION			GA0W
CODE		DESCRIPTION	
		A9 ··· Inspection by multi-use tester	0.2
548571	10	IMMOBILIZER CONTROL UNIT ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548575	10	LIN CUTOFF CONTROL UNIT ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548581	10	DISCHARGE HEADLAMP CONTROL UNIT ··· REPLACEMENT (One piece)	0.9
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
548920	10	CAN BOX UNIT ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
550000	90	REFRIGERANT CHARGE, AIR CONDITIONER	0.5
551110	10	FRONT HEATER ASSEMBLY ··· REPLACEMENT	4.6
		[Additional operation]	
		A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
551115	10	PTC HEATER ··· REPLACEMENT	3.3
		[Additional operation]	
		A8 ··· Steering wheel angular velocity sensor zero-calibration	0.2
551511	10	COOLER EVAPORATOR ASSEMBLY (FRONT) ··· REPLACEMENT	4.9
		[Additional operation]	
		A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
551512	10	EXPANSION VALVE ··· REPLACEMENT	1.0
552011	10	DEFROSTER DUCT ··· REPLACEMENT	1.5
552015	10	SIDE DEFROSTER DUCT ··· REPLACEMENT	1.5
552024	10	CENTER VENTILATOR AIR DUCT ··· REPLACEMENT	1.6
552026	10	REAR HEATER AIR DUCT ··· REPLACEMENT	1.0
552515	10	AIR PURIFIER FILTER ··· REPLACEMENT	0.3
553110	10	COMPRESSOR ASSEMBLY ··· REPLACEMENT	1.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
553112	10	COMPRESSOR RELIEF VALVE ··· REPLACEMENT	1.5
553120	10	MAGNET CLUTCH ASSEMBLY ··· REPLACEMENT	1.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
553210	10	FRONT CONDENSER ASSEMBLY ··· REPLACEMENT	1.6
554010	10	HEATER CONTROL ASSEMBLY ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
555511	10	COOLER (DISCHARGE) HOSE ··· REPLACEMENT (One piece)	1.3
555512	10	COOLER (SUCTION) HOSE ··· REPLACEMENT (One piece)	1.0
555531	10	RECEIVER ··· REPLACEMENT	1.6
558101	10	FRONT BLOWER MOTOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558111	10	CONDENSER FAN MOTOR ··· REPLACEMENT	1.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558121	10	SUCTION PORT CHANGE OVER DAMPER MOTOR ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558122	10	DISCHARGE PORT CHANGEOVER DAMPER MOTOR ··· REPLACEMENT	0.5
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558123	10	AIR MIX DAMPER CONTROL MOTOR ··· REPLACEMENT	0.4

OPERATION			GA0W
CODE		DESCRIPTION	
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558302	10	A/C PRESSURE SENSOR ··· REPLACEMENT	0.8
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558312	10	ROOM TEMPERATURE SENSOR (FOOT) ··· REPLACEMENT	0.4
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558321	10	AIR-INLET SENSOR ··· REPLACEMENT	0.7
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558331	10	FIN SENSOR ··· REPLACEMENT	4.9
		[Additional operation]	
		A7 ··· Steering wheel angular velocity sensor zero-calibration	0.2
		A9 ··· Inspection by multi-use tester	0.2
558403	10	BLOWER MOTOR RELAY ··· REPLACEMENT (One piece)	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558406	10	PTC HEATER RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558411	10	CONDENSER FAN MOTOR RELAY ··· REPLACEMENT (One piece)	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558423	10	AIR COMPRESSOR RELAY ··· REPLACEMENT	0.2
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558512	10	AIR CONDITIONER CONTROLLER ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558515	10	FULL AUTO AIR CONDITIONER CONTROL UNIT ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558901	10	HEATER BLOWER RESISTOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2
558912	10	FULL AUTO AIR CONDITIONER POWER TRANSISTOR ··· REPLACEMENT	0.3
		[Additional operation]	
		A9 ··· Inspection by multi-use tester	0.2

GA0W
PERIODICAL INSPECTION TIME (FOR EUROPE) (ZC)

OPERATION	4B1
12 months or 20,000km inspection	1.9
24 months or 40,000km inspection	2.7
36 months or 60,000km inspection	2.2
48 months or 80,000km inspection	2.7
[Additional time allowance]	
With transfer	0.2
Automatic transmission	0.3
60 months or 100,000km inspection	2.4
72 months or 120,000km inspection	2.9
84 months or 140,000km inspection	1.9
96 months or 160,000km inspection	3.0
[Additional time allowance]	
With transfer	0.2
Automatic transmission	0.3
108 months or 180,000km inspection	2.4
120 months or 200,000km inspection	3.3
[Additional time allowance]	
Automatic transmission	−0.1
132 months or 220,000km inspection	1.9
144 months or 240,000km inspection	2.9
[Additional time allowance]	
With transfer	0.2
Automatic transmission	0.3
156 months or 260,000km inspection	1.9
168 months or 280,000km inspection	2.7
180 months or 300,000km inspection	3.0

GA0W
PERIODICAL INSPECTION TIME (FOR EUROPE) (ZC)

OPERATION	4N1
12 months or 15,000km inspection	1.5
24 months or 30,000km inspection	3.0
36 months or 45,000km inspection	3.4
48 months or 60,000km inspection	3.3
60 months or 75,000km inspection	1.5
[Additional time allowance]	
With transfer	0.1
72 months or 90,000km inspection	4.9
[Additional time allowance]	
With transfer	0.1
84 months or 105,000km inspection	1.5
96 months or 120,000km inspection	3.3
108 months or 135,000km inspection	4.1
120 months or 150,000km inspection	3.0
[Additional time allowance]	
With transfer	0.1
132 months or 165,000km inspection	1.5
144 months or 180,000km inspection	5.2
[Additional time allowance]	
With transfer	0.1
156 months or 195,000km inspection	1.6
168 months or 210,000km inspection	3.0
180 months or 225,000km inspection	4.1
[Additional time allowance]	
With transfer	0.1
192 months or 240,000km inspection	3.3
204 months or 255,000km inspection	1.5
216 months or 270,000km inspection	4.9
[Additional time allowance]	
With transfer	0.1
228 months or 285,000km inspection	1.5
240 months or 300,000km inspection	3.3
[Additional time allowance]	
With transfer	0.1