MITSUBISHI MOTORS

SERVICE BULLETIN

GLOBAL AFTER SALES OFFICE, MITSUBISHI MOTORS CORPORATION

PURPOSE : CHANGE	ISSUE NO. : MSB-14EXM52-001	DATE : 2014-04-25
SUBJECT : CURTAIN AIR BAG MODULES FOR THE REGULATION FMVSS226		<DESTINATION/MODEL> (MMNA/USTP/MEXICO/EUR /RUSSIA/G.EXP/GCC OUTLANDER SPORT/RVR/ASX (GA0W) <M/Y> 13-15
GROUP : INTERIOR(Gr:52A)/SRS AIR BAG(Gr:52B)		

1. Description :

Please refer to the attached document for the information about the change of mention in the applicable service manual.(The curtain air bag modules corresponding to the regulation FMVSS226 has been mounted on the vehicles)

2. Affected service manuals :

Please refer to the attached document (Attached sheet 2)

3. About the details :

Please refer to the attached document (Attached sheets 3-5)

4. Effective time : From the vehicles produced after the middle of April.
(Please see the attached sheet 1 about the details of affected vehicles)

MODEL	VIN		
GA2WXTMHL4M	4A4AP3AU9EE027168	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU7EE027220	US	New Curtain air bag
GA2WXTMHL4M	4A4AP3AU4EE027255	US	New Curtain air bag
GA2WXTMHL4M	4A4AP3AU5EE027359	US	New Curtain air bag
GA2WXTMHL4M	4A4AP3AU0EE027396	US	New Curtain air bag
GA2WXTMHL4M	4A4AP3AU8EE027419	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU6EE027421	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU7EE027427	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU2EE027447	US	New Curtain air bag
GA2WXTXHL4M	4A4AP4AU7EE027448	US	New Curtain air bag
GA2WXTXHL4M	4A4AP4AU2EE027454	US	New Curtain air bag
GA2WXTXHL4M	4A4AP4AU4EE027455	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU5EE027457	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU7EE027461	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU9EE027462	US	New Curtain air bag
GA2WXTXHL4M	4A4AP4AU3EE027463	US	New Curtain air bag
GA2WXTXHL4M	4A4AP4AU5EE027464	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU4EE027465	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU6EE027466	US	New Curtain air bag
GA2WXTMHL4M	4A4AP3AU1EE027469	US	New Curtain air bag
GA2WXTXHLFCS	4A4LM41U9EE027470	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU1EE027472	US	New Curtain air bag
GA2WXTMHL4M	4A4AP3AU7EE027475	US	New Curtain air bag
GA2WXTMHL4M	4A4AP3AU2EE027478	US	New Curtain air bag
GA2WXTXHZL4M	4A4AR4AU0EE027480	US	All new Curtain air bag from here.
GA2WXTXHLFCS	4A4LM41U3EE027481	US	
GA2WXTXHL4M	4A4AP4AU7EE027482	US	
GA2WXTMHL4M	4A4AP3AU6EE027483	US	
GA2WXTMHL4M	4A4AP3AU8EE027484	US	
GA2WXTMHL4M	4A4AP3AUXEE027485	US	
GA2WXTMHL4M	4A4AP3AU1EE027486	US	
GA2WXNSHL4M	4A4AP3AU3EE027487	US	
GA2WXTMHL4M	4A4AP3AU5EE027488	US	
GA2WXTMHL4M	4A4AP3AU7EE027489	US	
GA2WXTMHL4M	4A4AP3AU3EE027490	US	
GA2WXTMHL4M	4A4AP3AU5EE027491	US	
GA2WXTMHL4M	4A4AP3AU7EE027492	US	
GA2WXTXHL4M	4A4AP4AU1EE027493	US	
GA2WXTXHLFCS	4A4LM41U1EE027494	US	
GA2WXTXHLFCS	4A4LM41U3EE027495	US	
GA2WXTXHLFCS	4A4LM41U5EE027496	US	
GA2WXTXHLFCS	4A4LM41U7EE027497	US	
GA2WXTXHL4M	4A4AP4AU0EE027498	US	
GA2WXNSHL4M	4A4AP3AUXEE027499	US	
GA2WXTXHL4M	4A4AP4AU5EE027500	US	
GA2WXTXHL4M	4A4AP4AU7EE027501	US	
GA2WXTXHL4M	4A4AP4AU9EE027502	US	
GA2WXTXHL4M	4A4AP4AU0EE027503	US	
GA2WXTXHL4M	4A4AP4AU2EE027504	US	
GA2WXTXHL4M	4A4AP4AU4EE027505	US	
GA2WXTXHL4M	4A4AP4AU6EE027506	US	
GA2WXTXHL4M	4A4AP4AU8EE027507	US	
GA2WXTXHL4M	4A4AP4AUXEE027508	US	
GA2WXTXHL4M	4A4AP4AU1EE027509	US	

GA2WXTXHL4M	4A4AP4AU8EE027510	US	
GA2WXTXHL4M	4A4AP4AUXEE027511	US	
GA2WXTXHL4M	4A4AP4AU1EE027512	US	
GA2WXTXHL4M	4A4AP4AU3EE027513	US	
GA2WXTXHL4M	4A4AP4AU5EE027514	US	
GA2WXTXHLFCS	4A4LM41U5EE027515	US	
GA2WXTXHL4M	4A4AP4AU9EE027516	US	
GA2WXTXHL4M	4A4AP4AU0EE027517	US	
GA2WXTXHLFCS	4A4LM41U0EE027518	US	
GA2WXTXHLFCS	4A4LM41U2EE027519	US	
GA2WXTXHLFCS	4A4LM41U9EE027520	US	
GA2WXTXHLFCS	4A4LM41U0EE027521	US	
GA2WXTXHLFCS	4A4LM41U2EE027522	US	
GA2WXTXHLFCS	4A4LM41U4EE027523	US	
GA2WXTXHLFCS	4A4LM41U6EE027524	US	
GA2WXTXHL4M	4A4AP4AUXEE027525	US	
GA2WXTXHL4M	4A4AP4AU1EE027526	US	
GA2WXTXHLFCS	4A4LM41U1EE027527	US	
GA2WXTXHLFCS	4A4LM41U3EE027528	US	
GA2WXTMHL4M	4A4AP3AU4EE027529	US	
GA2WXTMHL4M	4A4AP3AU0EE027530	US	
GA2WXTMHZL4M	4A4AR3AUXEE027531	US	
GA2WXTMHL4M	4A4AP3AU4EE027532	US	
GA2WXTMHL4M	4A4AP3AU6EE027533	US	
GA2WXTMHZL4M	4A4AR3AU5EE027534	US	
GA2WXTMHL4M	4A4AP3AUXEE027535	US	
GA2WXTXHL4M	4A4AP4AU4EE027536	US	
GA2WXTMHZL4M	4A4AR3AU0EE027537	US	
GA2WXTMHL4M	4A4AP3AU5EE027538	US	
GA2WXTMHL4M	4A4AP3AU7EE027539	US	
GA2WXTMHL4M	4A4AP3AU3EE027540	US	
GA2WXTMHL4M	4A4AP3AU5EE027541	US	
GA2WXTMHL4M	4A4AP3AU7EE027542	US	
GA2WXTXHL4M	4A4AP4AU1EE027543	US	
GA2WXTMHZL4M	4A4AR3AU8EE027544	US	
GA2WXTMHL4M	4A4AP3AU2EE027545	US	
GA2WXTMHL4M	4A4AP3AU4EE027546	US	
GA2WXTMHL4M	4A4AP3AU6EE027547	US	
GA2WXTMHL4M	4A4AP3AU8EE027548	US	
GA2WXTMHL4M	4A4AP3AUXEE027549	US	
GA2WXTXHZL4M	4A4AR4AU6EE027550	US	
GA2WXTMHL4M	4A4AP3AU8EE027551	US	
GA2WXTMHL4M	4A4AP3AUXEE027552	US	
GA2WXTMHZL4M	4A4AR3AU9EE027553	US	
GA2WXTMHZL4M	4A4AR3AU0EE027554	US	
GA2WXTXHZL4M	4A4AR4AU5EE027555	US	
GA2WXTMHL4M	4A4AP3AU7EE027556	US	
GA2WXTMHL4M	4A4AP3AU9EE027557	US	
GA2WXTMHL4M	4A4AP3AU0EE027558	US	
GA2WXTMHL4M	4A4AP3AU2EE027559	US	
GA2WXTXHZL4M	4A4AR4AU9EE027560	US	
GA2WXTMHL4M	4A4AP3AU0EE027561	US	
GA2WXTMHL4M	4A4AP3AU2EE027562	US	
GA2WXTMHL4M	4A4AP3AU4EE027563	US	
GA2WXTXHZL4M	4A4AR4AU6EE027564	US	

GA2WXTMHL4M	4A4AP3AU8EE027565	US	
GA2WXTMHL4M	4A4AP3AUXEE027566	US	
GA2WXTXHZL4M	4A4AR4AU1EE027567	US	
GA2WXTXHZL4M	4A4AR4AU3EE027568	US	
GA2WXTMHL4M	4A4AP3AU5EE027569	US	
GA2WXTMHZL4M	4A4AR3AU9EE027570	US	
GA2WXTMHZL4M	4A4AR3AU0EE027571	US	
GA2WXTMHL4M	4A4AP3AU5EE027572	US	
GA2WXTMHL4M	4A4AP3AU7EE027573	US	
GA2WXTMHZL4M	4A4AR3AU6EE027574	US	
GA2WXTXHZL4M	4A4AR4AU0EE027575	US	
GA2WXTMHL4M	4A4AP3AU2EE027576	US	
GA2WXTMHZL4M	4A4AR3AU1EE027577	US	
GA2WXTMHZL4M	4A4AR3AU3EE027578	US	
GA2WXTMHL4M	4A4AP3AU8EE027579	US	
GA2WXTMHL4M	4A4AP3AU4EE027580	US	
GA2WXTMHZL4M	4A4AR3AU3EE027581	US	
GA2WXTXHZL4M	4A4AR4AU8EE027582	US	
GA2WXTMHL4M	4A4AP3AUXEE027583	US	
GA2WXTMHZL4M	4A4AR3AU9EE027584	US	
GA2WXTMHZL4M	4A4AR3AU0EE027585	US	
GA2WXNSHL4M	4A4AP3AU5EE027586	US	
GA2WXTMHL4M	4A4AP3AU7EE027587	US	
GA2WXTMHZL4M	4A4AR3AU6EE027588	US	
GA2WXTXHZL4M	4A4AR4AU0EE027589	US	
GA2WXTMHZL4M	4A4AR3AU4EE027590	US	
GA2WXTMHL4M	4A4AP3AU9EE027591	US	
GA2WXTMHL4M	4A4AP3AU0EE027592	US	
GA2WXTMHZL4M	4A4AR3AUXEE027593	US	
GA2WXTMHL4M	4A4AP3AU4EE027594	US	
GA2WXTMHZL4M	4A4AR3AU3EE027595	US	
GA2WXTXHZL4M	4A4AR4AU8EE027596	US	
GA2WXTMHZL4M	4A4AR3AU7EE027597	US	
GA2WXTMHL4M	4A4AP3AU1EE027598	US	
GA2WXTMHL4M	4A4AP3AU3EE027599	US	
GA2WXTXHZL4M	4A4AR4AU6EE027600	US	
GA2WXTMHL4M	4A4AP3AU8EE027601	US	
GA2WXTXHZL4M	4A4AR4AUXEE027602	US	
GA2WXTMHL4M	4A4AP3AU1EE027603	US	
GA2WXTXHZL4M	4A4AR4AU3EE027604	US	
GA2WXTMHL4M	4A4AP3AU5EE027605	US	
GA2WXTXHZL4M	4A4AR4AU7EE027606	US	
GA2WXTXHZL4M	4A4AR4AU9EE027607	US	
GA2WXTXHZL4M	4A4AR4AU0EE027608	US	
GA2WXTXHZL4M	4A4AR4AU2EE027609	US	
GA2WXTXHL4M	4A4AP4AU1EE027610	US	
GA2WXTXHZL4M	4A4AR4AU0EE027611	US	
GA2WXTXHL4M	4A4AP4AU5EE027612	US	
GA2WXTXHZL4M	4A4AR4AU4EE027613	US	
GA2WXTXHZL4M	4A4AR4AU6EE027614	US	
GA2WXTXHZL4M	4A4AR4AU8EE027615	US	
GA2WXTMHZL4M	4A4AR3AU7EE027616	US	
GA2WXNSHL4M	4A4AP3AU1EE027617	US	
GA2WXTMHL4M	4A4AP3AU3EE027618	US	
GA2WXTMHZL4M	4A4AR3AU2EE027619	US	

GA2WXTMHZL4M	4A4AR3AU9EE027620	US	
GA2WXTXHL4M	4A4AP4AU6EE027621	US	
GA2WXTXHL4M	4A4AP4AU8EE027622	US	
GA2WXTXHL4M	4A4AP4AUXEE027623	US	
GA2WXTXHL4M	4A4AP4AU1EE027624	US	
GA2WXTXHL4M	4A4AP4AU3EE027625	US	
GA2WXTXHL4M	4A4AP4AU5EE027626	US	
GA2WXTXHL4M	4A4AP4AU7EE027627	US	
GA2WXTMHZL4M	4A4AR3AU3EE027628	US	
GA2WXTMHZL4M	4A4AR3AU5EE027629	US	
GA2WXTMHL4M	4A4AP3AU4EE027630	US	
GA2WXTXHL4M	4A4AP4AU9EE027631	US	
GA2WXTMHL4M	4A4AP3AU8EE027632	US	
GA2WXTMHZL4M	4A4AR3AU7EE027633	US	
GA2WXTXHL4M	4A4AP4AU4EE027634	US	
GA2WXTXHL4M	4A4AP4AU6EE027635	US	
GA2WXTXHL4M	4A4AP4AU8EE027636	US	
GA2WXTXHL4M	4A4AP4AUXEE027637	US	
GA2WXTXHL4M	4A4AP4AU1EE027638	US	
GA2WXTMHZL4M	4A4AR3AU8EE027639	US	
GA2WXTXHZL4M	4A4AR4AU7EE027640	US	
GA2WXTMHL4M	4A4AP3AU9EE027641	US	
GA2WXTMHL4M	4A4AP3AU0EE027642	US	
GA2WXTMHL4M	4A4AP3AU2EE027643	US	
GA2WXTXHLFCS	4A4LM41U5EE027644	US	
GA2WXTXHLFCS	4A4LM41U7EE027645	US	
GA2WXTXHLFCS	4A4LM41U9EE027646	US	
GA2WXTXHLFCS	4A4LM41U0EE027647	US	
GA2WXTXHLFCS	4A4LM41U2EE027648	US	
GA2WXTXHLFCS	4A4LM41U4EE027649	US	
GA2WXTMHL4M	4A4AP3AUXEE027650	US	
GA2WXTMHL4M	4A4AP3AU1EE027651	US	
GA2WXTMHL4M	4A4AP3AU3EE027652	US	
GA2WXNSHL4M	4A4AP3AU5EE027653	US	
GA2WXTMHL4M	4A4AP3AU7EE027654	US	
GA2WXTMHL4M	4A4AP3AU9EE027655	US	
GA2WXTMHZL4M	4A4AR3AU8EE027656	US	
GA2WXTMHZL4M	4A4AR3AUXEE027657	US	
GA2WXTMHL4M	4A4AP3AU4EE027658	US	
GA2WXTMHL4M	4A4AP3AU6EE027659	US	
GA2WXTMHL4M	4A4AP3AU2EE027660	US	
GA2WXTMHL4M	4A4AP3AU4EE027661	US	
GA2WXTMHZL4M	4A4AR3AU3EE027662	US	
GA2WXTMHZL4M	4A4AR3AU5EE027663	US	
GA2WXTMHL4M	4A4AP3AUXEE027664	US	
GA2WXTMHL4M	4A4AP3AU1EE027665	US	
GA2WXTMHL4M	4A4AP3AU3EE027666	US	
GA2WXTMHL4M	4A4AP3AU5EE027667	US	
GA2WXTMHZL4M	4A4AR3AU4EE027668	US	
GA2WXTMHZL4M	4A4AR3AU6EE027669	US	
GA2WXTMHL4M	4A4AP3AU5EE027670	US	
GA2WXTMHL4M	4A4AP3AU7EE027671	US	
GA2WXNSHL4M	4A4AP3AU9EE027672	US	
GA2WXTMHL4M	4A4AP3AU0EE027673	US	
GA2WXTMHZL4M	4A4AR3AUXEE027674	US	

GA2WXTMHL4M	4A4AP3AU4EE027675	US	
GA2WXTMHL4M	4A4AP3AU6EE027676	US	
GA2WXTMHL4M	4A4AP3AU8EE027677	US	
GA2WXTMHL4M	4A4AP3AUXEE027678	US	
GA2WXTMHL4M	4A4AP3AU1EE027679	US	
GA2WXTMHL4M	4A4AP3AU8EE027680	US	
GA2WXTMHZL4M	4A4AR3AU7EE027681	US	
GA2WXTMHZL4M	4A4AR3AU9EE027682	US	
GA2WXTMHZL4M	4A4AR3AU0EE027683	US	
GA2WXTMHZL4M	4A4AR3AU2EE027684	US	
GA2WXTXHL4M	4A4AP4AUXEE027685	US	
GA2WXTMHL4M	4A4AP3AU9EE027686	US	
GA2WXTMHL4M	4A4AP3AU0EE027687	US	
GA2WXTMHL4M	4A4AP3AU2EE027688	US	
GA2WXTMHZL4M	4A4AR3AU1EE027689	US	
GA2WXTMHL4M	4A4AP3AU0EE027690	US	
GA2WXTMHZL4M	4A4AR3AUXEE027691	US	
GA2WXTMHZL4M	4A4AR3AU1EE027692	US	
GA2WXTXHL4M	4A4AP4AU9EE027693	US	
GA2WXTMHL4M	4A4AP3AU8EE027694	US	
GA2WXTMHL4M	4A4AP3AUXEE027695	US	
GA2WXTMHZL4M	4A4AR3AU9EE027696	US	
GA2WXTMHL4M	4A4AP3AU3EE027697	US	
GA2WXTMHL4M	4A4AP3AU5EE027698	US	
GA2WXTMHZL4M	4A4AR3AU4EE027699	US	
GA2WXTXHZL4M	4A4AR4AUXEE027700	US	
GA2WXTMHZL4M	4A4AR3AU9EE027701	US	
GA2WXTMHL4M	4A4AP3AU3EE027702	US	
GA2WXTMHZL4M	4A4AR3AU2EE027703	US	
GA2WXTMHZL4M	4A4AR3AU4EE027704	US	
GA2WXTMHL4M	4A4AP3AU9EE027705	US	
GA2WXTXHL4M	4A4AP4AU3EE027706	US	
GA2WXTMHL4M	4A4AP3AU2EE027707	US	
GA2WXTMHZL4M	4A4AR3AU1EE027708	US	
GA2WXTMHZL4M	4A4AR3AU3EE027709	US	
GA2WXTMHL4M	4A4AP3AU2EE027710	US	
GA2WXTXHZL4M	4A4AR4AU4EE027711	US	
GA2WXTMHL4M	4A4AP3AU6EE027712	US	
GA2WXTMHL4M	4A4AP3AU8EE027713	US	
GA2WXTMHL4M	4A4AP3AUXEE027714	US	
GA2WXTMHZL4M	4A4AR3AU9EE027715	US	
GA2WXTMHZL4M	4A4AR3AU0EE027716	US	
GA2WXTMHL4M	4A4AP3AU5EE027717	US	
GA2WXTMHL4M	4A4AP3AU7EE027718	US	
GA2WXTXHZL4M	4A4AR4AU9EE027719	US	
GA2WXTMHL4M	4A4AP3AU5EE027720	US	
GA2WXTMHZL4M	4A4AR3AU4EE027721	US	
GA2WXTMHZL4M	4A4AR3AU6EE027722	US	
GA2WXTMHZL4M	4A4AR3AU8EE027723	US	
GA2WXTMHL4M	4A4AP3AU2EE027724	US	
GA2WXTMHL4M	4A4AP3AU4EE027725	US	
GA2WXTMHL4M	4A4AP3AU6EE027726	US	
GA2WXTMHZL4M	4A4AR3AU5EE027727	US	
GA2WXTMHZL4M	4A4AR3AU7EE027728	US	
GA2WXTMHL4M	4A4AP3AU1EE027729	US	

GA2WXTMHL4M	4A4AP3AU8EE027730	US	
GA2WXTXHZL4M	4A4AR4AUXEE027731	US	
GA2WXTXHZL5M	4A4AJ4AUXEE606144		
GA2WXTMHZL5M	4A4AJ3AU2EE606200	CANADA	New Curtain air bag
GA2WXTMHZL5M	4A4AJ3AU7EE606211		
GA2WXTMHZL5M	4A4AJ3AUXEE606218		
GA2WXTXHZL5M	4A4AJ4AU0EE606220		
GA2WXTMHL5M	4A4AH3AU5EE606221	CANADA	New Curtain air bag
GA2WXNSHL5M	4A4AH3AU7EE606222		
GA2WXTXHZL5M	4A4AJ4AU6EE606223		
GA2WXTXHZL5M	4A4AJ4AU8EE606224		
GA2WXTXHZL5M	4A4AJ4AUXEE606225	CANADA	New Curtain air bag
GA2WXTXHZL5M	4A4AJ4AU1EE606226		
GA2WXTXHZL5M	4A4AJ4AU3EE606227		
GA2WXTXHZL5M	4A4AJ4AU5EE606228		
GA2WXTXHZL5M	4A4AJ4AU7EE606229	CANADA	All new Curtain air bag from here.
GA2WXTXHZL5M	4A4AJ4AU3EE606230	CANADA	
GA2WXTMHL5M	4A4AH3AU8EE606231	CANADA	
GA2WXTXHZL5M	4A4AJ4AU7EE606232	CANADA	
GA2WXTXHZL5M	4A4AJ4AU9EE606233	CANADA	
GA2WXTXHZL5M	4A4AJ4AU0EE606234	CANADA	
GA2WXTXHZL5M	4A4AJ4AU2EE606235	CANADA	
GA2WXTXHZL5M	4A4AJ4AU4EE606236	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606237	CANADA	
GA2WXTXHZL5M	4A4AJ4AU8EE606238	CANADA	
GA2WXTMHL5M	4A4AH3AU2EE606239	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606240	CANADA	
GA2WXTXHZL5M	4A4AJ4AU8EE606241	CANADA	
GA2WXTXHZL5M	4A4AJ4AUXEE606242	CANADA	
GA2WXNSHL5M	4A4AH3AU4EE606243	CANADA	
GA2WXTXHZL5M	4A4AJ4AU3EE606244	CANADA	
GA2WXTXHZL5M	4A4AJ4AU5EE606245	CANADA	
GA2WXTXHZL5M	4A4AJ4AU7EE606246	CANADA	
GA2WXTXHZL5M	4A4AJ4AU9EE606247	CANADA	
GA2WXTXHZL5M	4A4AJ4AU0EE606248	CANADA	
GA2WXTXHZL5M	4A4AJ4AU2EE606249	CANADA	
GA2WXTMHL5M	4A4AH3AU1EE606250	CANADA	
GA2WXTMHL5M	4A4AH3AU3EE606251	CANADA	
GA2WXTXHZL5M	4A4AJ4AU2EE606252	CANADA	
GA2WXTXHZL5M	4A4AJ4AU4EE606253	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606254	CANADA	
GA2WXTMHL5M	4A4AH3AU0EE606255	CANADA	
GA2WXTXHZL5M	4A4AJ4AUXEE606256	CANADA	
GA2WXTXHZL5M	4A4AJ4AU1EE606257	CANADA	
GA2WXTXHZL5M	4A4AJ4AU3EE606258	CANADA	
GA2WXTXHZL5M	4A4AJ4AU5EE606259	CANADA	
GA2WXTXHZL5M	4A4AJ4AU1EE606260	CANADA	
GA2WXTXHZL5M	4A4AJ4AU3EE606261	CANADA	
GA2WXTXHZL5M	4A4AJ4AU5EE606262	CANADA	
GA2WXTXHZL5M	4A4AJ4AU7EE606263	CANADA	
GA2WXTMHL5M	4A4AH3AU1EE606264	CANADA	
GA2WXTXHZL5M	4A4AJ4AU0EE606265	CANADA	
GA2WXTXHZL5M	4A4AJ4AU2EE606266	CANADA	
GA2WXTMHL5M	4A4AH3AU7EE606267	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606268	CANADA	

GA2WXTXHZL5M	4A4AJ4AU8EE606269	CANADA	
GA2WXTXHZL5M	4A4AJ4AU4EE606270	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606271	CANADA	
GA2WXTXHZL5M	4A4AJ4AU8EE606272	CANADA	
GA2WXTXHZL5M	4A4AJ4AUXEE606273	CANADA	
GA2WXTXHZL5M	4A4AJ4AU1EE606274	CANADA	
GA2WXTXHZL5M	4A4AJ4AU3EE606275	CANADA	
GA2WXTXHZL5M	4A4AJ4AU5EE606276	CANADA	
GA2WXNSHL5M	4A4AH3AUXEE606277	CANADA	
GA2WXTXHZL5M	4A4AJ4AU9EE606278	CANADA	
GA2WXTXHZL5M	4A4AJ4AU0EE606279	CANADA	
GA2WXTXHZL5M	4A4AJ4AU7EE606280	CANADA	
GA2WXTXHZL5M	4A4AJ4AU9EE606281	CANADA	
GA2WXTXHZL5M	4A4AJ4AU0EE606282	CANADA	
GA2WXTXHZL5M	4A4AJ4AU2EE606283	CANADA	
GA2WXTXHZL5M	4A4AJ4AU4EE606284	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606285	CANADA	
GA2WXTXHZL5M	4A4AJ4AU8EE606286	CANADA	
GA2WXTXHZL5M	4A4AJ4AUXEE606287	CANADA	
GA2WXTXHZL5M	4A4AJ4AU1EE606288	CANADA	
GA2WXTXHZL5M	4A4AJ4AU3EE606289	CANADA	
GA2WXNSHL5M	4A4AH3AU2EE606290	CANADA	
GA2WXTXHZL5M	4A4AJ4AU1EE606291	CANADA	
GA2WXTXHZL5M	4A4AJ4AU3EE606292	CANADA	
GA2WXTXHZL5M	4A4AJ4AU5EE606293	CANADA	
GA2WXTXHZL5M	4A4AJ4AU7EE606294	CANADA	
GA2WXTXHZL5M	4A4AJ4AU9EE606295	CANADA	
GA2WXTXHZL5M	4A4AJ4AU0EE606296	CANADA	
GA2WXTXHZL5M	4A4AJ4AU2EE606297	CANADA	
GA2WXTXHZL5M	4A4AJ4AU4EE606298	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606299	CANADA	
GA2WXTXHZL5M	4A4AJ4AU9EE606300	CANADA	
GA2WXTXHZL5M	4A4AJ4AU0EE606301	CANADA	
GA2WXTXHZL5M	4A4AJ4AU2EE606302	CANADA	
GA2WXNSHL5M	4A4AH3AU7EE606303	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606304	CANADA	
GA2WXTXHZL5M	4A4AJ4AU8EE606305	CANADA	
GA2WXNSHL5M	4A4AH3AU2EE606306	CANADA	
GA2WXTMHZL5M	4A4AJ3AU9EE606307	CANADA	
GA2WXTMHZL5M	4A4AJ3AU0EE606308	CANADA	
GA2WXTMHZL5M	4A4AJ3AU2EE606309	CANADA	
GA2WXTMHZL5M	4A4AJ3AU9EE606310	CANADA	
GA2WXTMHZL5M	4A4AJ3AU0EE606311	CANADA	
GA2WXTMHZL5M	4A4AJ3AU2EE606312	CANADA	
GA2WXTMHZL5M	4A4AJ3AU4EE606313	CANADA	
GA2WXNSHL5M	4A4AH3AU1EE606314	CANADA	
GA2WXTMHL5M	4A4AH3AU3EE606315	CANADA	
GA2WXTMHL5M	4A4AH3AU5EE606316	CANADA	
GA2WXTMHL5M	4A4AH3AU7EE606317	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606318	CANADA	
GA2WXTXHZL5M	4A4AJ4AU8EE606319	CANADA	
GA2WXTXHZL5M	4A4AJ4AU4EE606320	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606321	CANADA	
GA2WXNSHL5M	4A4AH3AU0EE606322	CANADA	
GA2WXTXHZL5M	4A4AJ4AUXEE606323	CANADA	

GA2WXTXHZL5M	4A4AJ4AU1EE606324	CANADA	
GA2WXTXHZL5M	4A4AJ4AU3EE606325	CANADA	
GA2WXTMHZL5M	4A4AJ3AU2EE606326	CANADA	
GA2WXTMHZL5M	4A4AJ3AU4EE606327	CANADA	
GA2WXNSHL5M	4A4AH3AU1EE606328	CANADA	
GA2WXTMHZL5M	4A4AJ3AU8EE606329	CANADA	
GA2WXTXHZL5M	4A4AJ4AU7EE606330	CANADA	
GA2WXTXHZL5M	4A4AJ4AU9EE606331	CANADA	
GA2WXTXHZL5M	4A4AJ4AU0EE606332	CANADA	
GA2WXTXHZL5M	4A4AJ4AU2EE606333	CANADA	
GA2WXTXHZL5M	4A4AJ4AU4EE606334	CANADA	
GA2WXTXHZL5M	4A4AJ4AU6EE606335	CANADA	
GA2WXTXHZL5M	4A4AJ4AU8EE606336	CANADA	
GA2WXTXHZL5M	4A4AJ4AUXEE606337	CANADA	
GA2WXTXHZL5M	4A4AJ4AU1EE606338	CANADA	
GA2WXTXHZL5M	4A4AJ4AU3EE606339	CANADA	
GA2WXTXHZL5M	4A4AJ4AUXEE606340	CANADA	
GA2WXTXHZL5M	4A4AJ4AU1EE606341	CANADA	
GA2WXTMHZL5M	4A4AJ3AU0EE606342	CANADA	
GA2WXTXHZL5M	4A4AJ4AU5EE606343	CANADA	
GA2WXNSHL5M	4A4AH3AUXEE606344	CANADA	
GA2WXTMHZL5M	4A4AJ3AU6EE606345	CANADA	
GA2WXTMHZL5M	4A4AJ3AU8EE606346	CANADA	
GA2WXNSHL5M	4A4AH3AU5EE606347	CANADA	
GA2WXTXHZL5M	4A4AJ4AU4EE606348	CANADA	
GA2WXTMHZL5M	4A4AJ3AU3EE606349	CANADA	

Destination	Applicable manual	Pub. No.	Applicable title (INFO ID)	Contents
EU/ RUSSIA	2013 ASX Workshop Manual	CGAE13E1-CD(ENG) CGAF13E1-CD(FRE) CGAG13E1-CD(GER) CGAS13E1-CD(SPA) CGAI13E1-CD(ITA) RUSSIA:N/A	TRIM REMOVAL AND INSTALLATION (M521-00-112-03100-01)	Attached sheet 3 (1/5)～(4/5)
			CURTAIN AIRBAG MODULE(S) REMOVAL AND INSTALLATION (M524-01-350-66400-01)	Attached sheet 3 (5/5)
	2014 ASX Workshop Manual	CGAE14E1-CD(ENG) CGAF14E1-CD(FRE) CGAG14E1-CD(GER) CGAS14E1-CD(SPA) CGAI14E1-CD(ITA) RUSSIA:N/A	TRIM REMOVAL AND INSTALLATION (M521-00-112-03100-01)	Attached sheet 3 (1/5)～(4/5)
			CURTAIN AIRBAG MODULE(S) REMOVAL AND INSTALLATION (M524-01-350-66400-01)	Attached sheet 3 (5/5)
	2015 ASX Workshop Manual	CGAE15E1-CD(ENG) CGAF15E1-CD(FRE) CGAG15E1-CD(GER) CGAS15E1-CD(SPA) CGAI15E1-CD(ITA) RUSSIA:N/A	TRIM REMOVAL AND INSTALLATION (M521-00-112-03100-01)	Attached sheet 3 (1/5)～(4/5)
			CURTAIN AIRBAG MODULE(S) REMOVAL AND INSTALLATION (M524-01-350-77200-01)	Attached sheet 3 (5/5)
EXP/GCC	2013 ASX/ OUTLANDER SPORT Workshop Manual	PWPE1204R (ENG) PWPS1205R (SPA)	GENARAL INFORMATION (M521-00-011-46600-01)	Attached sheet 4 (1/10)
			FLONT FLOOR CONSOLE ASSEMBLY REMOVAL AND INSTALLATON (M521-00-520-12600-01 Added under)	Attached sheet 4 (2/10)～(6/10)
			GENARAL INFORMATION (M524-00-012-74700-01)	Attached sheet 4 (7/10)
			DRIVER’S AIRBAG MODULE INSPECTION (M524-04-760-29100-01 Added under)	Attached sheet 4 (8/10)～(10/10)
MMNA/ MEXICO	2013 Outlander Sport Service Manual	MSCD-017B-2013 MEXICO:DRAFT	TRIM REMOVAL AND INSTALLATION (M521-00-112-03100-01)	Attached sheet 5 (1/4)～(3/4)
			CURTAIN AIRBAG MODULE(S) REMOVAL AND INSTALLATION (M524-01-350-71600-01)	Attached sheet 5 (4/4)
	2014 Outlander Sport Service Manual	MSCD-017B-2014 MEXICO:DRAFT	TRIM REMOVAL AND INSTALLATION (M521-00-112-03100-01)	Attached sheet 5 (1/4)～(3/4)
			CURTAIN AIRBAG MODULE(S) REMOVAL AND INSTALLATION (M524-01-350-71600-01)	Attached sheet 5 (4/4)


Attached sheet 3 (1/5)

TRIMS

INTERIOR TRIM

REMOVAL AND INSTALLATION

M1521001102031



Cowl side trim removal steps
1. Front scuff plate
2. Cowl side trim

Rear scuff plate removal step
- Rear seat cushion <<B>>
3. Rear scuff plate

<Added>

Front pillar trim removal steps
4. Front door opening trim
6. Front pillar trim
7. Front pillar trim clip <<A>> >>A<< <<A>> >>A<<

Centre pillar trim removal steps
1. Front scuff plate
- Rear seat cushion
3. Rear scuff plate
4. Front door opening trim

<Added>

<Except for MMNA production>


Centre pillar trim removal steps
5. Rear door opening trim
8. Centre pillar cover inner
9. Centre pillar trim lower
10. Centre pillar trim cap
11. Centre pillar trim upper

Rear shelf trim removal step
12. Rear shelf trim

Cargo floor box removal steps
13. Cargo floor lid
14. Cargo floor pad <Vehicles with cargo floor pad>
15. Cargo floor box (centre) <Vehicles with cargo floor box (centre)>
16. Cargo floor board front
17. Cargo floor box
18. Cargo floor box (LH/RH)

Attached sheet 3 (2/5)

CLIP AND CLAW POSITIONS




<New>

Insert the Attached sheet 3 (3/5).


<Old>

Note
: Clip positions
: Claw positions



AC904458AB

NOTE: Each number in the illustration indicates a part number.


Section A – A
<Except for MMNA production>
Clip
6
7
Section A – A
<MMNA production>
6
Clip


<Added>
/FRONT PILLAR TRIM CLIP

Attached sheet 3 (4/5)

REMOVAL SERVICE POINTS


<<A>>FRONT PILLAR TRIM REMOVAL


<Old>




1. Pull down the front or rear pillar trim as shown in the figure.
2. Cut the clip at the cutting position shown in the figure, taking care not to damage the other components.
3. Remove the clip remaining on the front or rear pillar trim, taking care not to scratch the trim.
4. Remove the clip remaining on the vehicle side by breaking it to prevent damage to the flange of the clip mounting hole.

<New>





<<B>> CENTRE PILLAR TRIM CAP/QUARTER TRIM UPPER CAP REMOVAL





Remove the opening trim. Remove the trim cap by inserting the special tool ornament remover (MB990784) between the trim and body as shown in the illustration.

<Added>

INSTALLATION SERVICE POINT

>>A<< FRONT PILLAR TRIM/FRONT PILLAR TRIM CLIP INSTALLAION





Make sure that the clip is installed in the correct direction.

Attached sheet 3 (5/5)

CURTAIN AIR BAG MODULE(S)


REMOVAL AND INSTALLATION

M1524013500664

⚠ CAUTION

- **Disconnect the negative (–) battery terminal and wait for 60 seconds or more before starting work. Insulate the disconnected (–) terminal by wrapping the tape (Refer to the item 5 of Service Precautions).**
- **Never attempt to disassemble or repair the air bag module. If faulty, replace it with new one(s).**
- **Handle the air bag module with sufficient caution, and do not drop the module or allow contact with water, oil, or others. If denting, cracking, or deformation is discovered, replace it with new one(s).**
- **Store the air bag module on a flat surface. Also, do not put anything on it.**
- **Do not store the air bag modules in a place more than 93°C.**
- **After the curtain air bag deployment, replace the curtain air bag module with a new part.**
- **Put on gloves and safety glasses when handling deployed air bags.**
- **When discarding the air bag module, make sure to deploy the air bag before the disposal.**

Pre-removal operation
- Turn the ignition switch to the LOCK (OFF) position.
- Disconnect the negative (–) battery terminal.



AC904712 AC

Removal steps
- Headlining (Refer to GROUP 52A – Headlining).

<<A>> 1. Curtain air bag module connector
<<B>> 2. Curtain air bag module

Installation steps

>>A<<
- Pre-installation inspection

>>B<< 2. Curtain air bag module

<Added>

Installation steps (Continued)

>>C<< 1. Curtain air bag module connector
- Headlining (Refer to GROUP 52A – Headlining).

>>D<<
- Post-installation inspection

NOTE: The figure shows the right curtain air bag module.

- **When the front pillar trim is installed after the air bag module has been installed, make sure that the its trim clip faces towards the right direction. (Refer to GROUP 52A - Interior trim)**

Attached sheet 4 (1/10)

GENERAL INFORMATION

M1521000101466

OUTLINE OF CHANGES

- The gearshift 4WD switch has been changed, the service procedure has been established. The other service procedures are the same as before.
- The service procedures have been changed as the front pillar trim clip must be installed in the opposite direction on vehicles maufactured at MMNA.

<Added>

Attached sheet 4 (2/10)

Removal steps (Continued)

5. Gearshift 4WD switch <4WD>
6. Floor console panel
7. Gearshift lever cover assembly <M/T>
- Rear floor console assembly (Refer to).
- Shift panel (Refer to GROUP 23A – Transmission control).
8. Accessory socket assembly
9. Floor console front
- Inside transmission antenna assembly (front) (Refer to GROUP 42B – Outside Transmission Antenna Assembly, Inside Transmission Antenna Assembly, Receiver Antenna Module).
10. Floor console centre
11. Floor console trim plate bracket
12. Floor console bracket centre

Insert the Attached sheet 4 (3/10) to (6/10).

<Added>


Attached sheet 4 (3/10)

TRIMS

INTERIOR TRIM

REMOVAL AND INSTALLATION

M1521001102451



ACA00650AB

Cowl side trim removal steps

1. Front scuff plate
2. Cowl side trim

Rear scuff plate removal step

- Rear seat cushion

3. Rear scuff plate

<<A>> >>A<<

<<A>> >>A<<

Front pillar trim removal steps

4. Front door opening trim
6. Front pillar trim
7. Front pillar trim clip <Except for MMNA product>

Centre pillar trim removal steps

1. Front scuff plate

- Rear seat cushion

3. Rear scuff plate

Attached sheet 4 (4/10)

Centre pillar trim removal steps

4. Front door opening trim
5. Rear door opening trim
8. Centre pillar cover inner
9. Centre pillar trim lower

<<B>>

10. Centre pillar trim cap
11. Centre pillar cover upper
12. Centre pillar trim upper

Rear shelf trim removal step

13. Rear shelf trim

Cargo floor box removal steps

14. Cargo floor lid
15. Cargo floor pad <Vehicles with cargo floor pad>
16. Cargo floor board front
17. Cargo floor box
18. Cargo floor box (LH/RH)

Rear end trim removal steps

14. Cargo floor lid
16. Cargo floor board front
17. Cargo floor box
19. Rear end trim

Quarter trim removal steps

- Rear seat cushion
- Rear seat back assembly

3. Rear scuff plate

Quarter trim removal steps


5. Rear door opening trim
13. Rear shelf trim
14. Cargo floor lid
15. Cargo floor pad <Vehicles with cargo floor pad>
16. Cargo floor board front
17. Cargo floor box
18. Cargo floor box (LH/RH)
19. Rear end trim
20. Parcel strap hook
21. Quarter trim lid
22. Luggage room lamp
23. Quarter trim lower


<<B>>

24. Quarter upper trim cap
25. Quarter trim upper

NOTE: For the vehicles with curtain air bag, install the front pillar trim provided for curtain air bag.

CLIP AND CLAW POSITIONS







ACE01041AB

NOTE: Each number in the illustration indicates a part number.

REMOVAL SERVICE POINTS


<<A>>FRONT PILLAR TRIM/FRONT PILLAR TRIM CLIP REMOVAL





1. Pull down the front pillar trim as shown in the figure.
2. Cut the front pillar trim clip at the cutting position shown in the figure, taking care not to damage the other components.
3. Remove the front pillar trim clip remaining on the front pillar trim, taking care not to scratch the trim.
4. Remove the front pillar trim clip remaining on the vehicle side by breaking it to prevent damage to the flange of the clip mounting hole.


<<B>> CENTRE PILLAR TRIM CAP/QUARTER TRIM UPPER CAP REMOVAL




Remove the opening trim. Remove the trim cap by inserting the special tool ornament remover (MB990784) between the trim and body as shown in the illustration.

INSTALLATION SERVICE POINT

>>A<< FRONT PILLAR TRIM/FRONT PILLAR TRIM CLIP INSTALLATION





Make sure that the clip is installed in the correct direction.

Attached sheet 4 (7/10)

GENERAL INFORMATION

M1524000102747

OUTLINE OF CHANGE

- The service procedure has been changed as the steering wheel has been changed. The other service procedures are the same as before.

- The service procedure for the curtain air bag have been changed as the front pillar trim clip must be installed in the opposite direction on vehicles maufactured at MMNA.

<Added>

SERVICE PRECAUTION


M1524000302075

⚠ CAUTION
Never heat or incinerate the airbag modules and the seat belt pre-tensioners.

WARNING/CAUTION LABELS

M1524003002299


Driver's air bag module



ACB03681AB

Attached sheet 4 (8/10)

- Clock spring connector terminal 1 and horn connector terminal 1
- Clock spring connector terminal 5 and horn connector terminal 5



4. As shown in the Figure, connect the circuit tester to special tool extra fine probe (MB992006) and check to see that there is a charge between the terminals.

Insert the Attached sheet 4 (9/10) to (10/10).

<Added>

CURTAIN AIR BAG MODULE(S)


REMOVAL AND INSTALLATION

M1524013500794

⚠ CAUTION

- **Disconnect the negative (–) battery terminal and wait for 60 seconds or more before starting work. Insulate the disconnected (–) terminal by wrapping the tape (Refer to the item 5 of Service Precautions).**
- **Never attempt to disassemble or repair the air bag module. If faulty, replace it with new one(s).**
- **Handle the air bag module with sufficient caution, and do not drop the module or allow contact with water, oil, or others. If denting, cracking, or deformation is discovered, replace it with new one(s).**
- **Store the air bag module on a flat surface. Also, do not put anything on it.**
- **Do not store the air bag modules in a place more than 93°C.**
- **After the curtain air bag deployment, replace the curtain air bag module with a new part.**
- **Put on gloves and safety glasses when handling deployed air bags.**
- **When discarding the air bag module, make sure to deploy the air bag before the disposal.**
- **When the front pillar trim is installed after the air bag module has been installed, make sure that the its trim clip faces towards the right direction. (Refer to GROUP 52A - Interior trim)**

Pre-removal operation
- Turn the ignition switch to the LOCK (OFF) position.
- Disconnect the negative (–) battery terminal.



AC904712 AC

Removal steps
- Headlining (Refer to GROUP 52A – Headlining).

<<A>> 1. Curtain air bag module connector
<<B>> 2. Curtain air bag module

Installation steps

>>A<< • Pre-installation inspection
>>B<< 2. Curtain air bag module

Installation steps (Continued)


>>C<< 1. Curtain air bag module connector
- Headlining (Refer to GROUP 52A – Headlining).

>>D<< • Post-installation inspection

NOTE: The figure shows the right curtain air bag module.

REMOVAL SERVICE POINTS

<<A>> CURTAIN AIR BAG MODULE CONNECTOR REMOVAL



Use the flat-tipped screwdriver to pull out the locking button of wiring harness side connector, and release the lock.

<<B>> CURTAIN AIR BAG MODULE REMOVAL

⚠ CAUTION

- **Never use an electric tester to diagnose the air bag module circuit. Never attempt to disassemble the air bag module.**
- **The removed air bag module should be stored in a clean, dry place.**
- **When discarding the air bag module, discard after deploying the air bag as specified in the service procedure.**

INSTALLATION SERVICE POINTS

>>A<< PRE-INSTALLATION INSPECTION

1. Before the installation, check the air bag module.

   NOTE: Even when installing a new air bag module, perform an inspection before the installation.

2. Connect the negative (–) battery terminal.

⚠ CAUTION

Be sure to turn the ignition key to the LOCK (OFF) position when connecting or disconnecting M.U.T.-III.

3. Connect M.U.T.-III to the diagnosis connector (16 pin).
4. Turn the ignition switch to the ON position.
5. Read the diagnosis code, and check that everything is normal except the air bag module open circuit.
6. Turn the ignition switch to the LOCK (OFF) position.

>>B<< CURTAIN AIR BAG MODULE INSTALLATION

⚠ CAUTION

- **Take care not to contort the curtain air bag when installing it.**
- **Do not trap the air bag with the peripheral parts.**
- **Do not trap the strap with the front pillar trim clip or others.**


>>C<< CURTAIN AIR BAG MODULE CONNECTOR INSTALLATION

⚠ CAUTION

Connect the connector to the inflator thoroughly.

>>D<< POST-INSTALLATION INSPECTION

1. Turn the ignition switch to the "ON" position.



2. Check that the SRS warning lamp is illuminated for 6 to 8 seconds, and extinguished afterward.
3. If the lamp does not extinguish, perform the troubleshooting.


Attached sheet 5 (1/4)

TRIMS

INTERIOR TRIM

REMOVAL AND INSTALLATION

M1521001102031



Cowl side trim removal steps
1. Front scuff plate
2. Cowl side trim

Rear scuff plate removal step
- Rear seat cushion

3. Rear scuff plate

Front pillar trim removal steps
4. Front door opening trim
6. Front pillar trim

<Added>
<<A>> >>A<<
<<A>>
7. Front pillar trim clip
<Deleted>

Center pillar trim removal steps
1. Front scuff plate

- Rear seat cushion

3. Rear scuff plate

<<B>>

Center pillar trim removal steps
4. Front door opening trim
5. Rear door opening trim
8. Center pillar cover inner
9. Center pillar trim lower
10. Center pillar trim cap
11. Center pillar trim upper


Rear shelf trim removal step
12. Rear shelf trim <Vehicles with rear shelf trim>


Cargo floor box removal steps
13. Cargo floor lid
14. Cargo floor board front
15. Cargo floor box
16. Cargo floor box (LH/RH)

TSB Revision

Attached sheet 5 (2/4)

CLIP AND CLAW POSITIONS






AC904458AB

NOTE: Each number in the illustration indicates a part number.

TSB Revision

REMOVAL SERVICE POINTS

<Old>





<<A>>FRONT PILLAR TRIM REMOVAL

1. Pull down the front or rear pillar trim as shown in the figure.
2. Cut the clip at the cutting position shown in the figure, taking care not to damage the other components.
3. Remove the clip remaining on the front or rear pillar trim, taking care not to scratch the trim.
4. Remove the clip remaining on the vehicle side by breaking it to prevent damage to the flange of the clip mounting hole.

<<B>> CENTER PILLAR TRIM CAP/QUARTER TRIM UPPER CAP REMOVAL

Remove the opening trim. Remove the trim cap by inserting the special tool ornament remover (MB990784) between the trim and body as shown in the illustration.






<New>

INSTALLATION SERVICE POINT

>>A<< FRONT PILLAR TRIM INSTALLAION

Make sure that the clip is installed in the correct direction.



<Added>

Attached sheet 5 (4/4)

CURTAIN AIR BAG MODULE(S)

REMOVAL AND INSTALLATION

M1524013500716


⚠ WARNING

- ***Never attempt to disassemble or repair the curtain air bag modules. If faulty, replace it.***
- ***Do not drop the curtain air bag modules or allow contact with water, grease or oil. Replace it if a dent, crack, deformation or rust is detected.***
- ***Do not expose the curtain air bag modules to temperatures over 93 ℃ (200 ℉).***
- ***Wear gloves and safety glasses when handling air bags that have already deployed.***
- ***Certain components of this vehicle, such as air bag modules and seat belt pre-tensioners, may contain perchlorate materials. Before deployment and/or disposal of these components, review and comply with all applicable Federal, state and local regulations.***
- ***An undeployed curtain air bag module should only be disposed of in accordance with the procedures.***
- ***When removing and installing the front passenger seat, be sure to carry out accuracy check occupant classification sensor after the seat has been installed in the vehicle. (On-vehicle Service.)***

Pre-removal Operation
- Turn the ignition switch to the "LOCK" (OFF) position.

<Added>

- When the front pillar trim is installed after the air bag module has been installed, make sure that the its trim clip faces towards the right direction. (Refer to GROUP 52A - Interior trim)



ACA03439AB

Removal steps

<<A>> 1. Negative (–) battery cable connection
- Headlining (Refer to GROUP 52A, Headlining).

<<B>> 2. Curtain air bag module connector connection

<<C>> 3. Curtain air bag module

Installation steps

>>A<< • Pre-installation inspection

>>B<< 3. Curtain air bag module

>>C<< 2. Curtain air bag module connector connection
- Headlining (Refer to GROUP 52A, Headlining).

1. Negative (–) battery cable connection

>>D<< • Post-installation inspection

TSB Revision