SERVICE BULLETIN

MITSUBISHI MOTORS

GLOBAL AFTER SALES OFFICE, MITSUBISHI MOTORS CORPORATION

PURPOSE : CHANGE	ISSUE NO. : MSB-14EXMPC37-001	DATE : 2014-05-30
SUBJECT : POWER STEERING HOSE REMOVAL AND INSTALLATION		<DESTINATION/MODEL> (As per attached sheet 1) <M/Y> 07-15
GROUP : STEERING(Gr:37)		

1. Description :

Please refer to the attached document for the information about the change of mention in the applicable service manual. (Additional service procedures regarding the power steering and the pressure hose assembly are created.)

2. Affected service manuals :

Please refer to the attached document (Attached sheet 1)

3. About the details :

Please refer to the attached document (Attached sheet 2)

4. Effective time : From the vehicle produced initially

【For overseas market】
<MMNA/MEXICO(Pub No.: DRAFT)>
LANCER/LANCER SPORTBACK

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2008 LANCER Service manual	MSCD-106B-2008	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-07001-01)
2009 LANCER Service manual	MSCD-106B-2009	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-81001-01)
2009 LANCER SPORTBACK Service manual	MSCD-014B-2009	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-12500-01)
2010 LANCER Service manual	MSCD-106B-2010	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-81001-01)
2010 LANCER SPORTBACK Service manual	MSCD-014B-2010	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-12500-01)
2011 LANCER/LANCER SPORTBACK Service manual	MSCD-106B-2011 (Mexico: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-46001-01)
2012 LANCER/LANCER SPORTBACK Service manual	MSCD-106B-2012 (Mexico: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-46001-01)
2013 LANCER/LANCER SPORTBACK Service manual	MSCD-106B-2013 (Mexico: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-46001-01)
2014 LANCER/LANCER SPORTBACK Service manual	MSCD-106B-2014 (Mexico: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-46001-01)

LANCER EVOLUTION

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2008 LANCER EVOLUTION Service manual	MSCD-206B-2008	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-97301-01)
2009 LANCER EVOLUTION Service manual	MSCD-206B-2009	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-97301-01)
2010 LANCER EVOLUTION Service manual	MSCD-206B-2010	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-97301-01)
2011 LANCER EVOLUTION Service manual	MSCD-206B-2011	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-97302-01)
2012 LANCER EVOLUTION Service manual	MSCD-206B-2012	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-97302-01)
2013 LANCER EVOLUTION Service manual	MSCD-206B-2013	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-97302-01)
2014 LANCER EVOLUTION Service manual	MSCD-206B-2014	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-97302-01)

OUTLANDER

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2007 OUTLANDER Service manual	MSCD-007B-2007	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-34801-01)
2008 OUTLANDER Service manual	MSCD-007B-2008	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-79101-01)
2009 OUTLANDER Service manual	MSCD-007B-2009	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-79101-01)
2010 OUTLANDER Service manual	MSCD-007B-2010	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-79101-01)
2011 OUTLANDER Service manual	MSCD-007B-2011 (Mexico: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-79102-01)
2012 OUTLANDER Service manual	MSCD-007B-2012 (Mexico: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-79101-01)

<MEXICO>
OUTLANDER

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2008 OUTLANDER Service manual	DRAFT	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-39300-01)

<G.EXP/GCC>
LANCER/LANCER EX

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2008 LANCER/LANCER EX Workshop manual	PWME0701R(ENG) PWMS0702R(SPA) (South Africa, Argentina: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-21800-01)
2009 LANCER/LANCER EX Workshop manual	PWME0802R(ENG) PWMS0803R(SPA) (South Africa, Argentina: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-72400-01)
2010 LANCER/LANCER EX Workshop manual	PWME0901R(ENG) PWMS0902R(SPA) (South Africa, Argentina: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-72401-01)

LANCER EVOLUTION

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2009 LANCER EVOLUTION Workshop manual	PWSE0801R (China: DRAFT) PWSE0801R-A	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-84300-01)
2010 LANCER EVOLUTION Workshop manual	PWSE0905R (China: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-84301-01)

OUTLANDER

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2007 OUTLANDER Workshop manual	PWRE0607R (China, South Africa: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-03600-01)
2008 OUTLANDER Workshop manual	PWRE0707R(ENG) PWRS0708R(SPA) (Argentina, South Africa: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-44501-01)
2009 OUTLANDER Workshop manual	PWRE0810R(ENG) PWRS0811R(SPA) (China, Argentina, South Africa: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-74600-01)
2010 OUTLANDER Workshop manual	PWRE0906R(ENG) PWRS0907R(SPA) (China, Argentina, South Africa: DRAFT)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-26600-01)

<TAIWAN(Pub No:DRAFT)>
OUTLANDER

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2008 OUTLANDER Workshop manual	DRAFT	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-62700-01)

<CHINA(Pub No:DRAFT)>
LANCER EX

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2009 LANCER EX Workshop manual	DRAFT	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-96200-01)

<EU/RUSSIA(Pub No:N/A)>
LANCER/LANCER SPORTBACK

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2008 LANCER Workshop manual	CG1E08E2-CD(ENG) CG1F08E2-CD(FRE) CG1G08E2-CD(GER) CG1S08E2-CD(SPA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-51900-01)
2009 LANCER Workshop manual	CG1E09E1-CD(ENG) CG1F09E1-CD(FRE) CG1G09E1-CD(GER) CG1S09E1-CD(SPA) CG1I09E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-70200-01)
2009 LANCER SPORTBACK Workshop manual	CG4E09E1-CD(ENG) CG4F09E1-CD(FRE) CG4G09E1-CD(GER) CG4S09E1-CD(SPA) CG4I09E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-73500-01)
2010 LANCER Workshop manual	CG1E10E1-CD(ENG) CG1F10E1-CD(FRE) CG1G10E1-CD(GER) CG1S10E1-CD(SPA) CG1I10E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION <1800, 2000 (Petrol)> (M372-00-572-21100-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <1800 (Diesel)> (M372-00-572-32900-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <2000 Turbo (Diesel)> (M372-00-572-30700-01)
2010 LANCER SPORTBACK Workshop manual	CG4E10E1-CD(ENG) CG4F10E1-CD(FRE) CG4G10E1-CD(GER) CG4S10E1-CD(SPA) CG4I10E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION <Petrol> (M372-00-572-21100-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <1800 (Diesel)> (M372-00-572-31800-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <2000 (Diesel)> (M372-00-572-34100-01)
2011 LANCER/LANCER SPORTBACK Workshop manual	CG1E11E1-CD(ENG) CG1F11E1-CD(FRE) CG1G11E1-CD(GER) CG1S11E1-CD(SPA) CG1I11E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-44800-01)
2012 LANCER/LANCER SPORTBACK Workshop manual	CGSE12E1-CD(ENG) CGSF12E1-CD(FRE) CGSG12E1-CD(GER) CGSS12E1-CD(SPA) CGSI12E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-52300-01)
2013 LANCER/LANCER SPORTBACK Workshop manual	CCAE13E1-CD(ENG) CCAF13E1-CD(FRE) CCAG13E1-CD(GER) CCAS13E1-CD(SPA) CCAI13E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-52300-01)
2015 LANCER/LANCER SPORTBACK Workshop manual	CCAE15E1-CD(ENG) CCAF15E1-CD(FRE) CCAG15E1-CD(GER) CCAS15E1-CD(SPA) CCAI15E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-572-56700-01)

LANCER EVOLUTION

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2009 LANCER EVOLUTION Workshop manual	CGEE09E1-CD(ENG) CGEF09E1-CD(FRE) CGEG09E1-CD(GER) CGES09E1-CD(SPA) CGEI09E1-CD(ITA)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-61600-01)
2010 LANCER EVOLUTION Workshop manual	CGEE10E1-CD(ENG) CGEF10E1-CD(FRE) CGEG10E1-CD(GER) CGES10E1-CD(SPA) CGEI10E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-84301-01)
2011 LANCER EVOLUTION Workshop manual	CGEE11E1-CD(ENG) CGEF11E1-CD(FRE) CGEG11E1-CD(GER) CGES11E1-CD(SPA) CGEI11E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-84301-01)
2012 LANCER EVOLUTION Workshop manual	CGEE12E1-CD(ENG) CGEF12E1-CD(FRE) CGEG12E1-CD(GER) CGES12E1-CD(SPA) CGEI12E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-84301-01)
2013 LANCER EVOLUTION Workshop manual	CCZE13E1-CD(ENG) CCZF13E1-CD(FRE) CCZG13E1-CD(GER) CCZS13E1-CD(SPA) CCZI13E1-CD(ITA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-84302-01)

OUTLANDER (GS45X)

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2007 OUTLANDER Workshop manual	CGXE07E1-CD(ENG) CGXF07E1-CD(FRE) CGXG07E1-CD(GER) CGXS07E1-CD(SPA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-570-98100-01)
2008 OUTLANDER Workshop manual	CGXE08E2-CD(ENG) CGXF08E2-CD(FRE) CGXG08E2-CD(GER) CGXS08E2-CD(SPA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-36000-01)
2009 OUTLANDER Workshop manual	CGXE09E2-CD(ENG) CGXF09E2-CD(FRE) CGXG09E2-CD(GER) CGXS09E2-CD(SPA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION <2400> (M372-00-572-08400-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <3000> (M372-00-572-18100-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <2000> (M372-00-572-19200-01)
2010 OUTLANDER Workshop manual	CGXE10E1-CD(ENG) CGXF10E1-CD(FRE) CGXG10E1-CD(GER) CGXS10E1-CD(SPA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION <2400, 2000(PETROL)> (M372-00-572-36300-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <3000> (M372-00-572-18100-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <2000(DIESEL)> (M372-00-572-37400-01)
2011 OUTLANDER Workshop manual	CGXE11E1-CD(ENG) CGXF11E1-CD(FRE) CGXG11E1-CD(GER) CGXS11E1-CD(SPA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION <4B1> (M372-00-572-47100-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <6B3> (M372-00-572-48200-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <4N1> (M372-00-572-49300-01)

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2012 OUTLANDER Workshop manual	CGXE12E1-CD(ENG) CGXF12E1-CD(FRE) CGXG12E1-CD(GER) CGXS12E1-CD(SPA) (Russia: N/A)	POWER STEERING HOSE REMOVAL AND INSTALLATION <4B1> (M372-00-572-47100-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <6B3> (M372-00-572-48200-01)
		POWER STEERING HOSE REMOVAL AND INSTALLATION <4N1> (M372-00-572-49300-01)

<RUSSIA(Pub No: N/A)>
OUTLANDER

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2007 OUTLANDER Workshop manual	N/A	POWER STEERING HOSE REMOVAL AND INSTALLATION (M372-00-571-04700-01)

<PEUGEOT(Pub No: N/A)>
4007

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2008 4007 Workshop manual	N/A	POWER STEERING HOSE REMOVAL AND INSTALLATION <2400> (M372-00-571-52000-01)
2009 4007 Workshop manual	N/A	POWER STEERING HOSE REMOVAL AND INSTALLATION <2400> (M372-00-572-23300-01)
2010 4007 Workshop manual	N/A	POWER STEERING HOSE REMOVAL AND INSTALLATION <2400> (M372-00-572-23300-01)

<CITROEN(Pub No: N/A)>
C-CROSSER

Applicable manual	Pub. No.	Applicable title (INFO-ID)
2008 C-CROSSER Workshop manual	N/A	POWER STEERING HOSE REMOVAL AND INSTALLATION <2400> (M372-00-571-52000-01)
2009 C-CROSSER Workshop manual	N/A	POWER STEERING HOSE REMOVAL AND INSTALLATION <2400> (M372-00-572-23300-01)
2010 C-CROSSER Workshop manual	N/A	POWER STEERING HOSE REMOVAL AND INSTALLATION <2400> (M372-00-572-23300-01)





PRESSURE HOSE ASSEMBLY/HOSE BRACKET INSTALLATION

1. Install the pressure hose assembly to the steering gear and linkage with the gasket and the eye bolt, and then tighten the eye bolt by hand.
2. Install the hose bracket to the steering gear and linkage.
3. Install the pressure hose assembly to the hose bracket while pulling it upwards.

⚠ CAUTION

Make sure that the pressure hose assembly is secured when you tighten the eye bolt.

4. Tighten the eye bolt to the specified torque with holding the pressure hose assembly by hand.
5. Check the clearance between the pressure hose assembly and the backbone brace.

   Standard value: 5 mm (0.2 in) or more