SERVICE BULLETIN

MITSUBISHI MOTORS

GLOBAL AFTER SALES OFFICE, MITSUBISHI MOTORS CORPORATION

PURPOSE : CHANGE	ISSUE NO. : MSB-13E35-001	DATE : 2013-11-18
SUBJECT : G & YAW RATE SENSOR TYPE RESET		<DESTINATION/MODEL> (EUR) COLT/COLT CZ3/COLT CZT/COLT CZC <M/Y> 05-11
GROUP : ASC(Gr:35C)		

1. Description :

Please refer to the attached document for the information about the change of mention in the applicable service manual.

2. Affected service manuals :

Please refer to the attached document (Attached sheet 1)

3. About the details :

Please refer to the attached document (Attached sheet 2)
(We have added the procedure of G& YAW rate sensor type reset)

For overseas market

Attached sheet 1

Destination	Applicable manual	Pub. No.	Applicable title (INFO ID)	Content
EU	2005 COLT Workshop Manual	CZME05E1-CD (Eng) CZME05E2-CD (Eng) CZMS05E1-CD (Spa) CZMF05E1-CD (Fra) CZMG05E1-CD (Ger)	ON-VEHICLE SERVICE, STEERING WHEEL SENSOR (M355-00-920-03700-01) after	Attached sheet 2
	2006 COLT CZ3, COLT CZT Workshop Manual	CZ2E06E1-CD (Eng) CZ2S06E1-CD (Spa) CZ2F06E1-CD (Fra) CZ2G06E1-CD (Ger)		
	2007 COLT CZC Workshop Manual	CZ8E07E1-CD (Eng) CZ8S07E1-CD (Spa) CZ8F07E1-CD (Fra) CZ8G07E1-CD (Ger)		
	2005-2007 COLT, COLT CZ3, COLT CZT Workshop Manual	CZME07E1-CD (Eng)		
	2008 COLT Workshop Manual	CZME08E1-CD (Eng) CZMS08E1-CD (Spa) CZMF08E1-CD (Fra) CZMG08E1-CD (Ger)		
	2007-2008 COLT CZC Workshop Manual	CZ8E08E1-CD (Eng) CZ8S08E1-CD (Spa) CZ8F08E1-CD (Fra) CZ8G08E1-CD (Ger)		
	2009 COLT (Z30A) Workshop Manual	CZME09E2-CD (Eng) CZMS09E2-CD (Spa) CZMF09E2-CD (Fra) CZMG09E2-CD (Ger) CZMI09E2-CD (Ita)	ON-VEHICLE SERVICE, STEERING WHEEL SENSOR (M355-00-920-22001-01) after	
	2011 COLT (Z30A) Workshop Manual	CZME11E1-CD (Eng) CZMS11E1-CD (Spa) CZMF11E1-CD (Fra) CZMG11E1-CD (Ger) CZMI11EI-CD (Ita)	ON-VEHICLE SERVICE, STEERING WHEEL SENSOR (M355-00-920-22002-01) after	

G AND YAW RATE SENSOR TYPE RESET

⚠ CAUTION

Before connecting or disconnecting M.U.T.-III, always turn the ignition switch to the "LOCK" (OFF) position.

1. Before setting M.U.T.-III, turn the ignition key to the "LOCK" (OFF) position.
2. Turn the ignition switch to the "ON" position.
3. Select the system from the menu.
4. On the "System selection" screen, select "ABS/ASC/ASTC/WSS" in the system list, and then click the "OK" button.
5. Select "Special function" in the "ABS/ASC/ASTC/WSS" field.
6. In the "Special function" filed, select "Yaw rate sensor type reset."
7. Press the "OK" button.
8. Turn the ignition key to the "LOCK" (OFF) position, and remove the M.U.T.-III from the vehicle.

